



Instruction manual

: Wireless Charger Pad



Installation Steps



1. Please use qualified AC adapter Connect the usb power cord. The AC adapter should be 9V 1.67A or 20W above, otherwise insufficient input electric current might cause unstable charging.
2. When the power is connected, Product front the led Continuous light.
3. Place the back of the charging device with magnetic attraction function to the Product front, will attract each other, and automatically align the charging position to start charging.
4. Product front the led indicator will keep flashing or the charging pad will switch off by itself when charging goes wrong.

Technical Specifications

Name	: Wireless Charger Pad
Standard	: Qi
Conversion Rate	: ≤80%
Input	: 9V/1.67A & 20W above
Output	: 15W/10W/7.5W/5W

Safety Notice

1. Do not pull the power cord hard to avoid the power cord from breaking or falling off.
2. Do not disassemble by yourself or throw it into fire or water to avoid short circuit and leakage.
3. Do not use in severely high temperature, humidity or corrosive environments to avoid leakage of electricity due to damage to the circuit.

Frequently Asked Questions

1. Charging is slow. The mobile phone itself or the external receiving coil allows the wireless charging current to be different, or the application running consumes a lot of power when the mobile phone is charging. It is recommended to reduce or close the application.
2. The phone is charging intermittently, or the indicator light flashes. If the charging current is not enough, please use a charging head (adapter) with sufficient power 9V/1.67A or 20W above.
3. Charging fever. It is normal for the receiving coil or transmitter board to generate heat during wireless charging. If the plate is too warm, take your phone off the plate, and switch the plate off. The plate may switch off automatically if it is too hot. when the plate has cooled down, try charging again.
4. The charger does not work. Do not put metal debris or magnetic cards on the charging area. If the product does not work due to overheating, please take off the phone and wait for it to cool down and try charging again.
5. The host indicator is normal, but the mobile phone cannot work. It is recommended to replace the receiving coil or repair the mobile phone.
6. The indicator light of the host is not bright. If the host fails, contact after-sales maintenance.



FCC warning:

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

This device complies with part 15 of the FCC rules. operation is subject to the following two conditions:(1)this device may not cause harmful interference,and (2)this device must accept any interference received, including interference that may cause undesired operation