GK68

## User Manual

System Requirement

2.4G Mode：Windows XP/ Vista / Win7 / Win8 / Win10 / Mac
Bluetooth 5.0 Mode：Win8/Win10
Usb Port：Free USB (1.1/2.0/3.0) port

Installation steps

1. Take out the keyboard and insert the USB receiver into the USB interface of the computer.
2. Take out the attached battery and install it into the battery slot on the back of the keyboard
3. Restart the computer, the system will automatically install the driver
4. Wait for the computer to tell you that the new hardware is installed
5. Use your keyboard at this point
Note: It is recommended to connect the motherboard USB2.0 interface.

Warm Prompt

1. Do not pour any liquid into the keyboard, otherwise it will damage the keyboard
2. Clean the keyboard regularly to avoid accumulating too much dust and affecting the feel

Disclaimer

The information contained in this manual has been strived to be correct and complete, if any Any errors or omissions are not subject to any liability and the right is reserved to change this brochure at any time References to hardware and software without prior notice

Smart power saving mode

The keyboard will automatically enter after no key action for more than 30 minutes in 2.4G and Bluetooth mode，Sleep state, press any key to wake up the keyboard normal use.

Power switch

The power switch of this keyboard is in the back position. To turn ON the power switch of the keyboard, the switch should be moved to the ON position

OFF [ ] ON

2.4G wireless connection mode

Use 2.4G wireless connection mode, need to switch to 2.4G mode by using key combination after boot.And check whether the USB wireless receiver that comes with the unit has been plugged into the computer's USB interface.Plug in a USB receiver and use 2.4G wireless connection mode. The keyboard works in 2.4G mode at factory Paired, no need to pair, if you want to pair, long press FN+Q for more than 5 seconds, however Then insert the 2.4G receiver and the match is completed.

Fn — Q 2.4G   Switch to 2.4G mode (green light prompt)

F function key combination

Fn	1 ! / F1	F1
	2 @ / F2	F2
	3 # / F3	F3
	4 $ / F4	F4
	5 % / F5	F5
	6 ^ / F6	F6
	7 & / F7	F7
	8 * / F8	F8
	9 (/ F9	F9
	0) / F10	F10
	~ / F11	F11
	= + / F12	F12
	←Back / Pause Break	Pause Break

Other key combination functions

Fn	T	Music player
	Y	The volume reduction
	U	The volume increase
	I	Mute
	O	Stop playing
	P	In a song
	[{	On TV
	] }	The next song
	\ ~ / PrtSc	Print Screen/SysRq
	Del / Ins	Insert
	PgUp / Home	Home
	PgDn / End	End
	Win 🔒	Win key lock/unlock

FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-Reorient or relocate the receiving antenna.

-Increase the separation between the equipment and receiver.

-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-Consult the dealer or an experienced radio/TV technician for help.