


Instruction Manual



Wireless Charging

XE50-A


Product Introduction

XE50-A is a wireless charging device that can wirelessly charge mobile phones at intervals of 15-37mm. It is suitable for non-metallic desktops such as marble, wood, glass, etc., and can be placed on the desktop or installed at the bottom of the desktop. It can be used in homes, offices, hotels and more places. It can wirelessly charge mobile phones or other electronic devices that support the Qi standard, and the charging is stable. Different charging methods allow you to enjoy the wonderful life brought by infinite technology.

Smart Desk Stickers




Positioning light



Desk sticker

Induction Zone



Power Cord



Power Adapter

Installation Steps

Precautions before installation:

If installing under the desk, please make sure that the thickness of the desktop is within 37mm.

1

Take out the charger

Take out the wireless charger and tear off the 3M glue



Place the expected charging position

Paste the wireless charger at the expected charging position under the table, and the position of the light board is directly above it

2



(Figure 1 of installation steps). Desktop

3

Connect adapter

Plug in the power adapter and power on the wireless charger



(Figure 2 of installation steps)

4


Take out the auxiliary sticker

Open the bubble bag, take out the auxiliary sticker and put it on the table

5

Align the light board to brighten

Aim the light board at the bottom of the wireless charger until all lights are on



(Figure 3 of installation steps)

Paste auxiliary stickers


Tear off the 3M glue behind the upper part of the dotted line of the auxiliary sticker, and paste it on the table

6

7

Apply smart desk stickers

Tear off the circular sticker along the dotted line protrusion in the upper left corner of the auxiliary sticker, align and paste the smart table sticker




(Figure 4 of installation steps)

8

Tear off the sticker

Remove the auxiliary sticker on the outermost periphery of the indicator light




(Figure 5 of installation steps)

9

Charge anytime

Put your phone on the center of the smart sticker and start to use



(Figure 6 of installation steps)

Specifications

Input: 24V1A
Output: 10W (MAX)

Charging distance: 15-37mm
Size: $\phi 117*117$ mm

Note: Please choose a table top installed on non-metallic materials such as marble, wood, glass, etc., and the thickness is within 37mm

Safety Tips

1. Do not pull the power cord forcibly to avoid breaking or falling off the power cord.
2. Do not disassemble the XE50-A by yourself or throw it into fire or water to avoid short-circuit leakage.
3. Do not use XE50-A in severe high temperature, humid or corrosive environment to avoid leakage of electricity due to damage to the circuit.

Precautions

1. Please use a power adapter that supports QC2.0 and above protocols, otherwise it may cause unstable charging.
2. Do not place metal debris or magnetic cards on the wireless charging table, which may cause damage or the charger will not work.
3. During use, if the receiving coil or the transmitting board is overheated to stop charging, please remove the charging device and try again after cooling down.

FAQ

1. The wireless charging speed is relatively slow.

The mobile phone itself or the external receiving coil allows the wireless charging current to be different, or the application running consumes a lot of power when the mobile phone is charging. It is recommended to reduce or close the application.

2. Charging will heat up.

It is normal that the receiving coil or the transmitting board generates heat during the wireless charging process. It is recommended to adjust the charging position.

3. The wireless charging of the mobile phone does not work, and the host buzzer does not sound.

The installation method of the host is wrong or the wireless charging position of the mobile phone is wrong, please check the installation or place the mobile phone in the center of the desk sticker.⁰⁴

4. The host is installed correctly, the phone is placed in the correct position, the buzzer of the host does not ring when the power is on, and the phone does not charge.
5. If the host is faulty, contact after-sales maintenance.

Product After-sales Guide

Thank you for purchasing our XE50-A wireless wireless charger. In order to ensure you get reliable after-sales service, please read the following warranty instructions carefully.

Warranty Scope

The product fails to work normally or malfunctions during normal use, and can enjoy our company's after-sales service commitment after being certified by our company.

The following conditions are not covered by the warranty:

1. The accessories are not warranted;
2. Failure due to improper operation by the user;
3. Failures caused by accidental disasters, man-made damage, self-disassembly, unpacking, and repairs by non-authorized maintenance

Extended Service

If the product exceeds the warranty period, the customer still enjoys maintenance service, but the maintenance cost, material cost, etc. are required.



FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC RF exposure statement:

The equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance between 20cm the radiator your body.