

Remote control

Quick Start Guide

At a Glance

LED indicator

Arm button

Use when no one is at home. The alarm will sound in armed mode, when a door or window is opened, or when motion is detected.

Home arm button

Use when you're at home and want security. The alarm sounds when a door or window is opened.

Disarm button

Use when you don't want the security from the system. The alarm won't sound in disarmed model.

SOS button

Use in case of emergency. The alarm sounds and sends an alert notification to registered users.



Specifications

Power Supply: DC 3V (CR2025 Lithium Battery x1)

Standby Current: <5uA

Alarm Current: <15mA

Transmitting Distance: <80m (Open Area and No Interference)

Radio Frequency: 433Mhz

Operation Temperature: -10~55℃

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction