


SP06 说明书/成品尺寸:73*73mm 材质: 100g 铜版纸 印刷: 黑白印刷


SP06

User Manual
Please review this manual thoroughly before operating your device. In order to avoid unnecessary injuries, please do not Disassemble this product by yourself, and please use a standard charger.


Product Contains




Open ear Earbuds x2



Charging Case x1



USB Charging Cable x1




User Manual x1


Product Specification
Driver: 13mm
Support Profile: HFP / AVRCP / A2DP
Earbuds Charging Time: Up to 1.5 Hour
Charging case Charging Time: Up to 1.5 Hours
Working Voltage: 5V
Transmission Range: Up to 10m
Working Temperature:-30°-70°

Power On / off

- The earbuds will automatically turn on after opening the top lid of the charging case.
- Put the earbuds into the charging case and close the lid, they will automatically shut down.
- If you remove the earbuds but the earbuds are not powered on, please confirm if there is a protective film that needs to be removed before recharging the earbuds. Put the headphones back into the charging case and close the cover.
- If you put the earbuds back into the charging case compartment, close the lid, and the earbuds do not turn off, please charge the charging case.




Open



Close


First Pairing

Step1: Please turn on the bluetooth function on your cellphone/laptop.
Step2: Open the charging case, take out the earbuds, the blue lights flash on earbud.
Step3: Select "SP06" on your phone/laptop and connect the device, the red and blue lights off when you connect successfully.
(The earbuds will automatically turn off if not connected the device within 5minutes.)




Reset Earbuds
If only one earbud connects to phone / earbuds can not pair together. Please try the reset steps:
Step 1: Take out the earbuds from charging case.
Step 2: Turn off the Bluetooth of the phone, and quickly restore the factory settings by 5 clicks when the red/blue lights alternate on the earphones, But the TWS pairing information is unclear. The red and blue lights stay on for 1 second at the same time, and the device shuts down after turning red for 1 secondsuccessfully, please put earbuds back to charging case and take out again to connect the device again.

Product Wear




①




②

Step1: Take out the earbuds from charging case.
Step2: Hang the earbuds on your ears.


Product Control




Answer a Call
Short press the touch button once




End a call
Short press the touch button for 2 seconds




Reject call
Long press the touch button for 2 seconds




Play/Pause
Short press the touch button twice




Voice Assistant
Short press the touch button three times to call voice assistant.




Previous Song
Long press Left touch button for 2 seconds



Volume Up
Short press Right touch button once




Next Song
Long press Right touch button for 2 seconds




Volume Down
Short press Left touch button once

Product Charging



Charging Pins of Earphone



USB type-C Charging Port

Warranty
The warranty covers your device , including accessories against manufacturing defects for 1 year from the date of purchase.

Certification
This device complies with Part15of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
FCC ID:2A5LA-SP06

Safety For You

- ⚠ Do not expose device to liquids, moisture or humidity. It has electronics and a battery in it. Neither of them likes getting wet.
- ⚠ Don't use abrasive cleaning solvents to clean your device. Wipe them down with a slightly damp cloth if and when necessary.
- 🧼 Remove and clean the earbuds tips regularly, to ensure that you always enjoy the best sound possible from your device.
- ⚠ Do not expose device to extremely high or low temperatures as this may damage the battery or even deform the plastic parts.
- 💣 Don't throw yours device in a fire to dispose it. The internal battery may explode.
- ⚠ Don't try to disassemble your device. There are no user serviceable parts inside it.
- 🔑 Try not to drop your device and keep it away from sharp objects such as keys in your pockets.
- 🔌 Only charge your device from 5V USB ports such as phone chargers and laptops or PCs.
- 🔊 Never listen to music at high volumes or you may permanently damage your hearing.
- ⚠ Pay attention to your surroundings and never wear any headphones while riding, driving or walking in traffic. You do not come with any warranty.

FCC Caution

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.
This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-Reorient or relocate the receiving antenna.
-Increase the separation between the equipment and receiver.
-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-Consult the dealer or an experienced radio/TV technician for help.
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.