

EN  
PAU

# V10

## User Manual

Thanks for using our wireless electronic products. For a good user experience, please read the manual carefully before using the products. Notice: To avoid unnecessary troubles, please do not disassemble these products by yourself and use the standard charger to charge.

1

### Product Overview

- Choose the ear cap that suits you.

2

Make sure that the ear caps face down and put the earbuds into the ear in the angle shown as the picture on the right.

After putting on the earbuds, gently rotating the earbuds to a comfortable and secure position shown as picture 3 on the right. Now the earbuds are put on correctly!

### Error demonstration

Do not wear the earbuds like the way shown as the picture on the right

- 2
- 3
- 4

3

### First time using

- Tear off the insulating film.
- Put the earbuds into the charging case to charge.
- Take out from case, the indicator will turn to Red and Blue alternately.

**Warm notice:** If the earbuds are not turned on or there is no sound come out, please put them back in the charging case again to make sure that they are in the charging state before taking them out for use (red/blue light flash alternately)

4

- 1
- 2

4. Turn on the Bluetooth function on your phone and search for **【V10】** and connect it.

**Tips:** If the two earbuds can't pair under the first time using, or there is no sound in one of the earbuds, please proceed as follows:

#### Left/right Earbud Connection & Pairing

Hold the MFB buttons of the two earbuds simultaneously for 9s when they are in power off state, the earbuds will enter the interconnected pairing state (the blue light flashes quickly). When the interconnection and pairing of the two earbuds is successful, the red/blue lights of the two earbuds will be on for 2 seconds at the same time. Then, they will enter the mobile phone pairing mode and wait for the connection to the device (red and blue lights flash alternately).

5

### Button control

#### MFB Power Switch

Left Earbud Right Earbud

ON Take-out from case.  
OR press and hold for 5 seconds.

OFF When back into case.  
OR no connection for 5 minutes.

6

7

### Siri and other Voice Assistant

L / R Earbud

iOS users can triple-tap the left or right earbud to activate Siri and tap once to turn off Siri (this function only supports iOS system).

The voice assistant will be automatically activated depends in different OS in mobile system.

8

### Restore factory setting

If there is only one of the earbuds working due to misoperation, please follow below steps to fix it.

- Clear the record: Turn off the Bluetooth function of the phone, touch the MFB buttons for about 5 seconds when the earbuds are turned off. The earbuds will enter the pairing state (red/blue light flashes alternately), and then touch the MFB buttons four times quickly. After the red light is on for 1 second, the factory settings will be restored and the earbuds will automatically shut down.
- Reset: Put the left and right earbuds back into the charging case at the same time and reactivate them.
- Automatic pairing: Take out the left and right earbuds at the same time to automatically complete the pairing.
- After the earbuds are restored to the factory settings, please delete the historical connection record "V10", then search and reconnect again.

9

### Parameter specification

Version	V5.2+EDR
Support	A2DP,AVRCP,HFP,HSP
Transmission distance	10m
Frequency range	2.402GHz~2.480GHz
Hi-fi equipment	Φ6mm*2
Impedance	16Ω
Standby time	70 hours
Talk time	5 hours
Listening time	6 hours
Earbud battery capacity	55 mAh
Charging time	1.5 hour
Charging case battery capacity	300mAh
Charging case charging time	About 1 hours
Weight(single earbud)	4.7 g

10

### Earbuds indicator

Charging	Red light
Full battery	Green light

Status	Light
Turn on	The blue light flashes for 1 second
Turn off	The red light flashes for 1 second
Search earbuds	Red and blue light flash alternately
Connect with mobile phone successfully	No light
Music play	No light
Low battery	Red light of earbud flashes once every 6s
Charging	Red light on
Full battery	Red light off

11

### Charging case indicator

Low Battery	Red light
Charging	Red light
Full battery	Green light

Status	Indicator
Charging for case	Red light on
Full Battery	Green light on
Charging for earbuds	Red light on
Low Battery	Red light flashes

**Charging case**

Please use a charger with an output voltage of DC5V/1A to charge the charging case. You can also use a computer USB or other USB interface charger to charge (Must choose a charger certified by a regular manufacturer).

12

**Notice:**

△ If the charging case is out of power, it may cause the earbuds to fail to shut down and remain connected to the phone even when they are placed in the charging case. So please remember to charge the charging case in time.

△ If you want to switch the Bluetooth connection to another device, please disable the Bluetooth function in the previously connected device OR delete the pairing name of "V10" from the original device. Then the pairing name of "V10" can be searched in new device and connected successfully.

△ If moisture remains at the audio output hole, the sound may become fuzzy or completely inaudible. This is completely normal. In this case, please remove the earbuds and shake the audio output hole down several times to allow water to flow out or let it air dry for 1-2 hours, then the sound quality will become normal.

13

3. If there is noise, broken sound, or low sound, please take off the silicone ear cap and wipe it with a cotton swab.
4. If the earbud is not charged properly, wipe the charging column with a cotton swab, and then charge it again.

14

### Attentions

The Charging cable is not waterproof The Charging case is not waterproof Do not use hot water to disinfect the product

If there is water droplet on the surface, please wipe it with a dry cloth before putting them back into the charging case to avoid damaging the device.

**Tip:**

- If the product is dirty, please do not rinse it directly with water or use boiling water to soak and disinfect it. It is recommended to wipe the earbuds with an alcohol cloth or a wet paper towel.
- If the product falls into the water accidentally, please pick it up in time and dry it with natural wind or dry it in the sun for two hours before using it. (Otherwise it will affect the sound quality, thus fail to give you a better using experience)

15

- Do not use corrosive liquid to clean this product.
- If it comes into contact with chemicals, please rub it with a damp cloth wet with clean water.
- Do not use this product under extreme circumstances for temperature below -10 degree Celsius or above 60 degree Celsius.
- To avoid explosion, please do not throw this product into fire.
- To avoid scratches, please do not touch the earbuds with sharp objects.
- Do not insert objects into the earbuds, otherwise it would cause damage to the internal components.
- Do not disassemble the earbud.
- Please keep regular charge to earbuds, don't leave them become empty battery status to keep their lifetime.
- Please do not charge products with power adapter over 2A current. Excessive current may cause the damage to battery.

**Battery Warning !**

There is a built-in lithium battery in this product. To avoid explosion, do NOT expose the product to strong sunlight, fire or throw it into fire.

16

### FCC Caution

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirements. The device can be used in portable exposure condition without restriction.