


70.00 mm


60.00 mm

True Wireless Earbuds




User Guide

1. Package Accessories




2. Product Introduction



Usage Instructions

1. After you open the package for the first time use, please tear off the insulation film on the earbuds, then charge the earbuds and charging case via charging cable for at least 10 minutes; do not take out the earbuds during this period.



2. The choice of ear tips will affect your wearing comfort and the sound quality. The earbuds are installed with a pair of medium-sized ear tips by default. Please select the suitable size for better experience.

3. How to control

a) **Binaural mode instructions:**
Open the charging case and take out the earbuds or press and hold the Multifunctional Buttons (MFB) for 3 seconds in power-off state to turn them on, the left and right earbuds will enter TWS pairing mode automatically. After the pairing is successful, the indicator of the main earbud will flash red and blue light alternately and the indicator of the secondary earbud will go out, and a voice prompt "Pairing" will follow from the main earbud. At this time, turn on the Bluetooth function of your phone, search "T20" and click to pair. After the pairing is successful, the earbuds will prompt you with "Connected" and the indicators of earbuds will go out.

b) **Mono mode instructions:**
Open the charging case and take out a single earbud or press and hold the MFB for 3 seconds in power-off state to turn it on. Wait for about 15 seconds, and the earbud will enter pairing mode. At this time, the indicator of the earbud will flash red and blue light alternately and a voice prompt "Pairing" will follow. Turn on the Bluetooth function of your phone, search "T20" and click to pair. After the pairing is successful, the earbud will prompt you with "Connected".

Note:
If you are using one earbud in mono mode but you need to switch to binaural mode, and the charging case still has battery power, please open the charging case and take out the other earbud for use.

4. How to reset

- 1) Delete the pairing name "T20" on your mobile phone and turn off the Bluetooth function.
- 2) Press and hold the MFB for 5s, the earbuds turn off. Press and hold the MFB for 10 s, the blue light is constantly on 1s, and then the red light is constantly on 1s, the earbuds turn off.
- 3) Take out the earbuds from the charging case and they enter pairing mode. That means the earbuds have been reset successfully.
- 4) If the reset fails, please repeat the above steps.

5. How to control

| | |
|--------------------------|--|
| Turn on | 1. Take out earbuds, the earbuds in power-on state 2. Long press the L/R MFB button for 3 seconds in the power off state, and the red and blue lights flicker alternately. |
| Turn off | 1. Put the earbuds into the charging case, the earbuds in power-off state 2. Long press the MFB key of any earbud for 5 seconds to turn off and the red light is on for 1 second when the connected or unconnected device is turned on. |
| Play/Pause | Click the MFB on L/R earbud |
| Previous song | Hold the MFB on L earbud for 2s |
| Next song | Hold the MFB on Rearbud for 2s |
| Volume down | Three clicks the MFB on L earbud |
| Volume up | Three clicks the MFB on Rearbud |
| Answer/Hang up a call | Click the MFB on L/R earbud |
| Reject a call | Press and hold the MFB on L/R earbud for 2s |
| Activate voice assistant | Click the MFB on L/R earbud 2times |

6. Product parameters

| | |
|--|---|
| Version | 5.0 |
| Support protocol | HFP, A2DP, AVRCP |
| Working distance | About 10M (barrier-free) |
| Working time | Up to 5 hours (Varies by volume level and audio contents) |
| Single earbud/charging case battery capacity | 40mAh/500mAh |
| Charging times | 4 times |
| Input current | 5V/1A |
| Charging time of earbuds | About 1.5 hours |
| Charging time of charging case | About 1.5 hours |

7. LED indicator

| Status | Description |
|--------------------------------|---|
| Turn on | Blue light for about 2s |
| Turn off | Red light for about 2s |
| Successful pairing of earbuds | The main earbud flashes red and blue light alternately and the indicator of the secondary earbud goes out |
| Successful connection | Indicators of both earbuds go out |
| Earbuds are being charged | Red light is constantly on |
| Earbuds are fully charged | The light of indicators go out |
| Charging case is being charged | Green light is constantly on |
| Charging case is fully charged | The light of indicator goes out |

FAQ

1. The charging case still has battery power, but why the earbuds can not be charged?
A. Please confirm that the earbuds are correctly placed in the charging case. Otherwise, the earbuds can not be charged if the charging pins of earbuds and charging case don't contact fully.
B. Wipe the pins (golden part) of the earbuds and the charging case with a clean cotton cloth to ensure that there are no foreign objects. (If there is sweat or liquid on the charging pins of the charging case, it may cause corrosion to the earbuds. If there is sweat or liquid on the charging pins or the earbuds, please wipe it clean and then put the earbuds back into the charging case.)
2. Why the earbuds are still in connection status when the earbuds are placed in the charging case and the charging case is closed?
The possible cause is that the earbuds are not correctly placed in the charging case. Properly place the earbuds in the charging case to disconnect from the device.
3. Why is there a jamming when using the earbuds?
Due to the characteristics of Bluetooth earbuds, the electromagnetic wave interference in the area may cause temporary jamming. Please change a place for use.
4. Can the left and right earbuds be connected separately to two different devices in binaural mode?
No.

FCC Statement:
This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: 1) this device may not cause harmful interference, and 2) this device must accept any interference received, including interference that may cause undesired operation. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try correct the interference by one or more of the following measures:
- Reorient the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help. Changes or modifications not expressly approved by the party responsible for compliance could void your authority to operate the equipment.
FCC ID: 2A50U-2068

客供，70X60MM 五折页