


CEILING FAN LAMP REMOTE CONTROLLER



USER MANUAL



ATTENTION!

DO NOT USE THIS FAN WITH A DIMMER SWITCH OR VARIABLE SPEED WALL CONTROL. USING A DIMMER SWITCH OR VARIABLE SPEED WALL CONTROL WILL DAMAGE THE FAN.






- ① Input Live Wire(Black Line)
- ② Input Neutra Wire (White Line)
- ③ Output Neutral Wire(White Line)
- ④ Connection Motor Live Wire(Black Line)
- ⑤ Connection Lamp Live Wire(Blue Line)

① Fan Speed Controle

② Motor Switch

③ Lamp Switch

Battery Replacement: 3A/1.5V



This remote is pre-programmed from the factory and should work right out of the box once the battery is installed. Should, for any reason, reprogramming be needed, please follow the syncing process as follow:

SYNCING INSTRUCTIONS:

Turn off the main power, then turn it back on. Within 10 seconds, press and hold the high and low speed buttons on the remote at the same time for 3 seconds. The LED indicator will flash 1 times, signaling a successful synchronization. Once complete, the fan will start on the low speed with the light(if applicable) off.

FCC Statement:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the

user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.