


Quick Installation Guide&Warranty Card


Packing list : PCIe Adapter/Low Profile Brackets/Detachable dualband-5db antenna/ 30cm Bluetooth USB cable/Quick Installation Guide&Warranty Card/CD Driver

Connect to a Computer

a. Turn off your computer, unplug the power cable then remove the case panel.




b. Connect the provided Bluetooth USB cable to the adapter.



c. Locate an available PCIe slot and carefully insert the adapter.

Note:


If the bracket is not suitable for your computer, detach it from the adapter's board and replace it with the low-profile bracket.



d. Locate an available F_USB connector and carefully plug the Bluetooth USB cable into it.

Note:

If the Bluetooth USB cable is not correctly connected to the motherboard, Bluetooth function won't work even after driver installation.




e. Connect the antenna(s) to the adapter.

Tip:

To maximize performance, make sure the path between the antenna(s) and your router is clear.

f. Replace the case panel, plug in the power cable and turn on your computer.



Install Drivers

a. Insert the CD and open the directory.


Tip:

You can also check out the new Wireless - WiFi 6E AX210 at ark.intel.com Driver, and download the driver, or contact seller.

b. Install the Wi-Fi and Bluetooth drivers.

① Wi-Fi: Click on the Wi-Fi driver directory, according to the computer system 32/64 bit select the installation program, and follow the on-screen instructions to complete the installation.

② Bluetooth: Click on the Bluetooth driver directory, select the installation program, and follow the on-screen instructions to complete the Bluetooth installation.



Wi-Fi




Bluetooth

Join a Wireless Network

a. Click the network icon (📶 or 📶) on the taskbar.

b. Select your Wi-Fi network, click Connect, and enter the password when prompted.




Pair With Bluetooth Devices

a. Right click the Bluetooth icon on the taskbar. If it's not displayed, turn on Bluetooth in your PC settings first.

b. Select Add a Bluetooth Device or Add a Device to scan for available devices.

c. Select your Bluetooth device from the list and follow the onscreen instructions to complete pairing.

Note: Make sure your device's Bluetooth is enabled and discoverable.



Product Warranty Card

1. Below following cases, it is out of the warranty scope. Please note:

- The return/warranty period has been exceeded;
- Failures to install, use, maintain or keep the product according to the instructions; Alter without authorization; Tear up product bar code;
- Without authorization, modify the inherent Settings of the file or unauthorized dismantling repair;
- Damage to the product caused by accident or human behavior/such as focusing on bright light, inappropriate voltage input, high temperature, water, mechanical damage, breaking, serious oxidation or rusting of the product;
- Product failure or damage caused by force majeure such as earthquakes, fires, floods, lightning strikes, etc. Other failures or damages that are not caused by the product's own design, technology, manufacturing, quality, etc.

2. Technical Support and Software Upgrade Service

Before you send the product for repair, please contact seller to identify product failures.

3. Product has one-year warranty service.

Special Note

- If there are obvious hard object damage, cracks, broken feet, severe deformation, broken power cord, broken wire, bare core, etc. due to improper use by the customer or accidental factors, it will not be guaranteed and replaced, and the user can purchase it separately.
- Warranty replacement service is limited to the mainframe. Packaging and cables, software products, technical documents and other accessories are not covered by the warranty. The warranty period for the external antenna and main components is 3 months.
- If there are equipment performance problems within 15 days after the product is purchased, and the appearance is not scratched, you can directly replace it with a new product. During the free warranty period, the product must be inspected by seller. After the problem is confirmed, the same model or a repaired product with the same performance as the product will be replaced. The replaced defective product belongs to manufacturer; The normal product will be returned as it is. Please provide product warranty card for warranty service. If you are not able to provide, the free warranty period of the product will be calculated from its production date. If the product is charge for repair, the same problem will have a free warranty period of three months from the date of repair.
- Please request and keep your repair receipt. The shipping cost of the repaired product is request to charge to the sender.

4. Within the scope of national laws and regulations, the right of interpretation and maintenance of this commitment belongs to product manufacturer.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This product uses an INTEL module, the FCC ID is: PD9AX210D2

FCC WARNING

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum distance between 20cm the radiator your body: Use only the supplied antenna.