





HP 15

Front view



- | | |
|--|--------------------------------------|
| 1. [Power] Power Button | 11. [OK] Enter Button |
| 2. Screen | 12. [Mute] Mute Button |
| 3. Handset | 13. [Redial] Redial Button |
| 4. Alphanumeric Keypad | 14. [Left Arrow] Left Arrow Button |
| 5. [*] Asterisk Button | 15. [Right Arrow] Right Arrow Button |
| 6. [#] Pound Button | 16. [Handfree] Handfree Button |
| 7. [M1-M4] Quick Dial Buttons | 17. [Home] Home |
| 8. [Call] Call Button | 18. [Menu] Setting |
| 9. [End Call/Sleep] End Call Button/
Sleep Button | 19. [SMS] SMS |
| 10. [Volume Up/Down] Volume Buttons | 20. [Back] Back Button |
| | 21. Charging Indicator |
| | 22. Handfree Indicator |


Rear view



23. Microphone
24. 3.5MM JACK
25. Type C USB
26. DC 5V Power Connector
27. Battery compartment
28. Wall Mount Holes
29. Rj9 Handdset Jack

SIM Card Installation

1. Disconnect the power adapter and remove the battery compartment cover at the bottom of the device.
2. To install the SIM card, slide the metal tab to the left to unlock it. Flip it up, and place the card in the direction shown in the illustration.
3. Lower the metal tab and slide it to the right to lock it, as shown in the illustration.




Warnings

- Always ensure your device is turned off before removing or inserting your SIM card to prevent data loss and damage to the SIM card.
- Handle the SIM card with care to avoid damaging the phone's electrical contacts.
- Do not place the SIM card near electromagnetic surfaces or environments.
- Avoid touching the phone's metal connectors with your hands or metal objects.

Battery Installation

1. Disconnect the power adapter and remove the battery compartment cover.
2. Insert the battery into the battery compartment, ensuring the electrodes of the connector on the terminal match the slots on the top of the battery, as shown in the image.
3. Replace the battery compartment cover, ensuring it is securely in place.




Precautions


- Under no circumstances should you use the charger or battery if they are damaged. Use the battery correctly.
- Do not short-circuit the battery, as this may damage the battery or cause a fire.
- Do not expose the battery to high temperatures or fire, as it may explode.
- Return the spent battery to the dealer or place it in designated recycling locations; do not dispose of the battery in household trash.
- The battery charging time depends on the remaining charge, the type of battery, and the charger used.
- When the operation time is noticeably shorter than normal, replace the battery with a new one.
- Use only original chargers and manufacturer-approved batteries and accessories.
- Disconnect the charger from the electrical outlet and from the device when the phone is not in use.
- Do not expose the battery to extremely hot or cold temperatures, as this will reduce the battery's capacity.

Handset Installation

1. Plug the curly handset cord into the telephone base. The longer end of the uncurled cable should be connected under the base, while the shorter end is connected to the handset.




2. Plug the other end of the curly cable into the handset jack as shown in the illustration.



Battery Charging

1. Connect the power supply cable to the connector on the back of the phone, and then plug the power supply into a household AC outlet. The battery level will be indicated on the screen while the battery charging process is completed.
2. When the battery level is low, there will be a warning tone, a low battery message, and the battery icon will be displayed in red. Plug the power adapter into the device to start charging. The battery level will be indicated on the screen during charging mode and once fully charged, the battery icon will appear full.
3. Charging a completely discharged battery can take 2 to 3 hours.



Warnings

- Fully charge the battery before starting to use the device.
- Do not use damaged cables or connectors.
- Do not pull on the cables to disconnect the connector.
- Charge the battery only with the supplied adapter; do not use third-party accessories.
- Never use the device underwater or in high humidity environments.
- Never use the device in areas of extreme heat or cold.
- Avoid using the device during electrical storms.
- If you experience overheating, turn off the device immediately and discontinue use for some time.
- Follow safety regulations when using the device in restricted areas.

FCC Warning

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interferenceto radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Specific Absorption Rate (SAR) information:

This Mulberry tech group LLC meets the government's requirements for exposure to radio waves. The and thorough evaluation of scientific studies.The standards include a substantial safety margin designed to assure the safety of all persons regardless of age or health. FCC RF Exposure Information and Statement the SAR limit of USA (FCC) is 1.6 W/kg averaged over one gram of tissue. Device types: Fixed wireless phone has also been tested against this SAR limit. This device was tested for typical body-worn operations with the back of the Fixed wireless phone kept 0mm from the body. To maintain compliance with FCC RF exposure requirements, use accessories that maintain an 0mm separation distance between the user's body and the back of the Fixed wireless phone. The use of belt clips, holsters and similar accessories should not contain metallic components in its assembly. The use of accessories that do not satisfy these requirements may not comply with FCC RF exposure requirements, and should be avoided.