


## Vlog Selfie Stick with Remote Control

### Remote Control Functions



① Photo/Video

② Indicator Light

③ On/Off Button: Long press 3 seconds to switch on/off

④ 1.Smartphone / GoPro Mode Switch

Long press 3 seconds to switch (Bluetooth pairing with smartphone when red light; Bluetooth pairing with GoPro when green light)

2.Shooting Mode Switch

(1) GoPro Camera Mode (Green light flash) GoPro camera shooting mode can be switched  
(2) Smartphone Mode (Red light flash) This button has no function

### Parameter/Display Description

Charging Voltage: 5V / Over 100mA

Charging Time: About 2 Hours

Use time: Continuously used for about 12 hours when power on

Stand by for about one year without power on

Bluetooth: Bluetooth is not connected within 3 minutes will enter the shutdown state

Charging Status: Red light is on

Fully Charged: Green light is on

Phone Pairing Mode:

Red Light Fast Flash: Looking for pairing  
Red Light Slow Flash: Pairing successfully

GoPro Camera Mode:

Green Light Fast Flash: Looking for pairing  
Green Light Slow Flash: Pairing successful

**TELESIN**

CE FCC RoHS    

## FCC Statement

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.