

# Warranty card



# YOGEE Pad

## Instruction Manual

10W Wireless Charger



Name: \_\_\_\_\_  
Address: \_\_\_\_\_  
Tel: \_\_\_\_\_ Email: \_\_\_\_\_  
Purchase date: \_\_\_\_\_  
Dealer name: \_\_\_\_\_  
Product problems: \_\_\_\_\_


### YOGEE Pad Parts



a. Wireless charger surface  
b. Wireless charger plug-in

### YOGEE Pad User Guide

1. Plug in USB to power with certified adapter (QC 2.0 adapter is required).
2. Place mobile device (with wireless receiver built-in or attached) onto YOGEE Pad's surface evenly and properly.



3. Remove mobile device from YOGEE Pad's surface when it is fully charged.

# One Year Warranty

YOGEE Company Limited (hereinafter referred to "Company") warrants this product (see Exclusions below) to the original purchaser against defective material and workmanship that occurs during normal use for one year. Company will, at Company's option, either repair or replace same without charge (but no cash refunds will be made).

1. Damage resulting from accident, misuse, abuse, lack of reasonable care, subjecting the product to any but the specified electrical service, other than normal and ordinary use of the product, subjecting the product to abnormal working conditions or any other failure not resulting from defects in materials or workmanship.
2. Damage resulting from modification, tampering with or attempted repair by anyone other than the Company or designated repair representative by the Company.
3. Transfer of product to someone other than the original consumer purchaser.
4. The warranty is not valid for components subject to wear and/or to counterfeits.

## Safety Instructions

Read and follow all safety instructions.

1. YOGEE Pad's applicable operation temperature range is from 0°C to 30°C (or 32F to 86F) and can be stored at ambient temperature between -20°C to 50°C (or -4F to 122F) with ambient humidity less than or equal to 90%. YOGEE Pad or battery of the charging mobile device may be damaged if YOGEE is not being used properly.
2. Avoid YOGEE Pad receiving violent impact or intentional pressing, exposing to the sun and rain, or getting contact with corrosive substances. Keep away from fire.
3. Use EnergyPad with certified adapter ONLY or those applied to international standard rules (5V/2A, 9V/1.67A).

4. Do not disassemble, modify or repair YOGEE Pad yourself. Contact your distributor for after sale service if there's any questions.
5. Avoid children and pets chewing or swallowing YOGEE Pad.
6. Recycle YOGEE Pad properly for environmental protection.

## Hazardous substance test result:

Lead	Mercury	Cadmium	Chromium 6	PB	PBDEs
X	O	O	O	O	O

O: Content of the hazardous substances in all homogenous materials of the part is below the prescribed limits in accordance with GB/T26572 standard.

X: Content of the hazardous substances in a homogeneous material of the part is exceeding the prescribed limits in accordance with GB/T26572 standard.

## Troubleshooting

### 1. YOGEE Pad is not working.

Check and make sure YOGEE Pad's USB plug-in is well connected to proper power and/or adapter.

### 2. Mobile device is power off during charging or not being fully charged.

Check and make sure the adapter is a certified product or those applied only to international standard rules.

## PART 15 FCC Statement

This device complies with part 15 of the FCC Rules. Operation is Subject To the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not explicitly approved by the party responsible for compliance could void the user's authority to operate this equipment.

Note: this equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

## Radiation Exposure Statement

This device complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter. During the operation of device a distance of 15 cm surrounding the device and 20 cm above the top surface of the device must be respected.