Bluetooth Switch/pc/steam gamepad



备注:

1. 背部按键: 匹对按键;

2.+和-号按键同时按压为截屏按键

—. Function:

- A. Switch pro mode gamepad with waking-up function, without NFC
 - B. wired PC: Defaults Xinput; (Press Home 5 seconds to swap dinput); Steam compatible
 - C. Bluetooth PC compatible, steam compatible

二. connection:

1. Bluetootn pairing

- 1.1 Pressing "back" button lasting 3 seconds, LED1-LED4 flash quiclky, gamepad enters bluetooth pairing status;
- 1.3 Reconnection: when Switch system in off-screen status, press Home button to awake system, and system will connect gamepad automatically.
- 1.4 Bluetooth mode can connect PC, the same operation like connecting with Switch System
- 1.5 Gamepad connects Android and los
- 1.5.1 Connecting andorid device by bluetooth: Open Bluetooth setting in Phone, press X+ pair button at the same time when gamepad in turn-off status. gamepad LED2 and LED3 flash quickly meaning the gamepad in pairing model, to find "RF gameapd" name in Phone and connect.
- 1.5.2 IOS system bluetooth connection: Open Bluetooth setting in device, press Y + pair button at the same time when gamepad in turn-off status. gamepad LED1 and LED4 flash quickly meaning the gamepad in pairing model, to find "XBOX WIRELESS CONTROLLER" name in device and connect.

When gamepad enter sleeping mode, you can press any buttons to awake gameapd, and the gamepad will connect device automatically again.

1.6 Turn off gamepad: press the back pair button one time quickly to turn off gamepad

≡ Reconnection:

- 2.1 Gamepad in sleeping mode (not flighting mode), press Home button to awake system
- 2.2 Press Home button to awake gamepad, LED1-LED4 starts flashing slowly, gamepad will reconnect system automatically. if failed, gamepad will enter sleeping mode; other buttons can not awake system.
- 2.3 Reconnection all systems, gamepad will rumble one time to remind.

四 charging:

1. Charging

- 3.1 Gamepad in turn-off mode, when charging LED1-LED4 flash slowly. and turn off when charge fully.
- 3.2 When Battery in low power, the current LED flash quickly

2. sleeping automatically

- 4.1 Switch system screen-off, gamepad will enter sleeping mode
- 4.2 No any operation on gamepad, it will enter sleeping mode
- 4.3 Bluetooth mode, press Home button lasting 5 second to disconnect system connection, then gamepad enter sleeping mode

3. USB wired mode

- 6.1 Recognize PC/SWITCH/ANDROID/STEAM platform;
- $6.2\ Defaults\ Xinput\ on\ PC,$ and press Home button lasting 5 second to swap Dinput
- 6.3 Recognize android automatically(android with Xinpt and Dinput), if Xinput LED1 and LED4 lights up, if Dinput, LED2 and LED3 lights up.
- 6.5 Dinput mode on PC device name is: RETROFIGHTERS GAMEPAD

7. motor adjustment

- [+] +left joystick UP to increase
 - [-] + left joystick DOWN to decrease
- 4 ranges; 0-30%-70%-100%
- 8. Pressing home button lasting 10 seconds, gamepad hardware reset.
- 9. with Motion sensor

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -- Reorient or relocate the receiving antenna.
- -- Increase the separation between the equipment and receiver.
- -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -- Consult the dealer or an experienced radio/TV technician for help.

Warning: changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment

The devices has been evaluated to meet general RF exposure requirement, the device can be used in portable exposure condition without restriction