








- The monitor is paired with one camera by default, you should keep at least one camera connected.

## 9. Speaker Volume

### Explanation:

This function is used to adjust the speaker volume of the monitor.

Step 1:

1. Press  to enter menu page.
2. Choose  ->  button  
-> **Speaker Volume** ->  &   
button to decrease/increase the volume.







## 10. Alarm Volume

### Explanation:

This function adjusts monitor system sound.

Step 1:

1. Press  to enter menu page.
2. Select  -> **Alarm Volume**  
->  button.



Step 2:

1. Select the preferred alarm sound level. Press the  button.


## 11. VOX

### Explanation:


1. This function is used to wake up and light up the monitor screen. There are three wake-up levels (low/medium/high). When the sound detected by the camera reaches 75dB/65dB/60dB or more, the monitor will wake up and the LED indicator will flash.
2. Caution: The screen will not wake up automatically if VOX is turned off.

### Step 1:

1. Press  to enter menu page.
2. Choose  -> **Status** to turn on the VOX function.



### Step 2:

1. Select the option you want in **Sensitivity**. Then press the  button.






## 12. Alarm Clock

### Explanation:

This function is used to remind you to feed your baby. OFF means you turn off the function; 2 hours mean it will remind you every 2 hours, and the other options follow the same pattern.

### Step 1:


1. Press  to enter menu page.
2. Choose  ->  button.



Step 2:

1. Select **Remind**

and set the time you want. The and buttons can be used to adjust the value.



Step 3:

1. Select **Repeat** to create a recurring alarm and choose the scheduled time you want your alarm to repeat.


### 13. Time

Step 1:

1. Press to enter menu page.

2. Choose -> **Time**

-> button.



Step 2:

1. Press and to adjust the value, and press to save the settings.


### 14. Date

Step 1:

1. Press to enter menu page.

2. Choose -> **Date**

-> button.



Step 2:




1. Press and to adjust the value, and press to save the Settings.


## 15. Temperature

### Explanation:




You can set the maximum/minimum temperature and turn on the temperature alert, so that the baby monitor beeps whenever the room temperature falls outside the desired temperature range. You can also choose to display the temperature in Fahrenheit (°F) or Celsius (°C) on your monitor.

#### Step 1:

1. Press  to enter menu page.
2. Choose  -> Temperature  
->  button.



#### Step 2:

1. Press  and  to adjust the value, and press  to save the settings.



A temperature alarm can be temporarily turned off by pressing any button on the monitor.

## 16. Language

### Explanation:


There are four languages available on your device, you can choose your language here.

#### Step 1:

1. Press  to enter menu page.
2. Choose  -> Language  
->  button.



#### Step 2:

1. Select the desired language and press the  button.

## 17. Lullabies

### Explanation:


This function is for comforting your baby with soothing lullabies.

Step 1:

1. Press to enter menu page.
2. Choose -> **Lullabies**  
-> button.

Step 2:

1. Select your desired lullaby and press to turn it on / off. Press the up / down button to increase or decrease the lullaby volume. Select to play the lullaby on a loop.



## 18. Refresh Rate

### Explanation:

You can change the image refresh frequency of the camera to ensure that the camera works normally.

Step 1:

1. Press to enter menu page.
2. Choose -> **Refresh Rate**  
-> button.

Step 2:

1. Set the refresh frequency based on the usage in your region.






## 19. Factory Settings


### Explanation:


System will be restored to default settings.

#### Step 1:

1. Press  to enter menu page.
2. Choose  -> **Factory Setting**  
->  button.




#### Step 2:

1. Choose **YES** ->  button  
to start restoring factory settings.



## 20. Contact Us

#### Step 1:

1. Press  to enter menu page.
2. Choose  -> **Contact Us**  
->  button.

#### Step 2:

1. Press  to return to menu page.



# SPECIFICATIONS

## Monitor

Connectivity	2.4GHz FHSS
Image Aspect	16:9
Image Compression	MJPEG
Operating Range	960ft (line of sight, no obstructions)
Temperature Alert	Yes
Volume Control	9 levels
Brightness	8 levels
Operating Voltage	5V = 2A
Zoom	Zoom In (2X) Zoom In (4X)
Two-Way Talk	Yes
Multi-Camera	Max. 4 cameras
Storage Temperature	-20 °C to 70 °C / -4 °F to 158 °F
Operation Temperature	0 °C to 40 °C / 32 °F to 104 °F

## Camera

Connectivity	2.4GHz FHSS
Image Compression	MJPEG
Operating Voltage	5V --- 2A
Pan-n-Tilt	90 degrees vertical (Up=50°, Down=40°) 350 degrees horizontal (Left=175°, Right=175°)
Zoom	Zoom In (2X) Zoom In (4X)
Night Vision	Black & white image
IR LED	Non-visible IR LED with wavelength of 940nm
Light Sensor	Yes
Two-Way Talk	Yes
Storage Temperature	-20 °C to 70 °C / -4 °F to 158 °F
Operation Temperature	0 °C to 40 °C / 32 °F to 104 °F



# TROUBLESHOOTING

<p>Product not powering on?</p>	<ul style="list-style-type: none"> <li>· Check that the camera and monitor are turned on.</li> <li>· Check the camera and make sure it is properly plugged into the outlet.</li> <li>· Check that the monitor has sufficient battery power (When the battery icon flashes red, the monitor will automatically shut off after 5 minutes).</li> </ul>
<p>Baby monitor can't connect with the camera?</p>	<ul style="list-style-type: none"> <li>· Check whether the camera is near the monitor (recommended distance is 1.5-2 m / 4.9-6.6 ft)</li> <li>· Check whether the monitor has low battery. Charge it promptly to maintain a good connection.</li> <li>· Check whether the camera is securely connected to the power source.</li> <li>· Check whether there are any large metallic objects including doors, refrigerators, etc. placed between the camera and monitor, thus blocking the radio signals.</li> <li>· Check whether there's any other other 2.4GHz product nearby such as Wi-Fi routers and microwave ovens, which may interfere with the connection.</li> <li>· If none of the above applies, please try pairing again.</li> </ul>
<p>Nothing shown when I view a camera?</p>	<ul style="list-style-type: none"> <li>· Check all connections of the camera (the power cable plug and pairing)</li> <li>· Check whether the screen is in sleep mode. Press any button to wake it.</li> <li>· Check whether the camera is within the monitor's connection range.</li> </ul>

No sound from the monitor?	<ul style="list-style-type: none"> <li>· Check whether the speaker volume or alarm volume is set to mute.</li> </ul>
Black and white pictures?	<ul style="list-style-type: none"> <li>· Night vision LED may be ON. Please turn on the room lights to force it out of the night vision mode.</li> </ul>
Choppy video?	<ul style="list-style-type: none"> <li>· Check whether the camera is near the monitor and that there're no obstacles between them.</li> </ul>
Too much noise?	<ul style="list-style-type: none"> <li>· Volume may set too high. Press the volume shortcut button to lower the volume.</li> <li>· The camera and monitor may be too close; keep them at least 1.5 m / 4.9 ft apart.</li> </ul>

## WARRANTY & CUSTOMER SERVICE

12 months warranty (contact information can be found on the monitor or on the cover of this user manual)

## FCC COMPLIANCE (Camera)

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

### **Note:**

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

### **FCC 20cm Statement:**

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20cm between the radiator & your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

### **IC statement:**

This device complies with Industry Canada's licence-exempt RSSs. Operation is

subject to the following two conditions:

- (1) This device may not cause interference; and
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.

To maintain compliance with RF exposure guidelines, this equipment should be installed and operated with a minimum distance of 20cm between the radiator and your body.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:

- (1) l'appareil ne doit pas produire de brouillage, et
- (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Pour maintenir la conformité aux directives d'exposition aux radiofréquences, cet équipement doit être installé et utilisé avec une distance minimale de 20 cm entre le radiateur et votre corps.

## FCC COMPLIANCE (Monitor)

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

### **Note:**

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that

interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement.

The device can be used in portable exposure condition without restriction.

**IC statement:**

This device complies with Industry Canada's licence-exempt RSSs. Operation is subject to the following two conditions:

- (1) This device may not cause interference; and
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:

- (1) l'appareil ne doit pas produire de brouillage, et
- (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

L'appareil a été évalué pour répondre aux exigences générales d'exposition RF. L'appareil peut être utilisé dans des conditions d'exposition portables sans restriction.



## WEEE COMPLIANCE

DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS

“ --- ” This symbol indicates DC voltage

This product bears the selective sorting symbol for Waste electrical and electronic equipment (WEEE). This means that this product must be handled pursuant to European directive 2012/19/EU in order to be recycled or dismantled to minimize its impact on the environment. The user has the choice to give their product to a competent recycling organization or to the retailer when they buy a new electrical or electronic equipment.

EU Compliance Statement: Hong Kong Lute Technology Co., Limited hereby declares that this device is in compliance with the essential requirements and other relevant provisions of the Directive 2014/53/EU.







<b>图档名称</b>	momcozy BM02英文说明书			<b>版本号</b>	A2	<b>日期</b>	2023-08-11
<b>规格尺寸</b>	105*140 (h) mm	<b>印刷颜色</b>	CMYK	<b>设计师</b>	黄慧琴	13409964263	
<b>材质工艺</b>	封面200克铜板纸，内页105克哑粉纸，压边8mm/胶装						
<b>项目负责人</b>	薛冰雨	<b>文案编写/审核人</b>	薛冰雨		<b>设计审核人</b>	/	
<b>备注</b>	出血线为2mm；黑色线为刀模，请勿印刷；图档版权归深圳市路特佳成网络科技有限公司所有，私自泄露、修改、使用文档所产生的一切责任后果我司将追究到底。					<b>ROOT 路特</b>	