




powerbass:::


BT-200 SPLIT
User's Manual

Step 1 - Power On
Bluetooth Connection



Long-press 'MASTER' and 'SUB-MASTER'  simultaneously for 2 seconds, you will hear prompt tone of power on, and they will begin to connect automatically. An audible beep will sound when connected successfully. The indicator light of SUB-MASTER will remain blue, and master indicator light flashes quickly.

1

Step 2 - Phone
Bluetooth Choose Device



Find "BT-200" in your bluetooth list and select it.

2

Step 3 - Pairing Success
Bluetooth Indicator


The LED indicator remains blue once pairing is done, music may be played afterwards.

3

TWS Function



(Master and Sub-master shown above)

Long press MASTER and SUB-MASTER  simultaneously for two seconds, you will hear a prompt tone of power on, and they will begin to connect automatically.

(Please turn on bluetooth on your device before TWS pairing)

4

powerbass:::



Basic Operation

 **POWER BUTTON/MULTI-FUNCTION BUTTON**
Power on/off: Long Press  for 2 seconds
Answer/end call: Short Press  on MASTER speaker
Reject call: Press  twice on MASTER speaker
Resume/pause music: Short Press 
Disconnect TWS and Bluetooth: Press  3x to disconnect TWS, then 2x to disconnect bluetooth device.

  **VOLUME BUTTONS**
Volume increase: Short press 
Volume decrease: Short press 
Next track: Long press 
Previous track: Long press 

NOTE: Both speakers are mutually controlled after pairing.

5

Interface Instructions

SWITCH INDICATOR

- Blue LED flashes quickly when turning on speaker
- Blue LED flashes quickly when the speakers are pairing

BLUETOOTH INDICATOR

- Blue LED will remain on after successful connection.
- The LED light of the SUB-MASTER will remain on, while the MASTER will flash quickly after successful pairing.
- The Blue LED flashes quickly if the speakers are beyond range of the Bluetooth source (Unit will power off automatically if no connection is made after 10 minutes)

CHARGING INDICATOR

- Red LED indicator will remain illuminated while charging.
- Red LED indicator will turn off after a full charge.
- Red LED indicator will flash when the battery is low.
- The LED indicator will turn off when powered off.

6

BT-200 Specifications

Product Name: **BT-200 SPLIT**
Bluetooth Version: **5.0**
Battery Capacity: **1500mAh x 2**
Play Time: **10-12 hours**
Charging Time: **3-4 hours**
Driver Units: **10W x 2**
Charging Current: **5V / 0.8A**
Product Dimensions: **84 x 84 x 210mm**
Product Weight: **750g**

NOTES:

1. Please read this manual carefully before use.
2. Upon using the speaker for the first time, please fully charge the unit.
3. Please use the included certified adapter which has passed national safety certifications.
4. Please charge the speaker at least once a month to maintain battery performance.
5. Using this speaker in extremely cold or hot environment (beyond the range of 104°F to -20°F) may trigger the auto turn off to protect the internal circuit.
6. Charging this speaker in a high temperature environment may trigger the auto turn off for charging to protect the battery. The Power Indicator will flash quickly to indicate that the charging environmental temperature or the product internal temperature is too high.
7. Recommended ambient storage temperature: -20°F-95°F RH <70% (recommended 77°F ±5°).

7

FAQ
Q: What kind of charger should we use for the speaker?

A: While all common USB-C chargers can be used, we suggest 5V/2A or above 2A.

Q: What if there is noise or discontinuous sound during playback?

A: Normal range of the bluetooth speaker is 30ft with a clear unobstructed path. Please check if the speaker is within range with a clear path.

Q: Why did the speaker power off automatically without the Bluetooth disconnecting?

A: If the speaker is not paired for longer than 10min, it will automatically turn off.

Q: Why does the speaker not connect to the once-paired phone or device?

A: Remove BT-200 from your Bluetooth Device List then restart pairing (pg 1-3).

Q: What is the start up mode of the speaker?

A: Default mode is Bluetooth

Q: Why will the speaker not power up?

A: Plug in the charger and retry in a few minutes or try to long press the power button for 10-30 seconds to force reset.

IMPORTANT SAFETY INSTRUCTIONS:

1. Do not personally disassemble or repair this speaker, otherwise it may cause product damage or personal injury.

2. Do not use the speaker in dusty, humid, dry, or high-temperature environment.

3. Do not place this speaker near a heat source, in direct sunlight, in a dusty area or on a vibrating surface.

4. In order to reduce the risk of fire, please do not cover this speaker while in use (newspapers, tablecloths, curtains etc.).

5. This speaker is rated IPX7, please do not exceed the nominal parameters (submerged up to 1 meter of water for 30 minutes).

6. When any part of the product is damaged, such as the power cord, plug, liquid entering into or an object falling onto the device, and is unable to operate normally or fails, it must be repaired.

7. When the product is fully charged, do not keep the charger connected for a long period of time.

8. The maximum ambient temperature should not exceed 140°F.

*This speaker supports mobile phones and tablet PCs etc.

8

RoHS CE FC



Made in China

Federal Communications Commission (FCC) Statement. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received,

including interference that may cause undesired operation. Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide Reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Warning: Changes or modifications made to this device not expressly approved by **PowerBass USA, Inc.** may void the FCC authorization to operate this device. Note: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

RF exposure statement:

The device compliance RF exposure requirement and can be installed and used without restriction