


**User Manual** 




### Introduction


Thanks for choosing our product.

This product is a smart wireless microphone that provides professional-grade recording output. Plug and play, no app required. Multiple uses: It can be used in online live broadcast, video Vlog shooting, program interview, recording, video teaching and other occasions.


This product consists of three parts: charging box, microphone transmitting end and receiving end. (as shown in the figure below, some models have no charging box, subject to the real object)



# ID Diagram




Note: oppo / vivo / iqoo / realm brand mobile phones can be used normally only when they go to the settings (search "OTG" - turn on OTG power supply) Step 2: Press switch key of microphone, the indicator light turns green, and then power is turned on.




Step 3: The indicator light of receiver keeps always on,

then open the phone camera, live App or other Apps, and then to use the microphone to receive sound.



Special Note:

For the use of port: there is no battery in receiver, and no need to recharge during live. If the phone is low power during Live, it can be recharged directly through port.



### About UI

Microphone clip
 Function keys

7 Receiver indicator

100 LED Display

6 Type-C or Lightning port to connect phone

Receiver charging port
 Charging box Type-C charging port

#### Microphone Transmitter

Function	Button	LED	
Power on	Button 3S startup	Green light blinking	
Power off	Press 3S shutdown	All the lights went out	
Unconnected		Green light blinking	
Connected		Green light always on	
noise reduction	Al noise reduction		
Reverberation	Three-click button to switch reverberation, default is not on, need to turn on manually, three clicks again to exit reverberation	Turn on reverberation light turn off reverberation light off	
Silent mode	Mute Double click to mute the MIC and then double click again to restore the radio status.	Turn on mute indicator Turn off Mute indicator Off	
Charging		Battery RGY tricolor light power: 40-100% green light, Power: 20-40% yellow light, 10-20% red light, Power: below 10%, the red light flashes	
Fully charged		Fully charged all lights off	
Low battery		Low power indicator Blinks every 10 seconds. The green is off.	

Pa	ceiver	
110	SCIACI	

Function		LED
Power on	Automatically power on after plugging in the mobile phone port	The light blinks
Power off	Automatic shutdown after unplugging	
Unconnected		The light blinks
Connected		light is always on

## **Packing List**

How to use

Step 1: Connect the receiver to phone with port.

Content of packing

- (1) Microphone transmitter
- (2) Lightning receiver (3) Charging box
- (4) Charging box
- (5) User manual

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the

- interference by one or more of the following measures.

   Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
  -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -Consult the dealer or an experienced radio/TV technician for help. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.