BT02 Bluetooth Remote Control Manual

1. Product Introduction

The Bluetooth remote control is designed specifically for Vantrue dash cams and supports wireless control of the dash cam's core functions. Through a Bluetooth connection, users can easily capture photos, lock recordings, and toggle the microphone on and off, enhancing both safety and convenience while driving.

2. Product Accessories

- . Bluetooth Remote Control ×1
- . Battery (pre-installed) ×1
- . User Manual ×1
- . Spare Adhesive Pad ×1

3. Function Description

- . **Capture Photos**: Press the photo button on the remote control to immediately capture key moments during your drive.
- . **Lock Recording**: Press the lock button to quickly lock the current video segment to prevent it from being overwritten.
- . **Microphone On/Off**: Press the microphone button to turn the recording on or off at any time.
- . **Display Switch**: For certain models, long-press a specified button to switch between different camera views.

4. Connection Instructions

- 1. Turn on Bluetooth: Ensure the Bluetooth function on the dash cam is enabled.
- 2. Pair the Remote Control:
 - Enter the dash cam's Bluetooth settings menu and select "Bluetooth Remote Control."
 - Press any button on the remote control, and the dash cam will automatically search for and pair with the device.
 - Once paired, the dash cam will display "Bluetooth connection successful" on the screen.

5. Installation Steps

1. Select a suitable position to install the remote control, such as next to the steering wheel or on the inside of the car door, ensuring it is easy to operate.

2. Use the included adhesive pad to firmly attach the remote control to the desired location.

6. Battery Replacement

- 1. If the remote control stops responding, it may be time to replace the battery.
- 2. Open the battery cover on the back of the remote control, remove the old battery, and install a new one.
- 3. Ensure the correct polarity of the battery and close the battery cover.

7. Common Issues

. Unable to connect Bluetooth:

- o Check if the Bluetooth on the dash cam is turned on.
- o Ensure the remote control is functioning with sufficient battery power.
- o If the issue persists, restart the dash cam and re-pair the device.

Buttons are not responding:

- o Check if the remote control is successfully paired with the dash cam.
- o Replace the battery in the remote control.

8. Precautions

- . Do not place the remote control in high-temperature or humid environments.
- . The remote control is waterproof, but avoid prolonged exposure to water.
- . To ensure safe driving, it is recommended to operate advanced features of the remote control only when the vehicle is parked.

9. Technical Specifications

. Operating Frequency: 2.4GHz (Bluetooth)

. Effective Range: 10 meters

Battery Type: CR2032 Button Battery
Operating Temperature: -20°C ~ 60°C

10. Warranty Information

This Bluetooth remote control comes with a one-year warranty. For any quality issues, please contact Vantrue official customer service or an authorized dealer for after-sales service.

FCC Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1)This device may not cause harmful interference.
- (2)This device must accept any interference received,including nterference that may cause undesired operation.

Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device under Part 15 of the FCC Rules. These limits are designed to protect reasonably against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used by the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. Suppose this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on. In that case, the user is encouraged to try to correct the interference by one or more of the following measures:

- (1) Reorient or relocate the receiving antenna.
- (2)Increase the separation between the equipment and receiver.
- (3)Connect the equipment to an outlet on a circuit different from the receivers.
- (4)Consult the dealer or an experienced radio/TV technician for help.

ISED Statement

- English: This device complies with Industry Canada license -

exempt RSS standard(s). Operation is subject to the following

two conditions: (1) This device may not cause

interference, and (2) This device must accept any interference, including interference that may cause undesired operation of the device.

The digital apparatus complies with Canadian CAN ICES -3 (B)/NMB -3(B).

- French: Le présentappareilestconforme aux CNR d'Industrie

Canada applicables aux appareils radio exempts de licence. L'

exploitationestautorisée aux deux conditions suivantes: (1) l'

appareilne doit pas produire de brouillage, et (2) l'utilisateur de l'appareildoit accepter tout brouillageradi oélectriquesubi, mêmesi le brouillageest susceptible d'encompromettre le

fonctionnement. l'appareil numérique du ciem conforme canadien

This device meets the exemption from the routine evaluation

limits in section 2.5 of RSS 102 and compliance with RSS 102 RF exposure, users can obtain Canadian

information on RF exposure and compliance.

cet appareil est conforme à l'exemption des limites d'évaluation courante dans la section 2.5 du cnr - 102 et conformité avec

rss 102 de l'exposition aux rf, lesutilisateurs peuvent obtenir des données canadiennes sur l'exposition aux champs rf et la

conformité.

This equipment complies with Canada radiation exposure limits

set forth for an uncontrolled environment.

Cet équipement est conforme aux limites d'exposition aux

rayonnements du Canada établies pour un environnement non contrôlé.

This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

Cet équipement doit être installé et utilisé à une distance minimale de 20 cm entre le radiateur et votre corps.