


English Version



L80 SERIES

MECHANICAL KEYBOARDS

User Guide
使用说明书



New Design
New Series

Designed by IQUNIX


Start Reading →



Please read this manual guide and cautions to ensure that using this product correctly.


Three Ways of Connecting Devices

Details

Bluetooth Connection Mode



- 1 Toggle the keyboard Mode Switch to wireless side 
 - 2 Press FN+1, then hold FN+1 for 5 seconds if the indicator blinks in blue light.
(Bluetooth matching mode on when blue light blinks.) 
 - 3 Enable Bluetooth matching (Computer / Phone / Tablet)
 - 4 Select the matching device **【IQUNIX LIME80 BT 1】**
 - 5 Indicator light turning off when matching successfully.
- ❗ If you need to connect a new device, please hold FN+1 for 5 seconds to remove the previous device. When the LED indicator blinks blue light, you can connect your device following the Step 3.




Product Specification

Product: L80 Mechanical Keyboard	Connect Interface: USB Type-C
Model: L80 Formula Typing	Cable Length: 150cm
Key Count: 83	Dimensions: 325*162*45mm
Keyboard Material: ABS Case + PBT Keycaps	Origin: Shenzhen, China
Legends Printing: Dye Sublimation	Web: www.IQUNIX.store
Large Key Structure: Costar Stabilizers	Support E-mail: support@iqunix.store
Rating: 5V _{max} 1A	


FN

Function Keys Combinations




FN

LED Indicator Keys Combinations (RGB Version)




2.4GHz Connection Mode



- 1 Toggle the keyboard Mode Switch to wireless side.
- 2 Plug the 2.4GHz receiver into your computer.
- 3 Press FN+4 to enter 2.4GHz matching mode (2.4GHz matching mode on when pink light blinks.)
- 4 Indicator light turning off means successful matching.

Wired Connection Mode



- 1 For Wireless Version, toggle the keyboard Mode Switch to wired side.
- 2 Plug the USB cable into your device.

LED Indicator Status Description

Device Charging and Battery Status

 Yellow Light Blinking	 Green Light Blinking 3 Times	 Red Light Blinking
Charging	Charging Completed (Wired Mode)	Less than 10% (Wireless Mode)
	Charging Completed (Wireless Mode)	


Bluetooth Device Matching


 Blue Light Blinking	 Turquoise Light Blinking
Bluetooth Matching on	Bluetooth Device Re-Connection

Special Status

 White Light Blinking 5 Times	White Light On
Reset to Default	CapsLock On

2.4GHz Mode


 Pink Light Blinking
Enter 2.4GHz Mode



Special Keys Combinations (Hold for 5 Seconds)



Mac / Windows Layout Switching




Swap CapsLock and Left Ctrl

Reset to Default

Special Keys Combinations (Wireless Mode)



Switch to Bluetooth Mode



Switch to 2.4GHz Mode

Battery Level Check

The LED indicator blinks 1, 2, 3,...10 times, which stands for 10%, 20%, 30%,...100% battery level.

FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirements. The device can be used in portable exposure conditions without restriction.




Waste Electrical and Electronic Equipment Information

Correct Disposal of This Product (Waste Electrical & Electronic Equipment) (Applicable in countries with separate collection systems) This marking on the product, accessories or literature indicates that the product and its electronic accessories should not be disposed of with other household waste at the end of their working life. To prevent possible harm to the environment or human health from uncontrolled waste disposal, please separate these items from other types of waste and recycle them responsibly to promote the sustainable reuse of material resources. Household users should contact either the retailer where they purchased this product, or their local government office, for details of where and how they can take these items for environmentally safe recycling. Business users should contact their supplier and check the terms and conditions of the purchase contract. This product and its electronic accessories should not be mixed with other commercial wastes for disposal.

Mac / Windows Layout Switch



Hold for 5 seconds to switch the layout between macOS and windows systems.



To learn more details, please reach out to us on official website or social media. Official website: www.IQUNIX.store

Follow us:
@ IQUNIX




Download IQUNIX
Official App



产品细节

简体中文版




基本参数


产品名称: L80 机械键盘	接口类型: USB Type-C
键盘类型: L80动力方程式	数据线长: 150cm
按键数量: 83	产品尺寸: 325*162*45mm
键盘材质: ABS外壳+PBT键帽	产地: 中国深圳
字符工艺: 热升华	官网: www.iQunix.com
大键结构: 平衡杆	邮箱: Hello@iQunix.com
额定输入: 5V=1A	

开始阅读使用 →


使用前请仔细阅读此说明书和注意事项
以保证您能正确的使用此产品


2.4G模式



- 1 将键盘底部开关拨至“无线模式”
- 2 将2.4G接收器接入您的电脑；
- 3 短按FN+4，进入2.4G匹配模式
(指示灯开始闪烁粉色灯光时，键盘成功进入2.4G匹配模式)
- 4 灯光熄灭，匹配成功，开始使用您的键盘。

有线模式




- 1 将键盘底部开关拨至“有线模式”
- 2 将数据线USB-A端接入电脑（有线版从此步开始）；
- 3 将数据线USB-C端接入键盘；
- 4 开始使用您的键盘。

选择连接方式

蓝牙模式




- 1 将键盘底部开关拨至“无线模式”
 - 2 短按FN+1，指示灯开始闪烁青色灯光后，长按FN+1（长按5秒钟）
(指示灯开始闪烁蓝色灯光时，键盘成功进入蓝牙匹配模式。)
 - 3 打开设备（电脑、手机、平板）的蓝牙搜索界面；
 - 4 在设备的蓝牙搜索列表中选择【IQUNIX LIME80 BT 1】；
 - 5 灯光熄灭，匹配成功，开始使用您的键盘。
- ❗ 如果需要连接新设备，需要FN+1（长按5秒钟）清除已连接的上一台设备。
待指示灯开始闪烁蓝色灯光时，即可从第三步开始进行连接。

FN

特殊组合键 (长按5秒实现)

切换Mac、Windows
系统键位布局



CapsLock和
左Ctrl互换位置

恢复出厂设置

FN

多媒体功能组合键

Windows
打开网络
浏览器

Windows
Windows
下打开
我的电脑



锁定Win键
防止误触

上一首

下一首


FN

无线模式 特殊组合键

FN

切换蓝牙模式

切换2.4G模式




查看电量

指示灯闪烁1、2、3、...、10次为分别对应
电池10%、20%、30%、...、100%电量

FN


灯光组合键 (RGB版本)



切换为MAC布局对应的按键



长按5秒即可切换Mac、Windows系统键位布局



指示灯颜色和状态说明

关于设备充电

黄色灯光闪烁	绿色灯光闪烁3次	绿色灯光长亮	红色灯光闪烁
充电中	充电完成(有线模式)	充电完成(无线模式)	电量低于10%(无线模式)

关于蓝牙匹配


蓝色灯光闪烁	蓝色灯光闪烁
蓝牙匹配开启	设备1: 青色灯光闪烁
	蓝牙设备回连

关于特殊情况

白色灯光闪烁5次	白色灯光长亮
恢复出厂设置	Caps Lock开启

关于2.4G模式

粉色灯光闪烁
进入2.4G模式



了解更多详细信息请关注

官方微信公众号或下载IQUNIX APP



官方微信公众号



官方APP



品牌/Brand:
IQUNIX

产地/Origin:
中国
China

制造商/Manufacturer:
深圳市银色风暴科技有限公司
Shenzhen Silver Storm Technology Co., Ltd.

服务热线/Service Telephone:
400-1788-905