


**GUESS**  
EST.1981


**WIRELESS EARPHONES**  
STUDIO QUALITY SOUND




User Manual

\*Please read this manual carefully before use  
\* Different models, different graphics, pictures for reference only

**DESCRIPTION**



**CONTENT**



**PRODUCT SPECIFICATION**

Bluetooth: V5.3  
Frequency Range: 2402-2480 MHz  
Sensitivity: 96 ±3dB  
Impedance: 16ohm±15%  
Input: DC 5V / 500mA  
Earphones Battery Capacity: 40 mAh x 2  
Charging Pod Battery Capacity: 300 mAh  
Charge Time: 1.5 hours

**CHARGING FOR EARPHONES**

Fully charge the battery for 1-2 hours before using the earbuds for the first time, or when they have been unused for extended periods.

Put the earbuds into the charging case, and they will charge automatically. The indicators of earbuds will be lit-on orange and the indicators of charging case flashes white once time. The indicators will be off the earbuds are fully charged.


**CHARGING FOR CHARGING CASE**

When the charging case is connected with charger (or computer USB port) by charging cable, the indicators of charging case will flash in white.

When the charging case is fully charged, the indicators will be lit-on white.

**NOTE:**  
When the charging case is out of battery, the earbuds will not turn on/off automatically when removed from or placed back into the charging case. In this case, turn the earbuds on/off manually.

**FIRST USE & PAIRING**




**Auto Power-On & Pairing**  
Take the earbuds out of charging case, the earbuds will automatically power on and enter into pairing mode.



**Manual Power-On & Pairing**  
Touch the MFB for 2 secs on both earbuds to turn on the earbuds. The earbuds will automatically enter pairing mode.

**CONNECT**




Turn on the device's Bluetooth setting. Search for and choose GUESS TWS to pair, your device will show "connected". After connected, the indicator of primary earbud flashes white and orange alternatively and the indicator of secondary earbud will be off.

**POWER - OFF**



**Auto Power - Off**  
Put L&R earbuds into charging case, the earbuds will automatically power off.




**Manual Power - Off**  
1. Touch the MFB for 5 secs on both earbuds to power off the earbuds.  
2. The earbuds will automatically turn off when without pairing for 10 mins.

**WEARING**



Insert the earphones directed towards your ear canal. Twist gently until the earbuds fit comfortably and get better sound experience.

**CONTROL**



**RESET**

If you have problem to connect the earphones with your device, don't worry about it, please follow the step as below :

1. Make sure all devices have turned off bluetooth function. Clean all the pairing records from the Bluetooth list if need.
2. Take the earphones out of the case, tap the flashing earphone by 6 times quickly. The indicator will flashes white for 5 times quickly, prompt sound will be activated, then follow the pairing step as instruction.

**FCC Warning**  
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.  
Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.  
This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.  
This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.  
If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
  - Increase the separation between the equipment and receiver.
  - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
  - Consult the dealer or an experienced radio/TV technician for help.
- The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

Designed in France. Made in China.  
CE FC  
FCC ID: 2A7J2-GUTWSP4E  
MODEL : T18C