




# WIRELESS REMOTE CONTROL SOCKET



# PRODUCTS VIEW



**Wireless outlet**



**Remote control**

## FEATURES

Easily controlled by the remote control from up to 100 feet in line-of-sight.

Separate on and off buttons on the remote control.

Power output up to 1200W at 120V(60Hz).

Low power consumption, reduces energy.

# SETUP

The product consists of 2 parts, a wireless outlet, a gingerbread man remote control.

**Step 1:** Connect the wireless outlet to the power supply, then press the on/off button on the remote control to control the outlet on/off, Turn on the power, the red light is lit.

**Step 2:** The remote control is equipped with a music playback function, which can be accomplished by pressing the ON button 2 times consecutively to switch the music.

**Step 3:** The music playback on or pause function can be accomplished by long pressing the OFF button.

## NOTES

· If you find that the remote control does not control the wireless outlet, follow these simple instructions:

**Step 1:** Turn on the wireless outlet, then long press the button on the outlet until the red light on the outlet blinks.

**Step 2:** Long press the **ON** button on the Gingerbread Man remote control. If the red light on the wireless outlet stops blinking, pairing is complete, the product is ready for normal use.

Avoid exposure to high temperature sources, strong sunlight and moisture.

Do not exceed the maximum load current of 10A (Approximately 1200W)

## 1.1

- a)** The statement “Remove and immediately recycle or dispose of used batteries according to local regulations and keep away from children. Do NOT dispose of batteries in household trash or incinerate.”
- b)** The statement “Even used batteries may cause severe injury or death.”
- c)** The statement “Call a local poison control center for treatment information.”
- d)** A statement indicating the compatible battery type (e.g., LR44, CR2032).
- e)** A statement indicating the nominal battery voltage.
- f)** The statement “Non-rechargeable batteries are not to be recharged.”

**g)** The statement “Do not force discharge, recharge, disassemble, heat above (manufacturer's specified temperature rating) or incinerate. Doing so may result in injury due to venting, leakage or explosion resulting in chemical burns.”

## **1.2**

- a)** The statement “Ensure the batteries are installed correctly according to polarity (+ and -).”
- b)** The statement “Do not mix old and new batteries, different brands or types of batteries, such as alkaline, carbon-zinc, or rechargeable batteries.”

c) The statement “Remove and immediately recycle or dispose of batteries from equipment not used for an extended period of time according to local regulations.”

d) The statement “Always completely secure the battery compartment. If the battery compartment does not close securely, stop using the product, remove the batteries, and keep them away from children.”

Figure 7B.2  
Packaging Marking – Warning of ingestion Hazard





Figure 7B.1  
Packaging Marking – Warning: Contains coin battery



**This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:**

- (1)** This device may not cause harmful interference, and
- (2)** this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**NOTE:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable

protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

# **TECHNICAL DATA**

**Input Voltage** :110V-120V~50-60Hz

**Maximum power** :110V 1100W / 220V  
2200W 10A

**Remote battery** : button cell (2450) /3V

**Shenzhen Weiyou Lighting Technology  
Co.**

301, Building D, Xinwei Third Industrial Zone,  
Xinshi Community, Dalang Street, Longhua  
District, Shenzhen, China