




PSD NVNT ac80 5210MHz Ant1




PSD NVNT n20 5180MHz Ant1




PSD NVNT n20 5200MHz Ant1




PSD NVNT n20 5240MHz Ant1



PSD NVNT n40 5190MHz Ant1




PSD NVNT n40 5230MHz Ant1




**Band Edge**

Condition	Mode	Frequency (MHz)	Antenna	Max Value (dBc)	Limit (dBc)	Verdict
NVNT	a	5180	Ant1	-28.53	-27	Pass
NVNT	a	5240	Ant1	-48.48	-27	Pass
NVNT	ac20	5180	Ant1	-31.71	-27	Pass
NVNT	ac20	5240	Ant1	-48.24	-27	Pass
NVNT	ac40	5190	Ant1	-31.18	-27	Pass
NVNT	ac40	5230	Ant1	-48.34	-27	Pass
NVNT	ac80	5210	Ant1	-42.89	-27	Pass
NVNT	n20	5180	Ant1	-32.88	-27	Pass
NVNT	n20	5240	Ant1	-48.36	-27	Pass
NVNT	n40	5190	Ant1	-31.75	-27	Pass
NVNT	n40	5230	Ant1	-48.48	-27	Pass


Band Edge NVNT a 5180MHz Low Ant1




Band Edge NVNT a 5240MHz High Ant1




Band Edge NVNT ac20 5180MHz Low Ant1




Band Edge NVNT ac20 5240MHz High Ant1




Band Edge NVNT ac40 5190MHz Low Ant1




Band Edge NVNT ac40 5230MHz High Ant1




Band Edge NVNT ac80 5210MHz High Ant1









Band Edge NVNT n20 5180MHz Low Ant1




Band Edge NVNT n20 5240MHz High Ant1



Band Edge NVNT n40 5190MHz Low Ant1




Band Edge NVNT n40 5230MHz High Ant1




**Frequency Stability**

Condition	Mode	Frequency (MHz)	Antenna	Measured Frequency (MHz)	Frequency Error (Hz)	Deviation (ppm)	Limit (ppm)	Verdict
NVNT	a	5180	Ant1	5180.06	60000	11.58	25	Pass
NVNT	a	5200	Ant1	5200.08	80000	15.38	25	Pass
NVNT	a	5240	Ant1	5240.08	80000	15.27	25	Pass
NVNT	ac20	5180	Ant1	5180.08	80000	15.44	25	Pass
NVNT	ac20	5200	Ant1	5200.08	80000	15.38	25	Pass
NVNT	ac20	5240	Ant1	5240.1	100000	19.08	25	Pass
NVNT	ac40	5190	Ant1	5190.08	80000	15.41	25	Pass
NVNT	ac40	5230	Ant1	5230.08	80000	15.3	25	Pass
NVNT	ac80	5210	Ant1	5210.08	80000	15.36	25	Pass
NVNT	n20	5180	Ant1	5180.1	100000	19.31	25	Pass
NVNT	n20	5200	Ant1	5200.06	60000	11.54	25	Pass
NVNT	n20	5240	Ant1	5240.1	100000	19.08	25	Pass
NVNT	n40	5190	Ant1	5190.12	120000	23.12	25	Pass
NVNT	n40	5230	Ant1	5230.08	80000	15.3	25	Pass


Freq. Stability NVNT a 5180MHz Ant1




Freq. Stability NVNT a 5200MHz Ant1




Freq. Stability NVNT a 5240MHz Ant1




Freq. Stability NVNT ac20 5180MHz Ant1




Freq. Stability NVNT ac20 5200MHz Ant1




Freq. Stability NVNT ac20 5240MHz Ant1




Freq. Stability NVNT ac40 5190MHz Ant1



Freq. Stability NVNT ac40 5230MHz Ant1




Freq. Stability NVNT ac80 5210MHz Ant1




Freq. Stability NVNT n20 5180MHz Ant1







Freq. Stability NVNT n20 5200MHz Ant1




Freq. Stability NVNT n20 5240MHz Ant1



Freq. Stability NVNT n40 5190MHz Ant1




Freq. Stability NVNT n40 5230MHz Ant1



**Conducted RF Spurious Emission**

Condition	Mode	Frequency (MHz)	Antenna	Max Value (dBc)	Limit (dBc)	Verdict
NVNT	a	5180	Ant1	-34.27	-27	Pass
NVNT	a	5200	Ant1	-33.85	-27	Pass
NVNT	a	5240	Ant1	-34.33	-27	Pass
NVNT	ac20	5180	Ant1	-34.16	-27	Pass
NVNT	ac20	5200	Ant1	-33.67	-27	Pass
NVNT	ac20	5240	Ant1	-33.99	-27	Pass
NVNT	ac40	5190	Ant1	-33.3	-27	Pass
NVNT	ac40	5230	Ant1	-34	-27	Pass
NVNT	ac80	5210	Ant1	-34.41	-27	Pass
NVNT	n20	5180	Ant1	-33.41	-27	Pass
NVNT	n20	5200	Ant1	-34.34	-27	Pass
NVNT	n20	5240	Ant1	-34.25	-27	Pass
NVNT	n40	5190	Ant1	-34.27	-27	Pass
NVNT	n40	5230	Ant1	-34.05	-27	Pass

Tx. Spurious NVNT a 5180MHz Ant1 Emission



Tx. Spurious NVNT a 5200MHz Ant1 Emission