

---

# athom

Smart Home




## Devices User Manual

[www.athom.tech](http://www.athom.tech)

[support@athom.tech](mailto:support@athom.tech)

**Step 1:** Power on the device and use your computer or phone search the WiFi until find athom\_xxxx and click to connect, wait several seconds until configuration page pop up



**Step 2:** Input your 2.4G WiFi router SSID and password, then click save

The screenshot shows a mobile application interface. At the top, the status bar displays the time 3:17, the IP address 192.168.4.1, the device name Athen\_D9F8F2, and the signal strength indicator. Below the status bar is a navigation bar with a back arrow, a forward arrow, the text "Log In", and a "Cancel" button. The main content area is titled "WiFi Networks" and contains a "WiFi Settings" section. This section has two input fields: "SSID" and "Password". Below these fields is a blue "Save" button. A horizontal separator line is present below the "Save" button. The next section is titled "OTA Update" and contains a "Choose File" button with the text "no file selected" next to it. Below this is a blue "Update" button. At the bottom of the screen, there is a home indicator bar.

**Step 3:** then go to your Home Assistant  
It will show new devices discovered, press  
config to add it successfully














**Step 4:** After config successfully , now you can monitoring and control the device with Home Assitant

### Device info

PLATFORMID\_ESP8285  
by espressif  
Firmware: 2021.8.2 (Sep 14 2021, 07:54:18)

### Entities

	Athom Smart Plug	
	Athom Smart Plug Current	0.00 A
	Athom Smart Plug Power	0.0 W
	Athom Smart Plug Power Button	Off
	Athom Smart Plug Restart	
	Athom Smart Plug Status	Connected
	Athom Smart Plug Total ...	0.006 kWh
	Athom Smart Plug Uptim...	164,504 s
	Athom Smart Plug Voltage	236.3 V

[+1 disabled entity](#)

[ADD TO LOVELACE](#)

**Notice** : for more information

<http://www.athom.tech>

<https://github.com/athom-tech/athom-configs>

FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.