

V1络达说明书 材质: 105g双铜 尺寸: 80*75mm 印刷:正反印+单黑 折叠方式:风琴折

产品状态	提示音	灯效	
开机	"叮咚"	蓝灯闪	
关机	" 0者6 "	红灯闪一次	
连接成功	"咚"	蓝灯闪	
断开连接	"咚"	主耳红蓝交替闪,副耳灭	
低电报警	"啫""啫"	_	

■ 充	E电仓定义说 明		● 恢复出厂设置	■ 保修卡
ī	产品状态	灯效	耳机放入充电仓开盖,同时长按 左/右耳机触摸区域8秒,红灯亮	用户姓名:
	充电	充电中:红灯常亮,充满电:红灯灭	3秒,即恢复	用户电话:
	耳机放入 仓内充电	左耳充电蓝灯呼吸,充满蓝灯灭 右耳充电绿灯呼吸,充满绿灯灭	长按左/右耳机 触摸区域8秒	がった。 购机日期: 发票编号:
	耳机出入 仓检测	左耳出/入仓蓝灯呼吸一次 右耳出/入仓绿灯呼吸一次	● 安全准则	销售单位:
	开/关盖	耳机开机,充电仓显示当前电量3秒	又主/#则 1. 请遵循本说明书的使用说明,勿以任何理由拆卸或改装设备,否则可能	售后电话:
E	电量指示	20%以下红灯闪,20%以上绿灯亮	导致耳机发生故障或烧毁;	
电池容 充电方 充电电	&电仓参数说明 容量: 400mAh 5式: Type-C 自压/电流: 5V / 3充电时间: 约1		 這勿将产品侵入任何液体或水冲洗产品; 请勿使用超过耳机额定电流电压(5V/1A)以外的充电器给耳机充电, 否则容易造成耳机电池损坏(请使用搭配的充电线给耳机充电); 请在常温环境中使用和存放本产品,勿将设备置于温度过低或过高的环境中(0°以下或者45°以上); 请勿堵塞耳机的开口处,如充电口、指示灯和麦克风等; 请避免过大音量或过长时间使用耳机,避免造成头晕或对听力造成伤害; 请勿在雷暴天气下使用设备,可能导致设备工作不正常,信号中断等现象。 	CE 🕸 🖄

Product State	Tone	Lighting Effect
Turn on	"Ding dong"	Blue light flash
Turn off	"Du"	Red light flash once
Connected	"Dong"	Blue light flash
Disconnect	"Dong"	Red / Blue lights flash alternately
Low battery alert	"Du" "Du"	_

Product State	Lighting Effect	
Charging	Charging: Red light always On, fully charged: Red light off	
Put the earbuds in the case to charge	Left earbud: blue light flash when charging and goes out when fully charged Right earbud: green light flash when charging and goes out when fully charged	
Put the earbuds in the case	left earbud: blue light flash once when put in or take out Right earbud: green light flash once when put in or take out	
Open/Close the charging case	Earphone turn on and the charging case light display the current battery for 3 seconds	
Battery indicator	The red light flashing below 20%, and the green light is on above 20%	

Charging Case Parameter Description

Battery capacity: 400mAh Charging case product size: 83.82*64.59*28.35mm Battery life : about 3-4 times Charging port: Type-C Charging voltage/current: 5V / 1A Operating temperature: -10°C~+45°C

Charging time: about 1.5 hours Storage temperature: -20°C~+65°C

Restore factory settings

Put the earphone into the charging case and keep the case open, hold the left/right earphone touch area for 8 seconds. The red light will flash for 3 seconds and then factory reset Hold the left/right earpho touch area for 8s



Safety Guidelines

1. Please follow the instructions in this manual, do not disassemble or modify the device for any reason, otherwise it may cause the earphones to malfunction or burn

2. Do not infiltrate the product into any liquid or water to rinse the product 3. Do not use a charger other than the rated current and voltage of the headset

(5V/1A) to charge the headset, otherwise It is easy to cause damage to the earphone battery (please use the matching charging cable to charge the earphone)

4. Please use and store this product in a normal temperature environment, do not place the device in an environment where the temperature is too low or too high(below 0 or above 45°)

5. Do not block the openings of the headset, such as the charging port, indicator light and microphone, etc

6. Please avoid using headphones at excessive volume or for too long to avoid

dizziness or damage to hearing

7. Do not use the device under thunderstorm weather, which may cause the device

(€ 🖓 🗏

to work abnormally and the signal to be interrupted.

Warranty card

User Name:		
User Number:		
User Address:		
Purchase Date:		
Invioce Number:		
Seller:		
After-sales Provider:		
After-sales Number:		

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-Reorient or relocate the receiving antenna.

-Increase the separation between the equipment and receiver.

-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure statement

The device has been evaluatec to meel general RF exposure requirement. The device can be used in porlable exposure condition without restriction.