

版本号

B 版

设计

林雨娟

审核

周博凡

校对

黄丽华

日期

2024.10.17

MAGCAM PHONE GRIP-BLUE TOOTH REMOTE CONTROLLER
MAGCAM手机摄影手柄-蓝牙遥控器

PGYTECH

Specifications

Product Name: MagCam Phone Grip-Bluetooth Remote Controller
Main Materials: ABS+PC, Aluminum Alloy, Zinc Alloy
Magnetic Stand Vertical Suction Force: 18N
Battery Capacity: 3000mAh
Rated Capacity: 2100mAh
Grip Battery Voltage: 3.6V
Grip Battery Power: 3.6V/1.1Wh
Type-C Port Input: 5V/2A
Type-C Port Output: 5V/2A
Wireless Charging Output: 5V/1A
Electrical Contact Pins Output: 5V/1A

In the Box

User Guide x 1 Wireless Magnetic Charging Stand x 1 MagCam Charging Grip x 1

Get to Know Your Bluetooth Remote

Bluetooth Remote Controller x 1 Magnetic Ring x 1 Safety Lanyard x 1

Battery Indicator Light (Red)
Bluetooth Indicator Light (Blue)
Power/Bluetooth Pairing Button
Zoom Adjustment Button
Shutter/Record/Focus Button
Quick Start/Mode Switch/Camera Flip Button

Specifications

Battery Capacity/Voltage	40mAh 3.7V
Charging Port	Electrical contact pins
Operating Temperature	-10°C to 45°C
Transmission Range	10 meters

Status Indicator Lights

Battery Indicator Light (Red)

- Flashing: Battery level is below 25%.
- Solid: The grip is in external charging mode. It cannot discharge externally, and cannot charge the remote control and wireless charging.
- Off: Battery level is 25% or higher. Continue to charge the remote after the light is off.

Bluetooth Indicator (Blue)

- Flashing: Remote is on and in pairing mode.
- Solid: Remote is paired with the phone.
- Off: Remote is off.

Pairing Guide

Power On

- Press and hold the "Power" button for 1 second to turn on the remote.

Power Off

- Press and hold the "Power" button for 1 second to turn off the remote.

Pairing

- Turn on the remote, enable Bluetooth on your phone, and select "PGY-MagCam." The remote will automatically power off if not paired within 3 minutes. Once paired, it will turn off after 30 minutes of inactivity. After the first pairing, the remote will automatically reconnect on future power-ons unless paired with a different device.

Clear Bluetooth Pairing

- To reset the pairing, press and hold the "Quick Start/Mode Switch/Camera Flip" button and the "Power" button simultaneously. This will disconnect the remote from any previously paired devices. Afterward, you can pair it with a new device.

Focal Length Adjustment

- Tap the "Focal Length Adjustment" button left or right to adjust the focal length. For continuous adjustment, press and hold the button. Release it to stop adjusting.

Camera Flip

- When shooting, double-tap the "Quick Start/Mode Switch/Camera Flip" button to switch to the front-facing camera.

Warnings

- Pre-installation: Ensure the surface meets adhesive requirements and is clean. Allow the magnetic ring to set for 24 hours after applying for best results.
- Compatible Surfaces: Suitable for smooth PC, TPU, glass, or metal phone cases. (Not recommended for bare phones, as heat from the device may affect the adhesive strength. It is also unsuitable for matte glass, silicone, leather, wood, fabric, or waterproof-coated surfaces. The surface must be flat for the adhesive to work effectively.)
- Adhesive: Use non-reusable 3M500LSE adhesive. Ensure the correct placement on your first attempt.

Safety Instructions

Avoid Liquid Contact: Do not expose the product to any liquids. Never submerge it in water or use it in rainy or humid conditions. Contact with water may cause corrosion, leading to battery combustion or even explosion.

Fire Response: In case of fire, use water, water mist,

Camera Flip

- When shooting, double-tap the "Quick Start/Mode Switch/Camera Flip" button to switch to the front-facing camera.

Warnings

- Pre-installation: Ensure the surface meets adhesive requirements and is clean. Allow the magnetic ring to set for 24 hours after applying for best results.
- Compatible Surfaces: Suitable for smooth PC, TPU, glass, or metal phone cases. (Not recommended for bare phones, as heat from the device may affect the adhesive strength. It is also unsuitable for matte glass, silicone, leather, wood, fabric, or waterproof-coated surfaces. The surface must be flat for the adhesive to work effectively.)
- Adhesive: Use non-reusable 3M500LSE adhesive. Ensure the correct placement on your first attempt.

Safety Instructions

Avoid Liquid Contact: Do not expose the product to any liquids. Never submerge it in water or use it in rainy or humid conditions. Contact with water may cause corrosion, leading to battery combustion or even explosion.

Fire Response: In case of fire, use water, water mist,

Warnings

No Disassembly: Do not disassemble the product. Puncturing the battery during disassembly can cause electrolyte leakage, fire, or explosion.

Avoid Physical Damage: Do not subject the product to mechanical impact, crushing, or throwing. Avoid placing heavy objects on it. Do not heat the product or place it in a microwave or pressure cooker.

Avoid Heat Sources: Do not place the product near heat sources (such as stoves or heaters) or in a hot car. The storage temperature should be between -20°C and 65°C.

Battery Care: Do not leave the battery completely discharged for long periods, as this can damage the cells and make the battery unusable. To keep the battery in good condition, recharge and discharge it about every 1 month.

Disclaimer

Please read this disclaimer carefully. Using this product means that you acknowledge and accept the terms of this disclaimer.

By using this product, you hereby acknowledge and agree that you are solely responsible for your own conduct and any consequences thereof. You agree to use this product only for proper and lawful purposes. You understand and agree that PGYTECH accepts no liability for any and all misuse, consequences, damages, injuries, penalties, or any other legal responsibility directly or indirectly incurred by you using this product.

Before every use, make sure that your product is functioning properly. If there's any damage or irregularity, stop using it immediately. Within the scope of state laws and regulations, PGYTECH reserves the right of final explanation and revision for the commitment.

**让创作更轻松
MAKE CREATION EASIER**

LEARN MORE

Question & Support: support@pgtech.com

FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- - Reorient or relocate the receiving antenna.
- - Increase the separation between the equipment and receiver.
- - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- - Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and

(2) This device must accept any interference received, including interference that may cause undesired operation.