




Includes



Warning


It is recommended that this installation be performed by a licensed professional. The improper installation of this kit will void all warranties. PLEASE READ THE FOLLOWING INSTRUCTIONS THOROUGHLY BEFORE INSTALLING AND OPERATING THIS LED WHIP

Step 1 Mount Up




- 1 Remove the bottom nut and the spring washer on the bottom of your quick-release mount
- 2 Mount the LED WHIP into any open 1/2" bolt mount on your vehicle. Make sure the flat washer is inbetween the whip and the mount
- 3 Place the spring washer underneath the mount and then rescrew the bottom nut
- 4 Have a pair? Go for round 2 and mount the 2nd whip the same way

Step 2 Get wired!



- 1 Grab your battery cord and connect it to the bottom hanging cord on your LED WHIP
- 2 Have a pair? Connect the 3-prong plug coming out the side of the master LED WHIP to the plug coming from the slave LED WHIP.
Note: The slave LED WHIP cannot function without being connected to the master LED WHIP
- 3 Feed the power cord through to your vehicle battery
- 4 Connect the terminal wire to the Positive(+) and Negative(-) terminals of your vehicle battery
- 5 Hide any extra wiring with zip ties

Step 3




When whip is not attached to base, using supplied cap to keep dirt and debris out of connector.

Step 4




Using the flag mounts to secure flag to the whip

SPEC A One PC LED Whip




SPEC B One Pair LED Whips



12v- Turn Left
12v+ Turn Right
Braking

RF Remote controller



FCC Warning Statement: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Radiation Exposure Statement

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.