





Restrict Band NVNT n20mimo 5320MHz Peak




Restrict Band NVNT n20mimo 5320MHz Average






Restrict Band NVNT n40mimo 5270MHz Peak




Restrict Band NVNT n40mimo5270MHz Average






Restrict Band NVNT n40mimo 5310MHz Peak




Restrict Band NVNT n40mimo 5310MHz Average






Restrict Band NVNT ac20mimo 5260MHz Peak




Restrict Band NVNT ac20mimo 5260MHz Average






Restrict Band NVNT ac20mimo 5320MHz Peak




Restrict Band NVNT ac20mimo 5320MHz Average






Restrict Band NVNT ac40mimo 5270MHz Peak




Restrict Band NVNT ac40mimo 5270MHz Average






Restrict Band NVNT ac40mimo 5310MHz Peak




Restrict Band NVNT ac40mimo 5310MHz Average






Restrict Band NVNT ac80mimo 5290MHz Peak




Restrict Band NVNT ac80mimo 5290MHz Average






Restrict Band NVNT ac80mimo 5290MHz Peak



Restrict Band NVNT ac80mimo 5290MHz Average





E.5 Frequency Stability

Condition	Mode	Frequency (MHz)	Antenna	Measured Frequency (MHz)	Frequency Error (Hz)	Deviation (ppm)	Limit (ppm)	Verdict
NVNT	ac20	5260	Ant1	5259.98	-20000	-3.8	25	Pass
NVNT	ac20	5300	Ant1	5299.98	-20000	-3.77	25	Pass
NVNT	ac20	5320	Ant1	5319.98	-20000	-3.76	25	Pass
NVNT	ac40	5270	Ant1	5270	0	0	25	Pass
NVNT	ac40	5310	Ant1	5309.96	-40000	-7.53	25	Pass
NVNT	ac80	5290	Ant1	5290	0	0	25	Pass




Shenzhen LCS Compliance Testing Laboratory Ltd.
Add: 101, 201 Bldg A & 301 Bldg C, Juji Industrial Park Yabianxueziwei, Shajing Street, Baoan District, Shenzhen, 518000, China
Tel: +(86) 0755-82591330 | E-mail: webmaster@lcs-cert.com | Web: www.lcs-cert.com
Scan code to check authenticity




Test Graphs

Freq. Stability NVNT ac20 5260MHz Ant1




Freq. Stability NVNT ac20 5300MHz Ant1






Freq. Stability NVNT ac20 5320MHz Ant1




Freq. Stability NVNT ac40 5270MHz Ant1






Freq. Stability NVNT ac40 5310MHz Ant1



Freq. Stability NVNT ac80 5290MHz Ant1





Condition	Mode	Frequency (MHz)	Antenna	Measured Frequency (MHz)	Frequency Error (Hz)	Deviation (ppm)	Limit (ppm)	Verdict
NVNT	ac20	5260	Ant2	5259.98	-20000	-3.8	25	Pass
NVNT	ac20	5300	Ant2	5299.98	-20000	-3.77	25	Pass
NVNT	ac20	5320	Ant2	5319.98	-20000	-3.76	25	Pass
NVNT	ac40	5270	Ant2	5269.96	-40000	-7.59	25	Pass
NVNT	ac40	5310	Ant2	5309.96	-40000	-7.53	25	Pass
NVNT	ac80	5290	Ant2	5290.08	80000	15.12	25	Pass




Shenzhen LCS Compliance Testing Laboratory Ltd.
Add: 101, 201 Bldg A & 301 Bldg C, Juji Industrial Park Yabianxueziwei, Shajing Street, Baoan District, Shenzhen, 518000, China
Tel: +(86) 0755-82591330 | E-mail: webmaster@lcs-cert.com | Web: www.lcs-cert.com
Scan code to check authenticity




Test Graphs

Freq. Stability NVNT ac20 5260MHz Ant2




Freq. Stability NVNT ac20 5300MHz Ant2






Freq. Stability NVNT ac20 5320MHz Ant2




Freq. Stability NVNT ac40 5270MHz Ant2






Freq. Stability NVNT ac40 5310MHz Ant2



Freq. Stability NVNT ac80 5290MHz Ant2





E.6 Duty Cycle

Condition	Mode	Frequency (MHz)	Antenna	Duty Cycle (%)	Correction Factor (dB)	1/T (kHz)
NVNT	a	5260	Ant1	97.75	0.1	0.37
NVNT	a	5300	Ant1	97.72	0.1	0.37
NVNT	a	5320	Ant1	97.72	0.1	0.37
NVNT	n20	5260	Ant1	97.29	0.12	0.44
NVNT	n20	5300	Ant1	97.29	0.12	0.44
NVNT	n20	5320	Ant1	97.34	0.12	0.44
NVNT	n40	5270	Ant1	94.71	0.24	0.9
NVNT	n40	5310	Ant1	94.71	0.24	0.9
NVNT	ac20	5260	Ant1	97.29	0.12	0.44
NVNT	ac20	5300	Ant1	97.34	0.12	0.44
NVNT	ac20	5320	Ant1	97.34	0.12	0.44
NVNT	ac40	5270	Ant1	94.81	0.23	0.9
NVNT	ac40	5310	Ant1	94.72	0.24	0.9
NVNT	ac80	5290	Ant1	89.65	0.47	1.86




Shenzhen LCS Compliance Testing Laboratory Ltd.
 Add: 101, 201 Bldg A & 301 Bldg C, Juji Industrial Park Yabianxueziwei, Shajing Street, Baoan District, Shenzhen, 518000, China
 Tel: +(86) 0755-82591330 | E-mail: webmaster@lcs-cert.com | Web: www.lcs-cert.com
 Scan code to check authenticity




Test Graphs

Duty Cycle NVNT a 5260MHz Ant1




Duty Cycle NVNT a 5300MHz Ant1






Duty Cycle NVNT a 5320MHz Ant1




Duty Cycle NVNT n20 5260MHz Ant1






Duty Cycle NVNT n20 5300MHz Ant1




Duty Cycle NVNT n20 5320MHz Ant1






Duty Cycle NVNT n40 5270MHz Ant1




Duty Cycle NVNT n40 5310MHz Ant1






Duty Cycle NVNT ac20 5260MHz Ant1




Duty Cycle NVNT ac20 5300MHz Ant1






Duty Cycle NVNT ac20 5320MHz Ant1




Duty Cycle NVNT ac40 5270MHz Ant1






Duty Cycle NVNT ac40 5310MHz Ant1



Duty Cycle NVNT ac80 5290MHz Ant1






Condition	Mode	Frequency (MHz)	Antenna	Duty Cycle (%)	Correction Factor (dB)	1/T (kHz)
NVNT	a	5260	Ant2	98	0	0.46
NVNT	a	5300	Ant2	98	0	0.46
NVNT	a	5320	Ant2	98	0	0.46
NVNT	n20	5260	Ant2	97.86	0.09	0.5
NVNT	n20	5300	Ant2	97.86	0.09	0.5
NVNT	n20	5320	Ant2	97.86	0.09	0.5
NVNT	n40	5270	Ant2	95.93	0.18	1.01
NVNT	n40	5310	Ant2	95.83	0.18	1.01
NVNT	ac20	5260	Ant2	97.87	0.09	0.5
NVNT	ac20	5300	Ant2	97.82	0.1	0.5
NVNT	ac20	5320	Ant2	97.87	0.09	0.5
NVNT	ac40	5270	Ant2	95.77	0.19	1
NVNT	ac40	5310	Ant2	95.87	0.18	1
NVNT	ac80	5290	Ant2	91.6	0.38	2.08






Test Graphs

Duty Cycle NVNT a 5260MHz Ant2




Duty Cycle NVNT a 5300MHz Ant2






Duty Cycle NVNT a 5320MHz Ant2




Duty Cycle NVNT n20 5260MHz Ant2






Duty Cycle NVNT n20 5300MHz Ant2




Duty Cycle NVNT n20 5320MHz Ant2






Duty Cycle NVNT n40 5270MHz Ant2




Duty Cycle NVNT n40 5310MHz Ant2






Duty Cycle NVNT ac20 5260MHz Ant2




Duty Cycle NVNT ac20 5300MHz Ant2






Duty Cycle NVNT ac20 5320MHz Ant2




Duty Cycle NVNT ac40 5270MHz Ant2





Duty Cycle NVNT ac40 5310MHz Ant2



Duty Cycle NVNT ac80 5290MHz Ant2

