


AP User Manual

1. Connection


- 1) Power the AP to WAN port via af/at POE injector or POE Switch
- 2) Change the local IP of PC to 192.168.0.123
- 3) In the Browser, Fill in 192.168.0.50, then you can see login page

2. Login

- 1) In the Browser, Fill in 192.168.0.50, then you can see login page




- 2) Fill in login password: admin, then you can login it
- 3) The IP and password is showed on the label of the product




3. Wizard settings


The AP support both AP and Gateway mode ,we always use AP mode




Choose AP mode




If the default connection way is get IP from AC, if you want to use it work with AC, then no need to change it, if you do not want to use it work with AC, you can choose get IP from gateway or use static IP.






Next, you can switch on/off the wifi, and you can change the 2.4G and 5.8G SSID, wireless mode, channel, encryptions, etc.




After everything is configured, the AP will restart.

4. WIFI Settings


You can do the settings for wifi like in the wizard above.



You can add MAC ACL to limit the users by MAC





You can set up timing wifi in a time range.




5. Network settings

It is the same as the one in wizard.



The AP can be connected to cloud server management ,just fill in the server address and do some settings on cloud side ,the AP will be managed by cloud .


6. Management




You can restore the settings ,and upload it from other devices.

Backup -it is used to backup the current settings .


Reset- it is used to recover the settings to factory default



Time reboot supports to set a time to the device to reboot.



When there is a newer version ,can upgrade the newer version through this function



Time Manager- Can set up the time zone and server to what you need

FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- - Reorient or relocate the receiving antenna.
- - Increase the separation between the equipment and receiver.
- - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- - Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

RF Exposure Statement

To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum distance of 20cm the radiator your body. This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter.