## 产品规格

- · 产品型号: C-309

- ・ 出生が、1 1853 77 1864Ab, 完化会1.77 250mAb ・ 能容数は、正理3.77 1864Ab, 完化会2.77 250mAb ・ 変数を、1056年2月9 5.76 人は、1862 ・ 通数分割。 約354年 ・ 通数分割。 約354年 ・ 現まり前。 約354年 ・ 後期間。 1856年3月 ・ 後期間。 1856年3月 ・ 後期間。 1856年3年2年3日 ・ 大概会2月間。 1856年3日 ・ 大概会3年3年3日 ・ 大概会3年3日 ・ 大成会3年3日 ・ 大成

## 功能操作说明

1、开机 将耳机从充电仓拿出自动开机或长按左右耳机多功能键3秒开机。

2、美机 将耳机放入充电仓自动关机/长按左右耳机多功能键5秒关机。

3、开机回连 当配对成功后,第二次开机时蓝牙耳机优先进入回连状态自动回 连已连接过的手机。

4、播放/暂停 在待机状态下,单击左右耳机多功能键均可直接播放音乐,播放 时单击左右耳机多功能键均可暂停播放。

- 5、切换歌曲
- 播放音乐时三击左右耳机多功能键切换上下曲。 6、音量加減
- 双击左右耳机多功能键加大减小音量。
- 7. 辛由接听
- 手机来电时,单击左右耳机多功能键均可接听电话。
- 8、来电挂断
- 手机通话时,单击左右耳机多功能键均可挂断电话。
- 9、来电拒接
- 手机来电时,长按左右耳机多功能键2秒均可拒接来电。
- 10、末号重拨
- 在待机或者穩放音乐时,长按耳机多功能罐3秒即可拨打您通话记录中最后一个拨打过的电话。
- 11、启动语音助手
- 长按耳机多功能键1.5秒即可启动Siri或谷歌语音助手进行语音 控制手机操作。

## 配对方式 普通配对方式

- 1. 从充电仓取出或者同时长按左、右耳机多功能键3秒开机,自动 配对
- 2. 启动手机或者其它设备的蓝牙功能,点击进入配对
- 两只耳机也可单独与手机进行配对使用,操作方法可按上步骤2 操作手法进行操作。

## 充电操作

1.将Micro USB充电线一头插上充电盒的USB口一头插上充电器即可 给充电盒充电,当充电盒电量在对应指示灯的指示范围时,该位置 的白色指示灯间隔2秒闪一次,直至该指示灯的电量范围充满后则长 亮进入下一电量范围的指示灯闪烁,全部充满电后所有指示灯长亮 2. 给耳机充电:将耳机放入充电仓即可自动充电,充电时耳机指示 灯为红色,充满电后熄灭;充电仓蓝色指示灯长亮(充电仓满电时, 4个电量指示灯全亮,当充电仓电量下降达到相应电量时,对应的指 示灯则熄灭},当耳机充满电后充电仓蓝色指示灯全部熄灭。

Product specification Product model: C-309

Battery specifications: Earphone 3.7V 35mAh; Charging bin 3.7V 25mAh; Charging lime; about 3.7V 25mAh; Charging lime; about 3.7V 25mAh; Charging lime; charge the charging box for about 1.5 hours, and charge the headest for about 1.5 hours, and charge the headest for about 1.5V 25mBh; Charging lime; Sor earphones in charging bin about 2.5 limes

Function Operation Description

1, the bootTake the early on out of the charging bin and
start it automatically or press the left and right earphone
start it automatically or press the left and right earphone

2, turn it offFut the earphone into the charging bin to
automatically shut downlong press the left and right
earphone multi-function button for 5 seconds to shut down.

3, Start and recommectAfter the pairing is successful, the
Bluettooth headset will enter the connection state
preferentially and automatically return when

it is turned on for the second time Connect to an already connected cell phone.

4. Playphased he had been connected to the left of Playphased he had been connected to the left of Playphased his connected had been connected to the left and relay of the headset to play had been connected to the left and right headset multi-function keys to pause the playback.

5. Switch songs/When playing music, click the number of the playback had been connected to the left and relationship to the playback.

and down.
6, volume increase and decreaseDouble click the left and right multi-function buttons to increase and decrease the

11. Activate the voice assistantHold down the headset multifunction button for 1.5 seconds to activate Siri or Google's Voice AssistantControl phone operation.

pairingCommon (pairing mode)

1. Take it out from the charging bin or press
the left and right multi-function button for 3 seconds to
start automatically pairing

2. Activate Bluetooth on your phone or other device and

2. Activate Buter Dairing
3. The two earphones can also be paired with a mobile phone. For details, go to Step 2Operation method Perform operations.

phone. For details, go to Step 20 peration method Perform operation of the More Use Step 20 peration method Perform operation of the More Use Step 20 peration of the Company of the More Use Step 20 peration of the Company of the More Use Step 20 peration of the Company of the Company of the More Use Step 20 per 20 p

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -- Reorient or relocate the receiving antenna.
- -- Increase the separation between the equipment and receiver.
- -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -- Consult the dealer or an experienced radio/TV technician for help.

Warning: changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment