









Geek One Mic Quick Start Guide Manual v1.0
















TX Interface








RX Interface

......





TX2











Button	Behavior
Power On/Off	Long Press Power Button For 3s











TΧ











Button	Behavior
Mute	Click Power Button Lightly



























Button	Behavior
Backlight Control Mode	To turn power saver mode off, single-click the power button. The backlight will now always stay on.
Power Saver Mode	Single-click the power button



















Button	Behavior
Gain Control	Click M button to adjust -24, -18, -12, -6, -3, 0dB


































Button	Behavior
Mute Control	Click S button to select channel, Click M button to mute/Unmute







Button	Behavior	
Mono/Stereo	Long press M+S button for 3s	





WARRANTY SERVICE

Scan the QR code then input the required information to confirm your One-Year-Warranty service.



OUICK GUIDE WITH ANALOG OUTPUT

L Attached Rx to record device with 35mm TRS or TRRS cable II. Power on Rx & Tx III. Adjust Rx gain level for suitable level

IV. Adjust Rx output mode as Mono or Stereo V. Start your recording

QUICK GUIDE WITH USB OUTPUT

II. Attached Rx to record device with 35mm TRS or TRRS cable II. Power on Rx & Tx

III. Adjust Rx gain level for suitable level

IV. Adjust Rx output mode as Mono or Stereo

V. Start your recording





This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: 1) this device may not cause harmful interference, and 2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try correct the interference by one or more of the following measures:

- Reorient the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into and outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void your authority to operate the equipment.