


英



## Airmars XKT08 Pro

### Wireless Gaming Headphones Instruction manual


#### Product parameters

Bluetooth version	V5.3
Transmission distance	≥10m
Driver diameter	43mm
Driver impedance	32 Ω±15%
Sensitivity	109±3dB
Frequency response	20Hz-20kHz
Battery capacity (charging case)	300mAh 3.7V
Battery capacity (headphone)	33mAh 3.7V
Charging time(charging case)	≈1.5 hours
Music playtime (headphone)	≈5hours
Music playtime with charging case	≈24 hours

#### Packing list


	Headphone*2		charging case*1
	Instructions Manual*1		Type-C charging cable*1

#### Product Schematic Description



#### Charge the charging case

Connect the charging case to the 5V power adapter with Type-C charging cable.



Rated input:5V=30mA(Headphone)Rated input:5V= 300mA(charging case)

Tips: When the ice blue indicator flashes while closing the cover, please charge in time.

#### Indicator guide


Mode	Description	Voice prompt
Power on	Headphone ice blue indicator flash for 1 second	"Power on"
Power off	Headphone red indicator flash 3 times	"Power off"
Pairing	The earphone flashes red and blue alternately	"Pairing"
Connected	Headphone indicator off	"Connected"
Disconnected	The earphone flashes red and blue alternately	"Disconnected"
Low Battery	The red light flashes once every 5 seconds	"Low Battery"
Headphones placed in charging case	The headphone indicator light is always on when fully charged it goes out	—
Charging case low power	The upper and lower light bar indicator lights flash for 8 seconds and then turn off	—
Charging case charged	Up and down light bars indicator lights slow breathing	—
Charging case fully charged	Indicator light permanently on	—

#### Product operating instructions

- Power on  
Method 1: Take out the headphones from charging case, the headphones will turn on automatically.  
Method 2: Long press MFB for 3 seconds.
- Power off  
Method 1: Put the headphones into the charging case and close the cover.  
Method 2: After disconnected from the bluetooth device for 3 minutes.

- Pairing  
Method 1: Take out the headphones from the charging case, the headphones will start pairing automatically.  
Method 2: Search and click for "Monster Airmars XKT08 Pro" on the bluetooth list of the smart device, and when connection is successful, "Connected" will be heard.

\* If the distance is exceeded, return to the effective distance within 3 minutes after disconnection, and automatically connect the device.



Note:  
\* If the product is not suitable for a long time, it should be fully charged and ensure that the device is in a shutdown state.  
\* After charging, please pull out the charging cable to avoid equipment damage caused by long-time charging.

#### Touch key operation

- Normal**
- Voice assistant: Press the left MFB for 2 seconds
  - Volume +: Click right MFB
  - Volume -: Click left MFB

- Music mode**
- Pause/Play: Double click Left/Right MFB
  - Last song: Triple click left MFB
  - Next song: Triple click right MFB

- Phone**
- Answer: Double click the left/right MFB
  - Reject: Press left/right MFB for 2 seconds
  - Hang up: Double click the left/right MFB

- Game mode/music mode switch: Device connected**
- Press right MFB for 2 seconds to enter game mode
  - Press right MFB for 2 seconds to enter music mode

#### Restore factory settings

Either headphones is not connected to the bluetooth device when turned on, click the MFB 5 times to clear the previous pairing information and turn off.

#### FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:  
— Reorient or relocate the receiving antenna.  
— Increase the separation between the equipment and receiver.  
— Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.  
— Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:  
(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment  
FCC ID: 2A8PV-QSMT08P

#### Precautions

- Headphones will turn on automatically (needless to press any button) pair and connect the device when the charging case is opened. After placing the headphones in the charging case, they will turn off and automatic charging will start when the cover is closed.
  - Charging every 15 days will extend battery life when not in use often. Cleaning off dirt on the charging contacts by cotton swabs with alcohol will maintain a good contact for charging.
  - Keep battery (battery pack) away from inflammables or excessive heat such as direct sunlight.
  - Due to the wireless connection mode of this product, in the daily use process, influenced by the environment, mobile phone brand, usage behavior and other factors, it is normal that there may be a brief and slight sound delay in the process of playing music.
- Warnings**
- Do not use headphones at high volume for an extended period of time.
  - Keep the headphones away from dust and water.
  - Do not disassemble the headphones and accessories, otherwise warranty will be voided
  - Keep headphones away from any impact or vibration.
  - Do not use any chemical solvents or cleaning agent on the headphones.

Name of the Parts	Hazardous substances					
	Pb	Hg	Cd	Cr(VI)	PBB	PBDE
Housing	O	O	O	O	O	O
Loudspeakers	O	O	O	O	O	O
PCBA	X	O	O	O	O	O
Accessories	X	O	O	O	O	O

This table is compiled according to SJ/T 11364.

O: Indicates that this hazardous substance contained in all of the homogeneous materials for this part is below the limit requirement in GB/T 26572.

X: Indicates that this hazardous substance contained in at least one of the homogeneous materials used for this part is above the limit requirement in GB/T 26572.



The period of use of this symbol (10 years) is the period during which harmful substances in electronic and electrical products will not leak or mutate under normal use conditions, and users of electronic products will not cause serious pollution to the environment or serious damage to their personal and property when using this electronic product.

#### Warranty service

Dear user, this warranty card is the proof of your future warranty application with the seller to fill it out and keep it for future use!

#### User information

User name		Email	
Contact number		Postal code	

Mailing address

#### Product information

Product name		Product number	
Product barcode/Serial number/Batch number			

#### Vendor information

Name	
Address	
Contact number	Postal code
Sales date	Invoice number
Remark	

