

中

Monster Airarms XK003  
真无线蓝牙耳机  
使用说明书

产品参数

- 蓝牙版本 - V5.4
- 传输距离 - ≥10m
- 喇叭直径 - 15\*10mm
- 喇叭阻抗 - 24Ω±10%
- 灵敏度 - 112±3dB
- 喇叭频率 - 20Hz-20KHz
- 电池容量 (充电盒) - 200mAh 3.7V
- 电池容量 (耳机) - 60mAh 3.7V
- 充电时间 (充电盒) - ≈1.5小时
- 播放时间 (耳机) - ≈6小时
- 配合充电盒播放时间 - ≈14小时

包装清单

耳机 \*2

充电盒 \*1

使用说明书 \*1

Type-C充电线 \*1

产品示意图

指示灯

功能触摸键 (MFB)

充电触点

给充电盒充电

用Type-C充电线连接充电盒到5V电源适配器。

额定输入: 5V±60mA(耳机)    额定输入: 5V±200mA(充电盒)

温馨提示: 当关闭充电盒盖, 充电盒指示灯显示灯闪烁, 请给充电盒充电。

指示灯指南

| 模式    | 描述                | 语音提示           |
|-------|-------------------|----------------|
| 开机    | 耳机冰蓝指示灯闪烁3次       | "Power on"     |
| 关机    | 耳机红色指示灯长亮1秒熄灭     | "Power off"    |
| 配对    | 主耳冰蓝指示灯交替闪烁, 副耳熄灭 | "Pairing"      |
| 连接    | 耳机指示灯熄灭           | "Connected"    |
| 断开    | 主耳冰蓝指示灯交替闪烁, 副耳熄灭 | "Disconnected" |
| 耳机低电  | 耳机红色指示灯闪烁         | "Battery low"  |
| 充电盒低电 | 充电盒冰蓝指示灯闪烁        | ---            |
| 充电盒低电 | 充电盒红色指示灯闪烁        | ---            |
| 充电盒充电 | 充电盒红色指示灯闪烁        | ---            |
| 充电盒充满 | 充电盒红色指示灯长亮        | ---            |

产品操作说明

1. 开机

方式一: 打开充电盒上盖, 取出耳机自动开机;  
方式二: 长按左/右耳机的MFB按钮约3秒, 耳机开机。

2. 关机

方式一: 将耳机放回充电盒中, 耳机自动关机;  
方式二: 与蓝牙耳机断开连接3分钟后, 自动关机。

3. 配对

步骤一: 打开充电盒上盖, 取出耳机自动开机;  
步骤二: 打开智能设备的蓝牙列表, 搜索 "Monster Airarms XK003" 进行配对, 连接成功后, 你会听到提示音 "Connected"

\* 超出距离, 在新开连接3分钟内, 回到有效范围, 自动连接设备。

音乐播放模式

暂停/播放: 双击左/右耳机MFB  
上一曲: 三击左耳机MFB  
下一曲: 三击右耳机MFB

电话免提

接听: 双击左/右耳机MFB  
挂断: 双击左/右耳机MFB  
拒接: 长按2秒左/右耳机MFB

游戏模式/音乐模式切换: 已连设备

游戏模式: 长按2秒右耳机MFB进入游戏模式  
音乐模式: 长按2秒右耳机MFB进入音乐模式

恢复出厂设置

耳机开机后与蓝牙设备配对状态下, 左/右耳机配对成功, 连击左/右耳机5次后左/右耳机关机 (清除配对和连接的所有信息)

注意

1. 从充电盒取出耳机, 不需任何按键, 耳机自动开机, 连接或配对, 耳机放入充电盒, 充电盒将自动给耳机充电, 耳机关机。

2. 请清洁, 寿命长, 如长期不用, 建议15天充电1次, 延长使用寿命, 耳机充电部分经常用棉签清理, 能够保持耳机清洁, 避免接触不良, 影响使用体验。

3. 请勿将耳机或充电盒置于潮湿环境, 请勿将耳机置于高温环境中: 禁止上烤箱, 微波炉, 禁止放入火中, 若出现严重故障, 切勿继续使用, 切勿置于高温环境中, 液体禁止使用。

4. 由于耳机产品采用无线连接方式, 在日常使用过程中, 受到环境、手机品牌、使用行为等因素影响, 可能在播放音乐过程中, 会出现卡顿、轻微的声音卡顿属于正常现象。

警告

1. 长时间以高音量使用耳机可能会导致听力损伤, 建议只使用适当音量收听, 避免听音过度。

2. 请勿将耳机置于液体中, 以免造成短路。

3. 不要将耳机置于产品及其附件, 以免损坏耳机及保修权益。

4. 请勿将产品受到剧烈撞击或跌落造成损坏。

5. 请勿使用化学溶剂或腐蚀性清洁剂。

| Name of the Parts<br>部件名称 | Hazardous Substances<br>有害物质 |         |         |               |              |                |  |
|---------------------------|------------------------------|---------|---------|---------------|--------------|----------------|--|
|                           | Pb<br>铅                      | Hg<br>汞 | Cd<br>镉 | Cu(VI)<br>六价铬 | 多溴联苯<br>PBBs | 多溴二苯醚<br>PBDEs |  |
| Housing<br>外壳             | O                            | O       | O       | O             | O            | O              |  |
| Accessories<br>配件         | O                            | O       | O       | O             | O            | O              |  |
| PCBA<br>印刷电路板             | X                            | O       | O       | O             | O            | O              |  |
| Accessories<br>配件         | X                            | O       | O       | O             | O            | O              |  |
| Accessories<br>配件         | X                            | O       | O       | O             | O            | O              |  |

This table is compiled according to SJ/T 11364.  
本表格依据SJ/T 11364编制而成。  
O: Indicates that this hazardous substance contained in all of the homogeneous materials for this part is below the limit requirement in GB/T 26572.  
X: Indicates that this hazardous substance contained in at least one of the homogeneous materials used for this part is above the limit requirement in GB/T 26572.  
O: Indicates that this hazardous substance is not contained in any of the homogeneous materials used for this part is below the limit requirement in GB/T 26572.  
X: Indicates that this hazardous substance is not contained in any of the homogeneous materials used for this part is above the limit requirement in GB/T 26572.

FCC 声明

根据FCC规则第15部分, 本设备经过测试, 符合B类数字设备的限制。这些限制旨在提供合理的住宅设施中的有害干扰防护。该设备产生使用并可辐射射频能量, 如果未按照说明安装和使用该设备可能会对无线电信号造成有害干扰。然而, 有不能保证在特定安装中不会发生干扰。如果这个设备有对无线电或电磁接收造成有害干扰, 可通过转动来确定设备关闭和打开时, 鼓励用户尝试通过一个或多个以下更多措施:  
--重新定向或重新定位接收天线。  
--增加设备接收器与发射器之间的间距。  
--将设备连接到与接收器不同的电源上的插座以获得帮助。  
--咨询向经销商或经验丰富的无线电/电视技术人员以获得帮助。  
此设备符合FCC规则的15部分, 操作受以下两个条件限制:  
(1) 本装置不得引起有害干扰。  
(2) 本装置必须接受任何接收到的干扰, 包括可能导致意外操作的干扰。未经合规责任方明确批准的变更或修改可能使用户对设备的操作权限失效。  
FCCID: 2ABPV-QSMXX003  
Environment Friendly Use Period (EFUP)  
环保使用期限  
This logo refers to the period (10 years) during which the hazardous substances in electronic and electrical products will not leak or mutate so that the use of these [substances] will not result in any severe environmental pollution, any bodily injury or damage to any assets.  
这标志标识的期限 (10年) 是电子产品中含有有害物质在正常使用条件下不会发生外泄或突变, 电子产品用户使用该电子产品不会对环境造成严重污染或对人体人身、财产造成严重损害的期限。

保修卡

尊敬的客户, 本保修卡是您将来申请保修凭证, 请您在销售商填写并妥善保管!  
用户信息  
用户姓名: \_\_\_\_\_ 电子邮件: \_\_\_\_\_  
联系电话: \_\_\_\_\_ 邮政编码: \_\_\_\_\_  
通讯地址: \_\_\_\_\_  
产品信息  
产品名称: \_\_\_\_\_ 产品型号: \_\_\_\_\_  
产品条码/编号/批号: \_\_\_\_\_  
销售商信息  
名称: \_\_\_\_\_  
地址: \_\_\_\_\_  
联系电话: \_\_\_\_\_ 邮政编码: \_\_\_\_\_  
销售日期: \_\_\_\_\_ 发票号码: \_\_\_\_\_  
备注: \_\_\_\_\_  
合格证  
产品名称: \_\_\_\_\_  
生产时间: \_\_\_\_\_  
出厂日期: \_\_\_\_\_  
M MONSTER  
合格证  
产品编号: \_\_\_\_\_  
出厂日期: \_\_\_\_\_

英

Monster Airarms XK003  
True wireless Bluetooth headphone  
instruction manual

Product parameters

- Bluetooth version - V5.4
- Transmission distance - ≥10m
- Driver diameter - 15\*10mm
- Driver impedance - 24Ω±10%
- sensitivity - 112±3dB
- Frequency response - 20Hz-20KHz
- Battery capacity(Charging case) - 200mAh 3.7V
- Battery capacity(Headphone) - 60mAh 3.7V
- Charging time(Charging case) - ≈1.5 hours
- Music playtime(Headphone) - ≈6 hours
- Music playtime with charging case - ≈14 hours

Product Schematic Description

Headphone\*2

Charging case\*1

Instructions Manual\*1

Type-C Charging cable\*1

Product Schematic Description

Indicator

Multi-Function Buttons(MFB)

Charging contact

Type-C

Charge the charging case

Connect the charging case to the 5V power adapter with Type-C charging cable.

Rated input: 5V±60mA(Headphone)    Rated input: 5V±200mA(Charging case)

TIPS: When the cover of the charging box is closed, the indicator light of the charging box flashes ice-blue, please charge the charging box.

Indicator guide

| Mode                               | Describe  | Sound prompt   |
|------------------------------------|---|----------------|
| Power On                           | ice blue light of the headset blinks three times  | "Power on"     |
| Power Off                          | Red indicator light on the headphones remains on for 1 second and goes off                        | "Power off"    |
| Pairing                            | ice blue and red light flashes alternately in the main ear, and the secondary ear is extinguished | "Pairing"      |
| Connected                          | Headphones LED indicator is off   | "Connected"    |
| Disconnected                       | ice blue and red light flashes alternately in the main ear, and the secondary ear is extinguished | "Disconnected" |
| Low Battery                        | Red indicator on the headset blinks   | "Battery low"  |
| Headphones placed in charging case | ice blue indicator light of the charging case is bright   | ---            |
| Charging case low power            | ice blue indicator of the charging case blinks  | ---            |
| Charging case charged              | Red indicator of the charging case blinks   | ---            |
| Charging case fully charged        | Red light of the charging case is bright  | ---            |

Product operating instructions

1. Power on

Method 1: Open the top cover of the charging case, take out the headset and turn it on automatically.  
Method 2: Long press the MFB button of the left/right headset for about 3 seconds to power on the headset.

2. Power off

Method 1: Put the earphones back in the charging case and the earphones automatically turn off  
Method 2: The device automatically shuts down after 3 minutes of disconnection from the Bluetooth device.

3. Pairing

Step one: Open the top cover of the charging case, take out the headset and turn it on automatically.  
Step two: Open the Bluetooth list of smart devices, search for "Monster Airarms XK003" to pair, and the connection is successful. After that, you will hear the "Connected" tone.  
\* Headphones will try reconnecting to the device within 3 minutes when connection is lost.

Music playback

Pause/Play: Double click Left/Right MFB  
Last song: Three hits left MFB  
Next song: Three hits right MFB

Phone

Answer: Double click the left/right MFB  
Hang up: Double click the left/right MFB  
Reject: Long press left/right MFB for 2 S

Game mode/Music mode switch: Connected device

Game mode: Press and hold right earphone MFB for 2 seconds enter Game mode  
Music mode: Press and hold right earphone MFB for 2 seconds enter Music mode

Restore factory settings

When you turn on the headphone, make sure it does not connect to any Bluetooth device, and click the MF button 5 times to clear the pairing record, then turn off the headphone.

Precautions

1. Take out the earphone from the charging box, without pressing any button, the earphone will automatically turn on, connect or pair, put the earphone into the charging box, and the charging box will automatically charge your headphones. Turn them off.

2. Often clean, long life. If not used for a long time, it is recommended to charge once every 15 days to extend battery life, and the charging part of the headset is often used with cotton swabs. Alcohol wipe, can help smooth charging, avoid bad contact, affect the use experience.

3. The battery (battery pack or battery combination) shall not be exposed to lighting, baking or similar overheating environment; Do not disassemble, knock, squeeze or throw in the fire, if there is serious swelling, do not continue to use; Do not place in high temperature environment; Do not use after soaking water.

4. Because this product adopts wireless connection mode, it is affected by environment, mobile phone brand, usage behavior and other factors in daily use, it may be normal to have a brief, slight sound delay during the playing of music.

Warnings

1. Do not use headphones at high volume for an extended period of time.

2. Keep the headphones away from dust and water.

3. Do not disassemble the headphones and accessories, otherwise warranty will be voided.

4. Keep headphones away from any impact or vibration.

5. Do not use any chemical solvents or cleaning agent on the headphones.

| Name of the Parts | Hazardous Substances |    |    |        |     |      |  |
|-------------------|----------------------|----|----|--------|-----|------|--|
|                   | Pb                   | Hg | Cd | Cu(VI) | PBB | PBDE |  |
| Housing           | O                    | O  | O  | O      | O   | O    |  |
| Accessories       | O                    | O  | O  | O      | O   | O    |  |
| PCBA              | X                    | O  | O  | O      | O   | O    |  |
| Accessories       | X                    | O  | O  | O      | O   | O    |  |

This table is compiled according to SJ/T 11364  
O: Indicates that this hazardous substance contained in all of the homogeneous materials for this part is below the limit requirement in GB/T 26572.  
X: Indicates that this hazardous substance contained in at least one of the homogeneous materials used for this part is above the limit requirement in GB/T 26572.

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:  
-- Reorient or relocate the receiving antenna.  
-- Increase the separation between the equipment and receiver.  
-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.  
-- Consult the dealer or an experienced radio/TV technician for help.  
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:  
(1) This device may not cause harmful interference.  
(2) This device must accept any interference received, including interference that may cause undesired operation. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.  
This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the Radio and your body.  
FCCID: 2ABPV-QSMXX003  
Environment Friendly Use Period (EFUP)

Warranty Service

Dear user, this warranty card is the proof of your future warranty application, please cooperate with the seller to fill it out and keep it for future use!  
User info  
User name: \_\_\_\_\_ Email: \_\_\_\_\_  
Contact number: \_\_\_\_\_ Postal code: \_\_\_\_\_  
Mailing address: \_\_\_\_\_  
Product information  
Product name: \_\_\_\_\_ Product number: \_\_\_\_\_  
Product barcode / Serial number / Batch number: \_\_\_\_\_  
Vendor information  
Name: \_\_\_\_\_  
Address: \_\_\_\_\_  
Contact number: \_\_\_\_\_ Postal code: \_\_\_\_\_  
Sales date: \_\_\_\_\_ Invoice number: \_\_\_\_\_  
Remark: \_\_\_\_\_  
M MONSTER  
Certificate of Approval  
Product No.: \_\_\_\_\_  
Production Time: \_\_\_\_\_  
QC: \_\_\_\_\_