

USER MANUAL

Smart RGBCW Flood Lights

Model: NB-OL011

- © Please read before installation.
- © Please keep the manual for future reference.


Made in China

NOTICE

1. The product is suitable for outdoor use only. Avoid prolonged exposure to humid environments.
2. Do not immerse the product in water or any other liquids.
3. During installing, ensure that the screws are tightened securely .
4. Do not install the product in a high-temperature environment.
5. The adapter must be connected securely and ensure there are no looseness or poor contact.
6. Do not disassemble or assemble the lights by yourself.

OPERATION USE

1.Button Functions:



- (1) Short press to cycle through the following options: 1. Rainbow; 2. Red; 3. Green; 4. Blue; 5. Warm White; 6. Breathing; 7. Flowing; 8. Chasing; 9. Off.
- (2) Long press for 5 seconds to enter pairing mode, indicated by a flashing red light.
- (3) Double press to power off.

SOFTWARE INSTALLATION

(1) Sign up and sign in:

CozyLife APP download: Scan the QR code below or search for "CozyLife" in App Store or Google Play, then register and log in after downloading.



(2) Add the Device:

- **Step 1:** You are using a Wi-Fi + Bluetooth dual mode product. Please make sure your phone's Bluetooth is turned on and connected to Wi-Fi (only supports 2.4G WiFi networks). Also, ensure that the light is turned on and it is in the factory mode.
- **Step 2:** Open the "CozyLife" APP, the phone will automatically recognize the product, and a prompt box will pop up at the "+", showing "Scan to 1 device";
- **Step 3:** After clicking "+", select the device to be connected, click Next, and you will enter the Wi-Fi setting page;
- **Step 4:** After entering the Wi-Fi password, wait for the network configuration to be completed (only 2.4G Wi-Fi network is supported);
- **Step 5:** After successful connection, you can re-import the product and classify the room.

(3) FAQs:

Q1: How to restore the light to factory settings?

A1: Long press button over 5s or turn on/off over 3 times, the light flashes, indicating that the light strip has been set to the factory mode.

Q2: How to query the mac address?

A2: Check the Internet access on the computer, enter the network properties, and pull down to find the physical address (mac).

FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation

Caution: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However,


there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:


- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment must be installed and operated in accordance with provided instructions and the antenna(s) used for this transmitter must be installed to provide a separation distance of at least 20 cm from all persons and must not be co-located or operating in conjunction with any other antenna or transmitter. End-users and installers must be provide with antenna installation instructions and transmitter operating conditions for satisfying RF exposure compliance.

CUSTOMER SERVICE

 **Customer Service:** lightlife@globlesupports.com

 Manufacturer: Shenzhen Aspiron Technology Company Limited

 Address: 3rd Floor, Yiben Building, No.1063 Changuang Road, Xili Street, Nanshan District, Shenzhen, Guangdong, China

Made in China