BARON 2000MAH POWER BANK W/ WATCH CHARGER & CABLE INSTRUCTION MANUAL EPB-BA25

READ ALL INSTRUCTIONS CAREFULLY BEFORE USE AND KEEP THIS MANUAL.

IN THE BOX


• EPB-BA25 Baron 2000mAh Power Bank w/ Watch Charger & Cable (x1)

SAFETY PRECAUTIONS

- This product is NOT a toy, keep away from children and pets.
- Only use the product according to the instructions in this manual. Never use the product for anything other than its intended purpose.
- Do not open this product or attempt to repair the unit yourself if it is not working properly. Doing so risks fire, shock or injury.
- When not in use, the product should be stored in a dry, cool location, away from sources of water or heat.
- Do not expose product to extreme temperatures (heat or cold), open flames, humid or wet conditions.
- Do not submerge in water. Do not use in a location where the product could fall into liquid.
- Do not use if the product or built-in cable is damaged. If the product or built-in cable is damaged, it MUST be serviced or replaced by the manufacturer or its service agent before using again.
- · Do not over charge battery.
- This product contains a built-in battery and should not be disposed of with regular household waste. Please consult the local authorities on the correct way to dispose of this product.
- Attachments on the back of your watch can impede effectiveness of the wireless charger, and lead to overheating. Remove attachments from your watch before charging on the watch charger.
- The strong magnetic fields of neodymium magnets can damage items, such as
 television, computers, computer monitors, credit cards, bank cards, diskettes
 and other data carriers, video tapes, mechanical watches, hearing aids, loud
 speakers and VCRs. Pace-makers may be damaged or switched to "test mode"
 in the presence of a strong magnetic force, if pace-maker or other electronical
 body implant is in use. Keep a minimum of 3 feet distance.

—1—

PRODUCT DIAGRAMS



INSTRUCTIONS

Charge the power bank fully before using for the first time.

CHARGING THE POWER BANK

- Plug the small connector of the built-in USB-C cable into a USB-C power source, such as the USB-C port on a computer or into a certified USB-C adapter (not included), and plug into a wall socket.
- The LED indicator will **flash WHITE** while the power bank is in charging and stop flashing when the power bank is fully charged.
- To charge the power bank with USB-C charging cable (not included), plug the USB-C connector into the USB-C charging port on the power bank and the other end into a certified USB-C adapter (not included), and plug into a wall socket. (Note: Mobile power charging does not support wireless charging)

CHARGING ELECTRONIC DEVICES WITH THE POWER BANK

- Connect the built-in USB-C charging cable to your device, the power bank will begin to charge automatically.
- The LED indicator will **illuminate WHITE** when charging and turn OFF when charging complete.
- Remove the cable from your mobile device when it is fully charged.

USING WIRELESS CHARGING FOR SMART WATCH

• Press the **[Power]** button. The LED indicator will illuminate **WHITE** to indicate the watch charger is in standby mode.

- Place a wireless charging enabled smart watch on the corresponding watch wireless charging surface, the smart watch will begin to charge automatically.
- The perfectly aligned magnets in the wireless charging surface will attach to the charged watch and provide more secure wireless charging.
- The LED indicator will illuminate WHITE when charging.
- If your watch does not begin to charge, try repositioning your watch on the wireless charging surface. You may need to remove the case of your watch to charge properly.
- Remove your watch from the wireless charging surface when it is fully charged.

TECH SPECIFICATIONS

• Battery Capacity: 2000mAh/3.7V/7.4Wh

• USB-C Input: DC 5V/1.5A

USB-C Cable Input & Output: DC 5V/1.5A
Wireless Charging Output for Watch: 2W

• Working Temperature: $14^{\circ}F \sim 122^{\circ}F$ (- $10^{\circ}C \sim 50^{\circ}C$)

FCC ID: 2A9Q9-EPB-BA25

MADE IN CHINA

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -- Reorient or relocate the receiving antenna.
- -- Increase the separation between the equipment and receiver.
- -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction