


daskeyboard™


Holosonic T1w Manual



**Tri-Mode Wireless
Professional & Gaming Headset**

EN

Thank you for purchasing your new Holosonic T1w Wireless Pro & Gaming Headset. We recommend that you spend some time reading this instruction manual in order that you fully understand all the features it offers and keep this instruction manual for future reference.



1. Leatherette headband
2. Metal stretching bracket
3. Leatherette earmuffs
4. Detachable microphone
5. Long press 3 sec. for power on/off. Double click to switch to the next song. Single click to Pause, Play, Answer, End.
6. Single click to switch microphone on/off. Double click to switch to the previous song. Triple click to switch EQ mode (game mode, music mode) in 2.4G mode.
7. Volume+ wheel
8. Charging, audio input
9. Microphone connection interface

1

EN

Specifications

Speaker diameter	53mm
Sensitivity	120dB±3dB
Frequency response	20Hz~20K Hz
Rated output power	20mW
Maximum output power	30mW
Speaker impedance	32±15%Ω
Microphone dimension	Φ6.0* 5.0mm
Microphone sensitivity	-38±2dB
Directivity	Omnidirectional
Microphone impedance	< 2.2KΩ (Max)
Charging voltage	DC 5V
Battery capacity & working voltage	800mA DC 3.7V
Charging port	Type-C
Charging current	< 400mA
Effective distance	10 meters
Delayed	< 20mS
Continuous working time	15 hours

Power ON/OFF
ON: long press 3 sec on power switch
OFF: long press 3 sec on the power switch

2

EN

2.4G mode connecting

1. Turn on the headset
2. Plug the USB dongle into your computer's USB port
3. When the indicator light on USB dongle always on (not flashing) and the headset has been switched into 2.4G mode, that means 2.4G mode successful connected.

Bluetooth Mode

1. To change to Bluetooth mode, long press "M Button" for 3 seconds and switch to Bluetooth mode.
2. Open your Bluetooth device, search and connect to "Holosonic T1w" broadcasting ID, pair and connect it accordingly.
3. When pairing, the indicator is flashing and is always on if successfully connected.
4. To disconnect, three click "Power Button".

Wired Mode

1. To use wired mode, use Type-C to 3.5mm jack audio cable connect the headset and computer. No need pressing power button on the ear shell.
2. Note that when using the headset in 2.4G mode or Bluetooth mode, if plugging in the Type-C to 3.5mm audio cable or USB2.0 to Type-C charging cable, the headset will automatically shut down and not able to power on.

Note
Check your sound/audio settings so that you have the "output" set to wireless audio.
Keep the distance between headset and dongle less than 10 meters, otherwise it will be disconnected.
When power on, the headset will be the last mode-2.4G or Bluetooth which you used before power off.

Microphone

The headset comes with detachable microphone. Just plug the microphone into 3.5mm jack on headset to use microphone function.

3

EN

Charging

1. Fully charge the headset before first use.
2. Connect the Type-C to USB2.0 charging cable into a USB port device or a USB2.0 adapter.
3. It takes up to 5 hours to fully charged the headset. When the headset is charging, the LED indicator is red. LED automatically turns off when fully charged.

Power

When the battery is around 10% of power capacity, you'll hear the voice prompts "Battery Low" reminding you to charge the headset. In wireless mode, automatic shutdown will occur when the headset has not been paired for 3 minutes. In the connected and paired status, if the headset not in use, it will not automatically shut down unless the headset is out of power.

Package Contents

1 x Gaming Headset
1 x Pluggable Microphone
1 x USB Wireless Receiver
1 x Type-C to 3.5mm Jack Audio Cable
1 x USB to Type-C Charging Cable
1 x User Manual

Operating Systems

Compatible with PS4-5, Mac, PC, Mobile.

Share to Win Swag

Share your Das Keyboard experience on social media for a chance to win awesome swag.
Email a link of your shout to enter the monthly raffle:
iwantgoodies@daskeyboard.com

facebook.com/daskeyboard
twitter.com/daskeyboard

4

EN

Precautions

- Do not disassemble the product or attempt to fix it.
- Do not attempt to replace the battery inside.
- Do not crush, dispose of in fire, or expose the product to water or other liquids.
- Do not store or use the product in a high-temperature environment, including intense sunlight or heat.
- Avoid drops, vibrations, abrasions and impacts.
- If you find that the product is too hot, is emitting an odor, is deformed, or exhibits any suspicious or abnormal behavior, discontinue use immediately.

FCC Warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) this device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation

This device has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This device generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this device does cause harmful interference to radio or television reception, which can be determined by turning the device off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-Reorient or relocate the receiving antenna
-Increase the separation between the device and receiver
-Connect the device into an outlet on a circuit different from that to which the receiver is connected
-Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

5