

# AM09 NFC BLUETOOTH SPEAKER


## USER GUIDE

### Packing list:

- 1,AM09 NFC Bluetooth Speaker
- 2, Micro USB to USB charging cable
- 3, User Guide

## Product :

- ① LED indicator
- ② Power button
- ③ Vol - button
- ④ Vol+ button
- ⑤ Pairing/Tel button
- ⑥ Mic
- ⑦ Micro USB port



## Product specification:

Power output: 3W RMS

S/N: 70dB

Frequency range: 65Hz-20KHz

Wireless: Bluetooth 3.0 (A2DP, HFP), NFC

Speaker driver: 4Ω

Power Input: USB/DC 5V

Dimension: 130mm X 60mm X 23mm

Built-in Battery: 3.7v 750mAh Li-Polymer battery

## Charging:



③

⑦


If the speaker cannot turn on or the red LED be flashed, the built-in battery may be drained, please connect to a power source to recharge the speaker.

The Red LED indicator is on when the speaker is in charging, and turn off while fully charged.

### Pair with Bluetooth device:

1. Press and hold on  button.
2. The blue led be flashed
3. Search the new Bluetooth device on your smartphone
4. "HUAWEI AM09" be listed on the Smartphone
5. Select "HUAWEI AM09", if prompt the password, Pls input "0000".
6. the Paring be successful if the blue led is on
7. Press and hold on  to turn off .

Tips:

To pair with another bluetooth enabled device, please press and hold the  button for 2 seconds to disconnect the current connection and re-peat the pairing process

### Pair with NFC Bluetooth device:


- 1, Make sure the speaker is power on.
- 2, Touch the NFC area on your phone with the NFC area located on the speaker.
- 3, after successful sensing, the phone beeps or a screen prompting appears for bluetooth connection.

Tips: You can touch the NFC area again by your phone to disconnect the current connection.  
Make sure that your phone support NFC function and the NFC software is ins

### Handfree call:

- . When there is an incoming call, you can press the  button on the speaker to answer the call or press and hold the button to reject the call. Press the button again to hang up after conversation.

## **IMPORTANT SAFETY INSTRUCTIONS**

1. **WARNING:** Only use attachments/accessories specified or provided by the manufacturer (such as the exclusive supply adapter, battery etc).
2. **WARNING:** To reduce the risk of fire or electric shock, do not expose this apparatus to rain or moisture. The apparatus shall not be exposed to dripping or splashing and that objects filled with liquids, such as vases, shall not be placed on apparatus
3. **CAUTION:** Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type.
4. **WARNING:** The battery (battery or batteries or battery pack) shall not be exposed to excessive heat such as sunshine, fire or the like.
5.  **Correct Disposal of this product.** This marking indicates that this product should not be disposed with other household wastes throughout the EU. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmental safe recycling.

## **FCC**

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.