


USER MANUAL



Double E


1 Main parameters

Item No.: E354-003
Material: plastic and electronic components
Batteries: Car battery: 1pc of 4. 8V AA rechargeable battery.
Remote controller battery: two pcs of 1.5V AA batteries.



2 Battery Installation

1. Open the cover of battery case locates in the back of controller, inserts two pcs of 1.5V AA batteries into the battery case, and then screw the cover (Fig 2A).
2. Please screw out the cover at the back of car by screwdriver, open the cover as the arrow showed, insert 1pc of 4. 8V AA rechargeable battery, then screw the cover (Fig 2B).




Notice: This product shall be charged for two to three hours. The supporting USB charger shall not be used for other devices other than this product.

3 2.4GHz Auto-matching

1. After installing the batteries of tractor and remote controller, turn on the switch of both. The indicator of remote controller and the front lights of tractor would be flashing slowly, and then at a state of auto-matching. When the tractor with a sound of DI-DI, it means the auto-matching is successful.
2. One remote controller can only match with one tractor. After the success of matching, there is non-interference of each tractor.
3. If the remote controller could not find out the 2.4G signal of the tractor in 1minute, it would turn in a sleeping state(light off of the indicator). To press any key to activate.
4. To remake a pair with other tractor or remote controllers, please turn off the power of both.

4 Basic operation and functions

Installation Diagram



Basic operation and functions

Forward		
Backward		
Left		
Right		
Hopper Up		
Hopper Down		

5 Advanced features

1. Auto-OFF:

- After starting, the truck would automatically shut down without receiving any signal in 60 seconds. To reactivate by pressing any keys.

2. Multi-playing Function

- Products could be played together at the same time since they are remote controlled by 2.4GHz frequency.

6 Recharging

Notice: Please turn the power switch to "OFF" position if the product will not be used for a long time. Take the batteries out of the remote controller and the truck if they will be stored for a long time.

7 Notice

1. Don't play the toy on the road, select a safe place for operating to avoid dangerous.
2. Plays the toy in water may cause short-circuit damage. Please use the dry cloth to clean the car.
3. If abnormal speed or reaction, it may be because of insufficient battery power, Please replace new batteries.
4. Please install the battery in a correct polarity.
5. Do not mix new and old batteries together, short-circuited.
6. Don't break the remote control antenna to prevent injury.

Frequency bands : 2405MHz to 2475MHz
Maximum output power : -9.55dBm For EU

Manufacturer : Doubleeagle Industry (China) Limited.
Address : Xingda Industrial Park, Chenghai District, Shantou City, Guangdong Province, China.
Importer : JAMARA e.K.
Address : Inh. Manuel Natterer
Am Lauerbühl 5 - DE-88317 Aichstetten Germany

CHOKING HAZARD-small parts, not for children under 3 years.

changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.