
USER MANUAL

1 Introduction



Item No.: E359-003 Materials: plastic and electronic components Vehicle battery: 4.8V AA rechargeable battery


Remote control battery: 2 pcs of 1.5V AA batteries (not included)




2 Installing batteries

- Remove the battery compartment door at the back of the remote control (Picture2A). Install 2 pcs of 1.5V AA batteries in the correct polarity as indicated into the battery compartment. Reinstall the battery door and fix it with the screw (Picture 2A).
- 2. Remove the battery compartment door at the back of the vehicle. Install 1 pc of 4.8V AA rechargeable battery in the correct polarity as indicated into the battery compartment. Reinstall the battery door and fix it with the screw (Picture 2B).








Notice: The vehicle battery charging time is about 3 hours. Take good care of the charging line and avoid using it with other batteries. When the USB charger is connected to the power output, the indicator light will glow. Connect the battery to the USB charger and the indicator light will start flashing indicating that the battery is being charged. Disconnect the battery from the charger once the indicator light is off (Picture 2C).

3 Pairing procedure

- 1. Install the batteries into the vehicle and the remote control. Turn on the remote control and the vehicle. The pairing procedure will start automatically. The remote control indicator light will turn off and the vehicle will emit double beep indicating that pairing procedure was successful.
- 2. The remote control can be paired only with one vehicle at once. Each set has an interference free system.
- 3. If there is no linking signal for 1 minute the remote control will automatically shut down.
- 4. To re-pair the set restart the remote control and the vehicle.

4 Operations



5 Advanced functions

- ON/OFF BUTTON: Press the on/off button after the successful matching between the vehicle and the remote control. the vehicle is ready to play.
- 2. HORN BUTTON: Press the horn button and the vehicle will emit simulated horn sound.
- 3. DEMO FUNCTION: To press the demo key, the car could operate a series of the functions automatically; to exit this function through pressing any key.

6 Recharging

Notice: Always turn off the set and remove the batteries when the vehicle is not in use and when it is being stored. The vehicle battery charging time is about 2 hours. Do not charge more than 8 hours.

7 Notice

- 1. Do not drive on roads or areas used by real vehicles. Choose safe operating areas.
- 2. Do not drive in rain, snow, wetness or sand. Use dry cloth to clean the vehicle.
- 3. If the speed slows down or the vehicle does not properly turn right or left, please re-charge the battery.
- 4. The batteries should be charged under direct supervision of and adult. Please use only recommended batteries.
- 5. Pay attention to the battery polarity.
- 6. Avoid using old and new batteries together.
- 7. Please, charge the battery before initial use.
- 8. Regularly inspect the cable, plug, casing and other parts for damages. Do not use damaged batteries or charging lines.
- 9. Connect the battery only with the regular 5V USB chargers.

Frequency bands: 2405MHz to 2475MHz

Maximum output power: -3.52dBm (for EU compliance)

Manufacturer: Doubleeagle Industry(China)Limited.

Address: Xingda Industrial Park, Chenghai

District, Shantou City, Guangdong Province, China.

Importer: JAMARA e.K.

Address: Inh .Manu el Natterer

Am Lauerbuhl5-DE-88317 Aichstetten Germany CHOKING HAZARD-small parts, not for children under 3 years.

changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -- Reorient or relocate the receiving antenna.
- -- Increase the separation between the equipment and receiver.
- --- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.