


USER MANUAL


1 Introduction

Item No.: E569-003  
Materials: plastic and electronic components  
Vehicle battery: 4.8V AA rechargeable battery  
Remote control battery: 2 pcs of 1.5V AA batteries (not included)



2 Installing batteries


- 1. Remove the battery compartment door at the back of the remote control (Picture2A). Install 2 pcs of 1.5V AA batteries in the correct polarity as indicated into the battery compartment. Reinstall the battery door and fix it with the screw (Picture 2A).
- 2. Remove the battery compartment door at the back of the vehicle. Install 1 pc of 4.8V AA rechargeable battery in the correct polarity as indicated into the battery compartment. Reinstall the battery door and fix it with the screw (Picture 2B).



Notice: The vehicle battery charging time is about 3 hours. Take good care of the charging line and avoid using it with other batteries. When the USB charger is connected to the power output, the indicator light will glow. Connect the battery to the USB charger and the indicator light will start flashing indicating that the battery is being charged. Disconnect the battery from the charger once the indicator light is off (Picture 2C).

4 Operations

- 1. **On/Off button**
  - Press the on/off button after the successful matching between the vehicle and the remote control. The vehicle is ready to play (Picture 4A).
- 2. **Horn button**
  - Press the Horn/Mute button and the vehicle will emit simulated horn sound.



3. Forward/Backward


- Push left stick (throttle) forward/backward and the vehicle will go forward/backward (Picture 4B).

4. Left/Right

- Push right stick left/right and the vehicle will turn left/right (Picture 4C).

5. Loading/Unloading button

- After starting, press the Up (Down) of Hook, the bucket would be rise (falled) slowly; at the same time, the front and back lights would be lighted on with the mechanical sound. There would be the TATA sound at the zenith or nadir for clutch protection.(picture 4D)



5 Additional features

1. Interference free system

- The interference free system allows multiple sets to be used in one area without interference.

2. Mute button

- Long press on the Horn button will mute all sounds emitted by the vehicle.

3. Demo button

- To press the Demo button, the car could operate a series of the functions automatically; to exit function through pressing any key.

4. Auto off

- After turning on the controller by 60 sec. y signal from the remote

5. Multi-playing fun

- The product is remo y players.

6 Recharging

Notice: Always turn off the vehicle and when it is being recharged, the vehicle should not be used for more than 8 hours.

7 Notice

- 1. Do not drive on roads or areas used by real vehicles. Choose safe operating areas.
- 2. Do not drive in rain, snow, wetness or sand. Use dry cloth to clean the vehicle.
- 3. If the speed slows down or the vehicle does not properly turn right or left, please re-charge the battery.
- 4. The batteries should be charged under direct supervision of an adult. Please use only recommended batteries.
- 5. Pay attention to the battery polarity.
- 6. Avoid using old and new batteries together.
- 7. Please, charge the battery before initial use.
- 8. Regularly inspect the cable, plug, casing and other parts for damages. Do not use damaged batteries or charging lines.
- 9. Connect the battery only with the regular 5V USB chargers.

Frequency bands : 2405MHz to 2475MHz  
Maximum output power : -8.57dBm (Declaration for Europe)

Manufacturer : Doubleeagle Industry (China) Limited.  
Address : Xingda Industrial Park, Chenghai District, Shantou City, Guangdong Province, China.  
Importer : JAMARA e.K.  
Address : Inh. Manuel Natterer  
Am Lauerbühl 5 - DE-88317 Aichstetten Germany

CHOKING HAZARD-small parts, not for children under 3 years.

changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

**This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.**