


# USER MANUAL





## 1 Main Parameters

Item No. : E571-003  
Material: plastic and electronic components  
Batteries: Car battery: 1pc of 3.6V AA rechargeable battery  
Remote controller battery: 2pcs of 1.5V AA batteries



## 2 Battery Installation



1. Open the battery cover of remote controller as the Fig 2A showed, inserts 2pcs of 1.5V AA batteries and then screws the cover.
2. Open the cover under the truck by screwdriver, inserts 1pc of 3.6V AA rechargeable battery as the correct polarity, and then screw the cover. (Fig 2B)



Notice: USB charging time is about 3 to 4 hours.

## 3 2.4G Auto Coding

1. After installing the batteries of truck and remote controller, open the remote controller switch. The light at the front end of the remote controller's indicator will flicker slowly and then automatically code, meaning the automatic encoding succeeds.
2. One remote controller only could code one car. After the success of coding, there is non-interference of each car.
3. If the remote controller could not find out the 2.4G signal of the car in 1 minute, it would turn in a sleeping state (light off of the indicator). To press any key to activate.
4. To remake a pair with other cars or remote controllers after turning off the power of both.



## 4 Basic Operation and Functions

1. Forward/backward: To push the Left Trigger ahead/back, the truck would go forward/backward. (Fig 4B)
2. Turn Left/Right: To push the Left Trigger forward/backward, and Right Trigger turns left/right, the truck would turn left/right. (Fig 4C)
3. Excavating: press the key of "Excavating" after starting the car, the car will do a motion. (Fig 4D)

4. Unloading: press the key of "Unloading" after starting the car, excavator will do a motion. (Fig 4D)
5. Left/Right Rotation: press the key of "Left(or Right) Rotation", excavator will do a motion of left (or right) rotation. (Fig 4E)

Auto-OFF: after starting the excavator, the car will automatically shut down without receiving any controlling signal in 60 seconds. then all the functions are at a status of standby.

## 5 Notice

1. Don't play the toy on the road, select a safe place for operating to avoid dangerous.
2. Plays the toy in water may cause short circuit damage. Please use the dry cloth to clean the car.
3. If abnormal speed or reaction, it may be because of insufficient battery power, please charge the battery.
4. The batteries should be charged under adult supervision. Please use the batteries recommended.
5. Please install the battery in a correct polarity.
6. Do not mix new and old batteries together, short-circuited.
7. Please charge the battery before initial use.
8. Please check the plug case and other units of charger regularly to make sure that it is not broken. Don't use again if you find abnormality of the charger.
9. Please do not connect the product to different performance power.

**CHOKING HAZARD**-small parts, not for children under 3 years.


Specifications colors and contents may vary from illustrations.

Frequency bands : 2402MHz to 2480MHz  
Maximum output power : -9.96dBm (for EU compliance)

Manufacturer : Doubleeagle Industry (China) Limited.  
Address : Xingda Industrial Park, Chenghai District, Shantou City, Guangdong Province, China.

Importer : JAMARA e.K.  
Address : Inh. Manuel Natterer  
Am Lauerbühl 5 - DE-88317 Aichstetten Germany

changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.  
This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.



If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.