

 \mathbf{x}

BOOMPODS

music . anywhere . everywhere

User Manual

8 (*E*

🛞 Bluetooth wireless airpods

Keep away from high temperature or prolonged exposure to direct sunlight.

Your **BOOM**PODS[™]product is guaranteed against any defects in material or

workmanship for one full year from the date of original purchase providing it has not been disassembled and it has not suffered accidental damage such as a knock

The device must be used in accordance with the user manual. The warranty is subject to presentation of the original invoice or receipt from the retailer and does not

apply to normal wear and tear or to any device that has been misused or tampered

with. It should be returned to the local service centre, the service centre will not

Please check www.boompods.com for your local service centre.

Do not insert any conductive objects into the sound box.

General guidelines:

Do not disassemble. Do not drop the product.

Warranty

Avoid contact with liquids.


Keep out of reach of children.

or immersion in water, etc.

bear any shipping cost of the returned item.

Introduction:

Before using your wireless Airpods for the first time, please take a few moments to read through the user manual.



1-On/Off/Pair mode 2-Press & hold - Volume down/Quickly press - previous song 3-Play/Pause 4-Press & hold - Volume up/Quickly press - next song 5-LED 6-Microphone 7-Micro USB charging

Bluetooth operation:

1. Activate your phone's Bluetooth function and enter its searching mode.

2. Press & hold the on/off button (1) on your Airpods until the LED (5) flashes red & blue - this will activate the pairing mode. Please note the pairing will take approx. 10 seconds Your mobile phone will automatically find a new Bluetooth device called "airpods". Connect to this device and wait until the LED (5) has turned to a slow flashing blue. This indicates that your Airpods are now successfully connected.

4. Please adjust the sound to a moderate volume and enjoy your music.

5. To switch off your Airpods, press and hold the on/off button (1) until the LED (5) turns red then release the button.

Receiving incoming calls:

When receiving an incoming call, your music track will pause & you will be able to hear your regular mobile ringtone. To accept the call, press the on/off button (1) once. To reject the call press twice. Once the call is finished, your track will start again automatically.

Wired operation:

You can use your Airpods as a wired headphone to increase battery life. Simply switch off your Airpods and then connect the 3.5mm line-in cable to your audio source and the Micro USB end to your Airpods (7).

Charging:

To charge, simply connect the USB cable end directly to a PC, laptop or mains USB & the Micro USB end to your Airpods (7). The LED light on your headpods will turn red whilst charging and turn off when fully charged. Please note whilst charging, you will not be able to use your Airpods in play mode.

Package contents:

1x wireless airpods stereo headset 1x Micro USB/USB cable 1x 3.5mm audio/ Micro USB cable 1x Travel bag 1x User manual

Technical details:

- Battery capacity:250mAh 3.7V Operating time:10 hours Charge time:2-3 hours
- Bluetooth range: 10m
- Standby time 30 hours Bluetooth: 4.0 CSR

BOOMPODS[®] www.boompods.com

Federal Communications Commission (FCC) Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Warning: Changes or modifications made to this device not expressly approved by **iLike Electronics Co.,Ltd.** may void the FCC authorization to operate this device.

Note: The manufacturer is not responsible for any radio or tv interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.