

T)APP

Smart Connected Home

Setup Guide



) Features



APP Controlled

Supports iOS/Android Use up to 4 devices simultaneously



Standard Socket

Fits most standard light sockets



Contrast Control

Create the perfect mood & ambiance with white bulbs & starter kit



Wi-Fi Controlled

Allows flexible remote access from anywhere



Brightness

Control dimming functions from your devices



Multi Color

Customize up to 16 million colors with RGB bulbs & starter kit



lıme

Automate your settings to conveniently fit your schedule



Eco-friendly

Helps conserve and reduce energy usage



Energy Saving

Lifetime electricity savings up to \$250.00 over incandescent bulbs



Anti-Theft

Safe guard your home while away

For more information, please visit our website:

www.mytapplife.com

Table of Contents

1	1)	Package Contents
2))	Setup
3))	Bulb Installation
4))	Pairing
5))	Download & Connect
		Bulb Intro
		Finding Bulbs
		All Control
		Naming Bulbs
		Brightness
		Color
		Timer
		Groups
		Scenes
		Warranty12

Thank you for choosing the HYPE TAPP lifestyle product. All HYPE TAPP products are designed and manufactured according to the highest standards of quality.

Updates to product, packaging, manual and contents may happen without written notice at the manufacturer's discretion. We do this in order to resolve bugs and to provide you with the most updated product at the best quality that we can. Our most updated manuals and Apps can be found on our website. Feel free to visit us at any time on the App Store or at www.mytapplife.com.

1) Package Contents



Ethernet cable



USB power cable



Adapter





TAPP Gateway



TAPP Light bulbs

2) Setup



Plug adapter into wall outlet and USB cable into adapter








Connect other end of USB cable to TAPP Gateway

Connect TAPP Gateway to Wi-Fi router via

ethernet cable



Note: Hold "Pair" button for 8 seconds to reset TAPP gateway.

5)) Download + Connect





- Download free app HYPE TAPP from App Store
- Connect to your personal home network and open TAPP app on your device

6) Bulb Introduction



- Serial #s of each bulb appear under each bulb icon
- ldentify which
 bulbs are
 RGB color bulbs &
 which are white bulbs

7) Finding Bulbs

- Click on a bulb to enter the bulb's control menu
- Click "Find Me."
 The bulb will
 begin to flash.
- Once located, click "Find Me" again and the bulb will stop flashing.
-)) Proceed to change bulb settings.



8) All Control

To switch on all bulbs, simply press "Open All" from the home screen.



To switch off all bulbs, simply press "Close All" from the home screen.



9) Naming Bulbs








The "Brightness" menu is the first menu that appears at the top of the bulb control menu.

It is available for both RGB and white bulbs.






- Slide your finger clockwise along the wheel to brighten bulb.
- Slide your finger counter-clockwise along the wheel to dim bulb.
- The center power button lets you easily turn your bulb on/off as desired.
- If you have selected a white bulb to adjust brightness, the wheel slider will be white.
- lf you have selected an RGB color bulb to adjust brightness, the wheel slider will reflect the color you have chosen for that bulb.

11) Color



The "Color" menu is the second menu that appears at the top of the bulb control menu.

It is only available for RGB color bulbs.



- Bulb color can be chosen from the color wheel provided, or by one of the preset options in the color blocks below.
- Color saturation of a bulb can be adjusted by sliding the grey bar from dark to light on the bottom.






The "Timer" menu is the third menu that appears at the top of the bulb control menu.

It is available for both RGB and white bulbs.

Color

Timer

Bright



Delete

- Choose a day of the week you would like the bulb to repeat the action you are setting on the timer. If you would not like it to repeat, do not select a day.
- Select a color you would like your RGB bulb to set itself to when the timer goes off.

Please note, if you are setting a timer with white bulbs, you can set bulb brightness only.

- Select a timer type:
 Normal turns bulb on/off
 Gradual slowly fades bulb on/off
 Flicker bulb flickers
 - Select action type: Open - turns bulb on Close - turns bulb off
- Set the time of your timer.
- Press "Save" at top right to save your timer.
- If you are editing a timer on an existing bulb, you can edit any of the mentioned action types, times, repeat settings, etc. To delete your timer, press "Delete" at the bottom of the page.



Your "Timer" menu will show you the summary of the timer you have set.

You can set more than one timer for each bulb.

Press the "Back" button to return to your Lamp page.

On your Lamp page, a small alarm clock icon will appear next to bulbs that have timers.





- Select bulb type from top menu in order to group bulbs together.
-)) Color bulbs, warm bulbs, white bulbs, & plugs will automatically be separated for easy grouping.



) If you have not renamed your bulbs, they will appear by their serial number.



14) Scenes



Select NEW to add custom scene





Select a bulb or group.

Adjust timer, color, brightness





Select Color

Select Brightness




Preset or custom Scenes can be adjusted by pressing the setting gear to the right of each scene.



- After making desired adjustments to a preset scene or a custom-made scene, make sure you save.
- As you select a scene, the bulbs chosen for the scene will automatically change to the preset or custom scene.
- Adjust color, brightness and timer as desired.
- Save when complete.

Thank you for choosing the HYPE TAPP lifestyle product. All HYPE TAPP products are designed and manufactured according to the highest standards of quality.



For a period of three years from the date of purchase HYPE guarantees that your products will remain free of manufacturing faults in relation to materials or workmanship, as long as the products are used for its intended purpose.

The condition of this warranty and our responsibilities under this warranty are as follows:

Supplier's warranty is non-transferable and is limited to the original purchaser only.

- * You must be able to prove the date of original purchase of the unit with a dated receipt.
- * The warranty is not applicable if the product has been subject to physical abuse, improper installation, modification or repair by unauthorized third party.
- * The responsibility of supplier's products shall be limited to the repair of replacement of the product at its sole discretion.
- * Specifically exempt from any warranty are limited-life consumable components subject to normal wear and tear such as batteries, decorations and other accessories.
- * A supplier will not take any responsibility if the failure of the unit has resulted from accident, abuse, misuse, or any unauthorized repair, modification or disassemble.
- * Modification and repair of the unit should be done by authorized and qualified service personnel, service center or returned to the manufacturer.
- * This warranty gives you specific legal rights, and you may also have other rights which vary under local laws.

The following conditions comprise the requirements and scope of our warranty conditions and do not affect our legal and contractual warranty obligations. We offer a warranty on our products in accordance with the following conditions:

- 1) Hype[™] products are covered by a 12 month warranty. We will resolve damages or defects on Hype[™] products free of charge within 12 months of the purchase date under the following warranty conditions. For any damage or defect determined later than 12 months after the purchase date, proof of a manufacturing fault must be submitted for repair under warranty.
- 2) The warranty does not cover batteries and other parts, which are considered consumables, parts that break easily such as glass or plastic or defects based on normal wear and tear. There is no warranty obligation in the event of marginal differences compared to the target appearance and workmanship provided these have a negligible effect on the product's fitness for use, in the event of damage caused by chemical or electrochemical effects, by water or generally from abnormal conditions.
- 3) The warranty will be performed in such a way that we shall decide whether to repair the defective parts or to replace them with working parts free of charge. Hype™ reserves the right to exchange the product for a replacement product of equal value if the product sent in cannot be repaired within a reasonable time or at a reasonable cost. Requests cannot be made for repairs to be carried out on site. Parts that have been replaced or exchanged become our property.
- 4) The warranty claim does not apply if repairs or other work is carried out by unauthorized persons or if our products are equipped with additional parts or accessories that are not approved for our product.
- 5) Warranties that have been activated do not cause the warranty period to be extended, nor do they trigger a new warranty period. The warranty period for any replacement parts installed ends with the warranty period for the entire product.
- 6) Any other further claims are excluded, especially those for replacement due to damage caused to the outside of the product, provided there is no obligatory legal liability. We therefore accept no liability for accidental, indirect or other consequential damage of any kind, which leads to usage restrictions, data loss, and loss of earnings or interruption to business.

Asserting a warranty claim:

 To make use of the warranty service for hardware issues, you must contact the Hype™ Service Center by email at support@dqlusa.com 2) Hype™ will try to diagnose and solve your problem. If it is determined that a warranty claim exists, you will be given an RMA number (Return Material Authorization) and will be asked to send the product to Hype™.

IMPORTANT: Hype™ will only accept parcels that have an RMA number.

Please observe the following when sending the product:

- 1) Send the product suitably packaged with carriage and insurance paid. Do not enclose any accessories with the product (cables, chargers, manuals, etc.) unless the Hype™ Service Center specifies otherwise.
- 2) Mark the RMA number on the outside of the package in such a way that it is visible and clearly legible.
- You must enclose a copy of the sales slip as proof of purchase.
- Once Hype[™] has received the product, it will meet its warranty obligations in accordance with the warranty conditions and will return the product to the sender with carriage and insurance paid.

Service outside of warranty

Hype[™] can refuse any service claim made that is not covered by the warranty.

If Hype™ agrees to provide a service outside the warranty, the customer will be invoiced for all repair and transport costs. Hype™ will not accept any packages that have not first been approved by Hype™ by means of an RMA (Return Material Authorization).

For more information or technical support, please visit our website

www.mytapplife.com or contact

our customer service department at:

support@mytapplife.com

FCC STATEMENT

FLC STATEMENT This general trains are stated and found to comply with the limits for a Class B digital device. This equipment to be left of the ECE May are stated to the state of the ECE May are stated to the state of the ECE May are stated to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can raided raided frequency energy and, if not restaled and used in accordance with the instructions, may cause harmful interference to "raide" installation. If this equipment does could harmful interference to raid or television reception, which can be determined by turing the equipment off and or the uses in second great for the correct the statement of the state

Reorient or relocate the receiving antenna.
 Increase the separation between the equipment and receiver.
 Connect the equipment into an outlet on a circuit different from that to which the receiver is

connected.

—Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator 6 your body.

FCC NOTICE

measures:

device complies with Part 15 of the FCC rules . Operation is subject to the following two

(1) This device may not cause harmful interference; and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC CAUTION

Caution the user that changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Pair with additional TAPP lifestyle products



Smart APP Connected TAPP Outlet Control home electronics from anywhere.



Colored LED TAPP Bulb Creates white and colored smart lighting



White LED TAPP Bulb Creates white smart lighting.

For more information, please visit our website: www.mytapplife.com