

live love music™ FLY true wireless earbuds quick start guide



Touch control area

CHARGING YOUR EARBUDS

- ⚡ Charge the earbuds before using for the first time.
- 🕒 Charge the earbuds in the case for about 1 hour.
- 🎵 If you hear a long beep, the earbuds need to be charged.

MUSIC CONTROLS

- Tap earbud once to pause your music.
- Previous Song: Tap the left earbud 2x
- Next Song: Tap the right earbud 2x
- Volume Up: Tap the right earbud 3x
- Volume Down: Tap the left earbud 3x

USING YOUR EARBUDS FOR CALLS

- Tap either earbud once to answer or end call.
- Tap and hold either earbud to reject a call.

USING YOUR EARBUDS

Your earbuds will work best if it is within 30 ft. of your smart device. You may experience the sound briefly cutting off if you are out of range or if your wireless connection is weak.



Take the earbuds out of the charging case and they will automatically turn on and pair with each other.

Turn on Bluetooth® on your phone or tablet. Choose "FB-WECC". You're paired!

CONNECTION LOST?

- If only one earbud is working, press the other earbud for 3 seconds to reconnect.
 - If pairing two earbuds does not work, turn off the earbuds and repeat the steps again in "Using earbuds as a pair".
 - Make sure your earbuds are within range of your smart device.
 - If you hear a long beep, you need to recharge your earbuds.
- Connection may be lost due to low battery.

live love music™ FLY true wireless earbuds quick start guide

SPECIFICATIONS

Earbud Battery: 30mAh x 2
Battery Type: Lithium Polymer
Case Battery: 300 mAh
Play Time: Up to 3-5 hrs
Charge Time: Up to 2 hrs
Charging voltage: DC5V
Operating temperature range: 0-45 °C
BT ID: D044460
FCC ID: 2AANZWECC

TMA warning:

1. Tma: User use ambient temperature
2. No power protection device at the input.
3. Caution :
 - a) PCB of battery should not be crushed and twisted.
 - b) Cell body should not be blended.
 - c) Do not disassemble and Do not dispose of in fire.

DGL Group, Ltd.
2045 Lincoln Highway, 3rd Floor, Edison, NJ, 08817, USA.
www.dglusa.com

FCC STATEMENT

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates use and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
 - Increase the separation between the equipment and receiver.
 - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 - Consult the dealer or an experienced radio/TV technician for help
- Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

RF WARNING STATEMENT

The device has been evaluated to meet general RF exposure requirement.
The device can be used in portable exposure condition without restriction.