


TOUCH



Installation Instructions

1


Turn off power from the circuit breaker for the switch you are replacing.



Tip: Flip the switch you are replacing to confirm the power is off.

2

Remove the existing wall plate by removing the small screws located at the top and bottom of the wall plate.



Tip: Tape the small screws to the back of the removed wall plate for safe keeping.

3


Remove the screws that attach the bare switch to the wall box.



Tip: Use your smart phone or digital camera to take a picture of the wires before detaching.

4


Pull out the bare switch as much as the wires will allow. Identify the load, line and neutral wires. Detach bare switch.



Tip: STOP if neutral wire is not present. TOUCH is not compatible with your wiring.

5

Connect your TOUCH with the wire nuts provided by placing the exposed end of the wires into the wire nut and twisting.



Tip: Check all wires to be sure they are secure in the wire nut.

6

Push all wires back into the wall box. Attach your TOUCH to the wall box with screws provided. Snap the wall plate into place.



Tip: Do not use metal wall plates as they can interfere with the Wi-Fi signal.

7

Complete this step in order to control your TOUCH light switch from your tablet, smartphone or PC.

Go to:
www.sierralingo.com/touch/wifiinstall
Follow instructions to connect your TOUCH to your home Wi-Fi network.

Tip: Enjoy your TOUCH light switch!

FCC Caution.

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:
1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

WARNING!

THIS IS AN ELECTRICAL SHOCK HAZARD. Incorrect installation could be dangerous. Call a professional electrician if you are uncomfortable or unfamiliar with electrical work.

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure guidelines. This equipment should be installed and operated with minimum distance 20cm between the radiator& your body.