


amazon
basics

Instruction Manual • English

AmazonBasics Bluetooth® Speaker

Quick Setup Guide



BT V 3


B00GUTY132

Setup

Your speaker is partially charged when it arrive so you can use it right away. For the best reception, keep the speaker within 30 feet of the device it's paired to.

Pairing the speaker and a device

- Turn ON the speaker. A tone sounds and the LED blinks.
- Turn ON your device (like a phone or tablet).
- On your device, locate your Bluetooth settings and turn on Bluetooth.
- In Bluetooth Settings, scan for devices if necessary, then select **Amazon BT3** from your device's list. The LED stops blinking and light blue. Your device and speaker are paired and your speaker is ready to use.



Pairing another device

- Disconnect from the previous device by pressing and holding the function button. A tone sounds and the LED blinks.
- Repeat the Pair the device steps for your next device.

Note: You can pair multiple devices but you can only have one device actively paired at a time.

Reconnecting a previously paired device

- Disconnect from any other device by pressing and holding the function button. A tone sounds and the LED blinks.
- If the speaker doesn't automatically find the device you want paired (indicated by the LED blinking blue), go to your device settings and ensure that Bluetooth is still ON, then select **Amazon BT3**. The speaker and device re-pair.

Play music

- Start playing music on your paired device. You will hear the music through the speaker.
- On the speaker, press + or – to increase or decrease the volume
- During music playing, you can simply press the function button to act as play/pause function.

Use as a speakerphone

You can listen through the speaker and speak through the speaker's microphone during phone calls. Position the speaker about 2 feet away and speak normally.


If you make a call while paired:


The audio and microphone automatically default to the speaker.

- Use your phone to make the call
- Press the call-divert  button to end the call

If you received a call while paired:

Your phone rings through the speakerphone.

To listen and speak through the speakerphone, press the call-divert  button to answer the call.

- Press the call-divert  button to end the call.
- During the phone rings through the speakerphone, you can also select press and hold the function button for 2 sec to reject the call.

Call-divert function

After you receive your call by using the Amazon_BT3, if you want to transfer your listening and speaker of the call from the Amazon_BT3 back to the mobile device,


*Press and hold the call-divert button for 2 sec.

*Then, you can use your phone to answer and listen to the call.

Connect with an audio cable

Connect a 3.5mm audio cable (not included) from the speaker's AUX jack to your audio device (like an MP3 player).

Note: When connected to AUX, please disconnect from Bluetooth, use the controls on the device instead of the speaker.




Charge the speaker

After turn on the speaker, when the battery is low the speaker's LED flashes red. If not charged, the speaker shuts off.

To charge the speaker, connect the USB charging cable to the charging port and an available USB port on your computer.

If the speaker is ON, the Red LED will "Flash" when charging.
If the speaker is OFF, the Red LED will "Flash" while charging,
and Red LED keep solid when fully charged.

Remark: Please aware that the Blue LED is in ON/flashes status when the speaker is "ON". So, there will have Blue and Red overlap lighting effect when you charging a "ON" speaker.



Safety and Compliance

WARNING: To reduce the risk of fire or electrical shock, do not expose the system to rain or moisture.



FCC Information

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance.

May cause interference and void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This device complies with FCC radiation exposure limits set forth for an uncontrolled environment.

PRODUCT DISPOSAL INFORMATION

Dispose of this product in accordance with Local and National Disposal Regulations.



WEEE

Regulatory Information: Disposal of Waste Electrical and Electronic Equipment (WEEE)
The Waste Electrical and Electronic Equipment (WEEE) Directive aims to minimize the impact of electrical and electronic equipment going to landfill. The symbol on this product or its packaging signifies that this product must be disposed separately from ordinary household wastes at its end of life. Be aware that this is your responsibility to dispose of electronic equipment at recycling centers in order to help conserve natural resources.

Each country should have its collection centers for electrical and electronic equipment recycling. For information about your recycling drop off area, please contact your related electrical and electronic equipment waste management authority, your local city office, or your household waste disposal service.