DO NOT PRINT COMMENTS

MERKURY

MERKURY INNOVATIONS CONFIDENTIAL

FILE INFORMATION

DATE: 03/03/21

MODEL NUMBER: MI-E048T-SERIES

PRINTER SPECIFICATIONS

FILE NAME: MI-E048T-SERIES_Manual_030321_REV.ai SCALE: 100%

SIZE: Trim: W 186mm x H 144mm PAPER STOCK: 80g Art Paper

FINISH: PP Matte Varnish Coating

INKS: 1/0

Greyscale

PRESS WORK / NOTES: Trim to size, score, fold, & glue in specified areas.

---- Score

DO NOT print Comments or Dielines.

Physical sample according to specs must be approved by MERKURY before proceeding to production.

CONTACT

MERKURY CHINA:

perry@merkuryinnovations.com.cn

COMMENTS (Internal reference only)

File created by GEORGE

- Please include this manual in all packaging for MI-E048T-SERIES
- Greyscale
- Double sided printing

MANUAL

Troubleshooting

Music is not playing

Bluetooth device will

not reconnect with

Recharge your earbuds using the included micro USB cable. Try using a different micro USB cable.

Check if both devices are paired and connected over Bluetooth. Restart the earbuds to reconnect your

Navigate to your Bluetooth® settings menu on your Bluetooth device, tap "Merkury E048T", and select "Forget". Now follow the steps to pair your

Battery Information: Built-in Battery: Lithium

Capacity: 400mAh

Specifications: Frequency Response: 20Hz to 20KHz Driver Size: 13mm

Bluetooth Information: Bluetooth Specification: V5.0 Operating Distance: 30 ft. System Requirements: Bluetooth-capable device

*Approximate Playback time depends on individual use

Additional Connection Sources: Power Source: Built-in rechargeable battery or via USB cable

Music playing time: App. 3 Hours* Charging time: 2 hours

This device complies with Part 15 of the FCC Rules. Operation is subject to the two following conditions: 1. This device may not cause harmful interference

2. This device must accept any interference received, including interference

Please do not attempt to fix the product by yourself. If you are experiencing any problems with the product, please do not return it to the store you bought it from. You can contact our technical support representatives and they wi∎ assist you with any questions you might have.

For assistance operating your product, please consult the User's Manual first, then feel free to contact Merkury Innovations technical support:

Merkury Innovations 45 Broadway, 3rd Floor New York, New York 10006

E-mail: support@merkuryinnovations.com

©2021 Merkury Innovations, LLC.

To explore our full selection of products, visit us at: www.merkuryinnovations.com

The Bluetooth wordmark and logo are registered trademarks owned by Bluetooth SIG, Inc. The illustrated product and specifications may differ slightly from those supplied. All other trademarks and trade names are those of their respective owners.

Made in China

MERKURY







User's Manual for MI-F048T

True Wireless Earbuds | Charging Case | Micro USB Charging Cable

IMPORTANT Please read before using this product

EARBUDS
 Checking the "R" and "L" indicators on the charging case, place the right and left earbuds into the corresponding slots so that the magnetic metal charging contacts line-up correctly.

Charge It

- The LED indicators on the earbuds will glow red and the charging indicators on the case will glow blue. Your earbuds are now charging.
- Once your earbuds are fully charged the LED indicators will turn off.

- ne case is charging, the led light will slowly flash red. When charge is complete, the red Il turn solid.
- Note: the case can charge the earbuds while charging itself.

Pair & Connect with a New Device

- POLARIS will turn on automatically once it is removed from charging case.
 It will blink alternately red and blue indicating that it is in pairing mode.
- Open the Bluetooth® menu on your smartphone and search for new devices • When you see "Merkury E048T" listed, tap it to connect.
- Once connected with your device, there will be a BEEP from the earbuds.


Reconnect to Bluetooth®

- \bullet You only need to pair your Bluetooth $\!\!^{\otimes}\!\!$ device with these earbuds once.
- With your device's Bluetooth[®] feature turned on and in range, power on the left
- & right earbuds. • They will automatically connect to each other and to your smartphone.
- If you have a previously paired device that does not auto-reconnect, navigate to the Bluetooth® settings menu on your device and select "Merkury E048T" from the list of paired Bluetooth® devices.

Play


- Connect your device to the earbuds via Bluetooth® (see "Pair & Connect with a New Device." Open your favorite music app and press play.
- Control the music tracks and volume from your device or from the on-ear controls
- on the earbuds. Press the button once to play/pause music & answer calls.
- . All audio, including music, games, videos, and notifications will be routed through the earbuds.

TRUE WIRELESS EARBUDS



CHARGING CASE (BACK)


CHARGING CASE (TOP)



2 LED Charging Indicator Light

4 Charging Connectors 6 Charging Input

6 LED Charging Indicator Light Charging Connectors



Multi-Function Power Button

OUTSIDE

GUIDE FOR NEW DEVICES POLARIS will turn on automatically once it is removed from charging case. It will blink alternately red and blue indicating that it is in pairing mode.

QUICK PAIRING

- 2. On your smartphone open the Bluetooth® menu, power on your Bluetooth® setting and search for new devices. 3. When you see Merkury E048T listed, tap it to
- 4. Once connected with your device, there will be a BEEP from the right earbud.
- **Note:** If your device asks for a passcode to connect, enter "0000".

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates

uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this

equipment does cause harmful interference to radio or television reception. which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following

- -- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -- Consult the dealer or an experienced radio/TV technician for help This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1)this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.