# Specifications:

Speaker Specification: 40 MM x 3 W Frequency Response: 60 Hz-18 KHz

Sensitivity: 80+-2db Distortion: 0.5% Bluetooth® v3.0 EDR

Bluetooth® Communication Protocol: Support Advanced Audio Transition

Mode (A2DP) v1.2

Bluetooth® Communication Range: 10 M depending on surroundings.

Charging Time: 3 hours for full charge.

## **Operational Instructions:**

Buttons:

- ON/OFF: Power Key
- Play/Pause: In Bluetooth mode, answer/hang up incoming calls. In Music mode, play/pause.
- Volume Down/Previous: Long press decreases volume. Short press switches to previous song.
- Volume Up/Next: Long press increases volume. Short press switches to next song.

# **Getting Started:**

Pairing the speaker with your device:

- Switch the speaker on, enter Bluetooth mode, the blue indicator will flash, and you will hear a voice prompt, "The Bluetooth device is ready to pair."
- Enable smartphone, computer or other device's Bluetooth function, and start

the search for new devices. At the name "MINI SPEAKER," the speaker will search for the device, and you will hear "The Bluetooth device is connected successfully."

• Once paired successfully, in play mode, the blue indicator flashes slowly.

#### Hands Free:

Connecting speaker with Bluetoothenabled phone: When call is received, press "" to answer/end call.


### Audio Input:

In any play mode, plug one side of the 3.5 mm jack into audio output of desired device, plug other side of jack into AUX port of Bluetooth speaker. The voice prompts "Aux in," and it will play automatically.

# How To Charge:

Charge speaker before using for the first time. Plug micro USB to Wireless Mini Speaker and the USB part to the USB port. The red charging LED light is on. After 2–3 hours fully charged, the red LED light will shut off.

RH



# **FCC Statement**

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -- Reorient or relocate the receiving antenna.
- -- Increase the separation between the equipment and receiver.
- -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.