


# Boulder Waterproof Outdoor Bluetooth Speaker

## Instruction Manual



### What's Inside:

- 1 x Waterproof Outdoor Speaker
- 1 x Instruction Manual
- 1 x USB to Micro-USB Cable
- 1 x 3.5mm Audio Cable

### WARNING:

Read Instruction Manual completely before using the Boulder Waterproof Outdoor Bluetooth Speaker. Do not disassemble, crush, open etc. for risk of fire or burns. If internal mechanisms are exposed do not attempt fixing, seek professional assistance.

1

### 1 Charging the Boulder Waterproof Outdoor Bluetooth Speaker prior to initial use:

- Plug the Micro-USB cable into the port located on the speaker.
- Plug the opposite USB end into the USB part of a computer or compatible AC wall adapter.
- The Red LED turned on to indicate that the speaker is charging.
- Once the Boulder Bluetooth Speaker is fully charged, the LED turns off.

### 2 Pairing with the Boulder Waterproof Outdoor Bluetooth Speaker:

- Turn the Boulder on by sliding the ON/OFF button to ON. A Blue LED will flash 3 times slowly, then will flash quickly to indicate Bluetooth pairing mode.
- Follow the instructions of your device you wish to pair the Boulder with and search for the speaker.
- Select "Boulder" from the list of possible pairs.
- A Blue LED light will flash slowly when pairing is complete.

### • LED indicator description:

Charging	Red LED on
Fully Charged	Red LED shuts off
Pairing Mode	Blue LED flashes fast
Connected	Blue LED on
Play-mode	Blue LED flashes slow

### • Tech Specifications:

- Rated Output Power: 3W x 2 (THD = 10%)
- Frequency Response: 120Hz-16kHz
- Driver: 1.5" x 2
- Power Supply: USB, DC 5V 500 mA
- Distortion: ≤ 0.5%
- S/N: ≥ 60dB
- Battery Capacity: 2000mAh/3.7
- Battery Play Time: Up to 5 hours
- Battery Charging Time: 5 hours
- Product Size: L 193.5 x W 37.5 x H 60 mm
- Product Weight: 400g

2

### SAFETY INSTRUCTIONS:

- Charge the device completely before first use
- Do not attempt to repair. Seek professional consultation if powerbank isn't working.
- Do not insert objects that do not belong into power bank.
- Keep out of reach of children.
- Do not use near or around water as this could result in electrocution.
- Keep away from flame.

### NOTE:

---

---

---

---

---

---

---

FC

Made in China

3

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

#### RF Exposure Statement

To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum distance between 20cm the radiator your body: Use only the supplied antenna.

The users manual or instruction manual for an intentional or unintentional radiator shall caution the user changes or modifications not expressly approved by the party responsible for compliance could void the user is authority to operate the equipment.