






PSD NVNT ac20 5825MHz Ant2




PSD NVNT ac40 5190MHz Ant1




PSD NVNT ac40 5190MHz Ant2




PSD NVNT ac40 5230MHz Ant1




PSD NVNT ac40 5230MHz Ant2



PSD NVNT ac40 5270MHz Ant1




PSD NVNT ac40 5270MHz Ant2




PSD NVNT ac40 5310MHz Ant1




PSD NVNT ac40 5310MHz Ant2




PSD NVNT ac40 5510MHz Ant1




PSD NVNT ac40 5510MHz Ant2




PSD NVNT ac40 5590MHz Ant1




PSD NVNT ac40 5590MHz Ant2




PSD NVNT ac40 5670MHz Ant1




PSD NVNT ac40 5670MHz Ant2




PSD NVNT ac40 5755MHz Ant1




PSD NVNT ac40 5755MHz Ant2




PSD NVNT ac40 5795MHz Ant1




PSD NVNT ac40 5795MHz Ant2




PSD NVNT ac80 5210MHz Ant1




PSD NVNT ac80 5210MHz Ant2




PSD NVNT ac80 5290MHz Ant1




PSD NVNT ac80 5290MHz Ant2




PSD NVNT ac80 5530MHz Ant1




PSD NVNT ac80 5530MHz Ant2




PSD NVNT ac80 5610MHz Ant1




PSD NVNT ac80 5610MHz Ant2




PSD NVNT ac80 5775MHz Ant1




PSD NVNT ac80 5775MHz Ant2




PSD NVNT n20 5180MHz Ant1




PSD NVNT n20 5180MHz Ant2




PSD NVNT n20 5200MHz Ant1




PSD NVNT n20 5200MHz Ant2




PSD NVNT n20 5240MHz Ant1




PSD NVNT n20 5240MHz Ant2




PSD NVNT n20 5260MHz Ant1




PSD NVNT n20 5260MHz Ant2




PSD NVNT n20 5280MHz Ant1




PSD NVNT n20 5280MHz Ant2




PSD NVNT n20 5320MHz Ant1




PSD NVNT n20 5320MHz Ant2




PSD NVNT n20 5500MHz Ant1




PSD NVNT n20 5500MHz Ant2




PSD NVNT n20 5600MHz Ant1




PSD NVNT n20 5600MHz Ant2




PSD NVNT n20 5700MHz Ant1




PSD NVNT n20 5700MHz Ant2




PSD NVNT n20 5745MHz Ant1




PSD NVNT n20 5745MHz Ant2




PSD NVNT n20 5785MHz Ant1




PSD NVNT n20 5785MHz Ant2




PSD NVNT n20 5825MHz Ant1




PSD NVNT n20 5825MHz Ant2




PSD NVNT n40 5190MHz Ant1




PSD NVNT n40 5190MHz Ant2




PSD NVNT n40 5230MHz Ant1




PSD NVNT n40 5230MHz Ant2




PSD NVNT n40 5270MHz Ant1




PSD NVNT n40 5270MHz Ant2




PSD NVNT n40 5310MHz Ant1




PSD NVNT n40 5310MHz Ant2




PSD NVNT n40 5510MHz Ant1




PSD NVNT n40 5510MHz Ant2




PSD NVNT n40 5590MHz Ant1




PSD NVNT n40 5590MHz Ant2




PSD NVNT n40 5670MHz Ant1




PSD NVNT n40 5670MHz Ant2



PSD NVNT n40 5755MHz Ant1




PSD NVNT n40 5755MHz Ant2



PSD NVNT n40 5795MHz Ant1



PSD NVNT n40 5795MHz Ant2




25.5 BAND EDGE


Condition	Mode	Frequency (MHz)	Antenna	Max Value (dBc)	Limit (dBc)	Verdict
NVNT	a	5180	Ant1	-41.76	-27	Pass
NVNT	a	5240	Ant1	-40.1	-27	Pass
NVNT	a	5260	Ant1	-40.22	-27	Pass
NVNT	a	5320	Ant1	-41.22	-27	Pass
NVNT	a	5500	Ant1	-43.52	-27	Pass
NVNT	a	5700	Ant1	-39.18	-27	Pass
NVNT	a	5745	Ant1	-34.21	-27	Pass
NVNT	a	5825	Ant1	-34.09	-27	Pass
NVNT	a	5180	Ant2	-41.98	-27	Pass
NVNT	a	5240	Ant2	-47.64	-27	Pass
NVNT	a	5260	Ant2	-48.69	-27	Pass
NVNT	a	5320	Ant2	-39.8	-27	Pass
NVNT	a	5500	Ant2	-40.33	-27	Pass
NVNT	a	5700	Ant2	-39.27	-27	Pass
NVNT	a	5745	Ant2	-34.09	-27	Pass
NVNT	a	5825	Ant2	-34.34	-27	Pass
NVNT	ac20	5180	Ant1	-48.41	-27	Pass
NVNT	ac20	5180	Ant2	-48.55	-27	Pass
NVNT	ac20	5240	Ant1	-47.83	-27	Pass
NVNT	ac20	5240	Ant2	-48.85	-27	Pass
NVNT	ac20	5260	Ant1	-49.37	-27	Pass
NVNT	ac20	5260	Ant2	-48.76	-27	Pass
NVNT	ac20	5320	Ant1	-47.78	-27	Pass
NVNT	ac20	5320	Ant2	-46.21	-27	Pass
NVNT	ac20	5500	Ant1	-47.77	-27	Pass
NVNT	ac20	5500	Ant2	-47.76	-27	Pass
NVNT	ac20	5700	Ant1	-46.68	-27	Pass
NVNT	ac20	5700	Ant2	-47.33	-27	Pass
NVNT	ac20	5745	Ant1	-42.02	-27	Pass
NVNT	ac20	5745	Ant2	-40.58	-27	Pass
NVNT	ac20	5825	Ant1	-43.14	-27	Pass
NVNT	ac20	5825	Ant2	-40.98	-27	Pass
NVNT	ac40	5190	Ant1	-48.26	-27	Pass
NVNT	ac40	5190	Ant2	-47.15	-27	Pass
NVNT	ac40	5230	Ant1	-47.88	-27	Pass
NVNT	ac40	5230	Ant2	-48.02	-27	Pass
NVNT	ac40	5270	Ant1	-49.65	-27	Pass
NVNT	ac40	5270	Ant2	-48.96	-27	Pass
NVNT	ac40	5310	Ant1	-47.76	-27	Pass
NVNT	ac40	5310	Ant2	-47.29	-27	Pass
NVNT	ac40	5510	Ant1	-47.24	-27	Pass
NVNT	ac40	5510	Ant2	-47.93	-27	Pass
NVNT	ac40	5670	Ant1	-46.4	-27	Pass

NVNT	ac40	5670	Ant2	-46.64	-27	Pass
NVNT	ac40	5755	Ant1	-42.72	-27	Pass
NVNT	ac40	5755	Ant2	-39.51	-27	Pass
NVNT	ac40	5795	Ant1	-43.55	-27	Pass
NVNT	ac40	5795	Ant2	-42.94	-27	Pass
NVNT	ac80	5210	Ant1	-46.46	-27	Pass
NVNT	ac80	5210	Ant2	-45.71	-27	Pass
NVNT	ac80	5290	Ant1	-48.82	-27	Fail
NVNT	ac80	5290	Ant2	-48.71	-27	Fail
NVNT	ac80	5530	Ant1	-46.73	-27	Pass
NVNT	ac80	5530	Ant2	-46.78	-27	Pass
NVNT	ac80	5610	Ant1	-47.57	-27	Pass
NVNT	ac80	5610	Ant2	-48.75	-27	Pass
NVNT	ac80	5775	Ant1	-33.95	-27	Pass
NVNT	ac80	5775	Ant2	-37.02	-27	Pass
NVNT	n20	5180	Ant1	-47.36	-27	Pass
NVNT	n20	5180	Ant2	-46.89	-27	Pass
NVNT	n20	5240	Ant1	-46.57	-27	Pass
NVNT	n20	5240	Ant2	-47.59	-27	Pass
NVNT	n20	5260	Ant1	-48.21	-27	Pass
NVNT	n20	5260	Ant2	-48.78	-27	Pass
NVNT	n20	5320	Ant1	-43.79	-27	Pass
NVNT	n20	5320	Ant2	-42.23	-27	Pass
NVNT	n20	5500	Ant1	-46.65	-27	Pass
NVNT	n20	5500	Ant2	-43.46	-27	Pass
NVNT	n20	5700	Ant1	-44.36	-27	Pass
NVNT	n20	5700	Ant2	-44.99	-27	Pass
NVNT	n20	5745	Ant1	-40.16	-27	Pass
NVNT	n20	5745	Ant2	-38.19	-27	Pass
NVNT	n20	5825	Ant1	-39.08	-27	Pass
NVNT	n20	5825	Ant2	-40.04	-27	Pass
NVNT	n40	5190	Ant1	-46.16	-27	Pass
NVNT	n40	5190	Ant2	-46.01	-27	Pass
NVNT	n40	5230	Ant1	-48.56	-27	Pass
NVNT	n40	5230	Ant2	-47.41	-27	Pass
NVNT	n40	5270	Ant1	-48.69	-27	Pass
NVNT	n40	5270	Ant2	-48.36	-27	Pass
NVNT	n40	5310	Ant1	-46.97	-27	Pass
NVNT	n40	5310	Ant2	-45.14	-27	Pass
NVNT	n40	5510	Ant1	-47.42	-27	Pass
NVNT	n40	5510	Ant2	-44.84	-27	Pass
NVNT	n40	5670	Ant1	-46.18	-27	Pass
NVNT	n40	5670	Ant2	-46.03	-27	Pass
NVNT	n40	5755	Ant1	-36.8	-27	Pass
NVNT	n40	5755	Ant2	-35.22	-27	Pass
NVNT	n40	5795	Ant1	-41.63	-27	Pass
NVNT	n40	5795	Ant2	-42.95	-27	Pass


Band Edge NVNT a 5180MHz Low Ant1




Band Edge NVNT a 5240MHz High Ant1




Band Edge NVNT a 5260MHz Low Ant1




Band Edge NVNT a 5320MHz High Ant1



Band Edge NVNT a 5500MHz Low Ant1




Band Edge NVNT a 5700MHz High Ant1




Band Edge NVNT a 5745MHz Low Ant1




Band Edge NVNT a 5825MHz High Ant1




Band Edge NVNT a 5180MHz Low Ant2




Band Edge NVNT a 5240MHz High Ant2




Band Edge NVNT a 5260MHz Low Ant2




Band Edge NVNT a 5320MHz High Ant2




Band Edge NVNT a 5500MHz Low Ant2




Band Edge NVNT a 5700MHz High Ant2




Band Edge NVNT a 5745MHz Low Ant2




Band Edge NVNT a 5825MHz High Ant2




Band Edge NVNT ac20 5180MHz Low Ant1




Band Edge NVNT ac20 5180MHz Low Ant2




Band Edge NVNT ac20 5240MHz High Ant1




Band Edge NVNT ac20 5240MHz High Ant2




Band Edge NVNT ac20 5260MHz Low Ant1




Band Edge NVNT ac20 5260MHz Low Ant2




Band Edge NVNT ac20 5320MHz High Ant1




Band Edge NVNT ac20 5320MHz High Ant2




Band Edge NVNT ac20 5500MHz Low Ant1




Band Edge NVNT ac20 5500MHz Low Ant2




Band Edge NVNT ac20 5700MHz High Ant1




Band Edge NVNT ac20 5700MHz High Ant2



Band Edge NVNT ac20 5745MHz Low Ant1




Band Edge NVNT ac20 5745MHz Low Ant2




Band Edge NVNT ac20 5825MHz High Ant1




Band Edge NVNT ac20 5825MHz High Ant2




Band Edge NVNT ac40 5190MHz Low Ant1




Band Edge NVNT ac40 5190MHz Low Ant2




Band Edge NVNT ac40 5230MHz High Ant1




Band Edge NVNT ac40 5230MHz High Ant2




Band Edge NVNT ac40 5270MHz Low Ant1




Band Edge NVNT ac40 5270MHz Low Ant2



Band Edge NVNT ac40 5310MHz High Ant1




Band Edge NVNT ac40 5310MHz High Ant2




Band Edge NVNT ac40 5510MHz Low Ant1




Band Edge NVNT ac40 5510MHz Low Ant2




Band Edge NVNT ac40 5670MHz High Ant1




Band Edge NVNT ac40 5670MHz High Ant2



Band Edge NVNT ac40 5755MHz Low Ant1



Band Edge NVNT ac40 5755MHz Low Ant2



Band Edge NVNT ac40 5795MHz High Ant1




Band Edge NVNT ac40 5795MHz High Ant2




Band Edge NVNT ac80 5210MHz Low Ant1




Band Edge NVNT ac80 5210MHz Low Ant2



Band Edge NVNT ac80 5290MHz Mid Ant1




Band Edge NVNT ac80 5290MHz Mid Ant2




Band Edge NVNT ac80 5530MHz Low Ant1




Band Edge NVNT ac80 5530MHz Low Ant2




Band Edge NVNT ac80 5610MHz High Ant1




Band Edge NVNT ac80 5610MHz High Ant2




Band Edge NVNT ac80 5775MHz Mid Ant1




Band Edge NVNT ac80 5775MHz Mid Ant2




Band Edge NVNT n20 5180MHz Low Ant1




Band Edge NVNT n20 5180MHz Low Ant2




Band Edge NVNT n20 5240MHz High Ant1




Band Edge NVNT n20 5240MHz High Ant2



Band Edge NVNT n20 5260MHz Low Ant1



Band Edge NVNT n20 5260MHz Low Ant2



Band Edge NVNT n20 5320MHz High Ant1