

■ Getting started

1. Parts Checklist

Check the contents of the box – the Airplane BT Transmitter should contain: Transmitter adapter, Micro USB Cable & User Manual



2. Charging the Inflight Bluetooth Transmitter Adapter

The TransmitterAdapter comes with a built-in rechargeable battery. Before using it for the first time, it is recommended to fully charge the battery. When the Transmitter is low on power, the red LED will flash. This will be the time to recharge the battery.

Connect the Micro USB Cable to TransmitterAdapter's Micro USB socket to a standard charger with USB/A female port. The Red LED will be on during charging. It takes about 2 hours to charge the battery fully. When charging is complete, the red LED will be off.

Note: i. The adapter will be reboot while you connect the Micro USB Cable for charging.

ii. Please don't attempt to take the battery out of the Transmitter adapter as this may damage the product.

3. Switching the TransmitterAdapter on/off

Function	Operation	LED indicator
Switching on	Press the button for 3 seconds	Blue LED will be flashed at the same time for 1 second and Blue LED will flash every 5 seconds
Switching off	Press the button	Red LED will be flashed at the same time for 1 second and then off

	for 3 seconds	
--	---------------	--

4. LED indicator

LED indicator	Status
Blue/RED LEDs flashes alternately for 20 seconds	Pairing mode
Blue LED flashes once every 5 seconds	Standby mode and not connected to a Bluetooth device
Blue LED light will be always on	Connected to a Bluetooth device (Normal mode)
Red LED flashes twice every 5 seconds	The battery is low power

5. The pairing steps are as follows:

1. Keep the Transmitter adapter and your Bluetooth devices within 3feet;
2. Switch on your Bluetooth devices and make it enter pairing mode;
3. Make sure the Transmitter adapter is in Standby mode(Power-ON, not connected to device) then double-click the button on the Transmitter adapter, then the blue/red LED flashes alternately. At this time, the Transmitter adapter has entered pairing mode;
4. The Transmitter adapter will automatically search for the Bluetooth device and finish the connection;
5. After successful connection, the blue LED of the Transmitter adapter will be always on.
6. Once Transmitter adapter is paired with Bluetooth devices, insert the Transmitter adapter's audio plugs into inflight audio out socket, music or voice will be streamed out from the inflight entertainment system.

Notes: In pairing mode, the blue/red LED flash will last for 20 seconds, if no devices connected during this period, any new connection with Bluetooth devices, please follow above step #3.

6. Reconnect/Disconnect to a Bluetooth device

1) Automatic connection

Every time the Transmitter adapter is turned on, it will automatically connect to the last connected device.

2) Manual connection/dis-connection

When the Transmitter adapter is turned on, short press the button, and it will re-connect/dis-connect to the last connected device.

Notes: For Apple AirPods, please press the Transmitter Adapter's button to make sure the connection is completed every time.

■ Care and maintenance

Before using the Transmitter adapter, please read the following recommendations, it will help you to enjoy the product for many years.

- ◆ Do not expose the product to liquid, moisture or humidity to avoid the product's internal circuit being affected.
 - ◆ Do not expose the product to extremely high or low temperature as this will shorten the life of electronic devices, destroy the battery or distort certain plastic parts.
 - ◆ Don't use abrasive cleaning solvents to clean the product.
 - ◆ Don't dispose of the product in a fire as it will result in an explosion.
 - ◆ Don't expose the product to contact with sharp objects as this will cause scratches and damage.
 - ◆ Don't let the product fall down onto the floor. The internal circuit might get damaged.

Federal Communication Commission Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

- **FCC Caution:**

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

- **Non-modification Statement:**

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.