

Quick Start Guide

The following are the general user guide:

Step 1:

Screw the bulb into a standard socket.

Step 2:

Open the App and select "Register" to create new account or Log in with existing account.

Step 3:

Type Email, then select "Get Verification Code", Create password and select "Done".

Step 4:

Power up your lamp and select "Add Device".

For additional help, regulatory and safety Information, please go to: Federal Communications Commission (FCC) Interference Statement This device complies with Part 15 of the FCC Rules. Operation issubject to the following twoconditions:

- (1) This device may not cause harmful interference.
- (2) This device must accept any interference received, including interference that may cause undesired operation.

The grantee is not responsible for any changes or modifications notexpressly approved by the party responsible for compliance. Such modifications could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for aClass B digital device, pursuant to part 15 of the FCC Rules. Theselimits are designed to provide reasonable protection against harmfulinterference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not

installed and used in accordance with the instructions, maycause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or televisionreception, which can be determined by turning the equipment off and on,the user is encouraged to try to correct the interference by one or moreof the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- -Connect the equipment into an outlet on a circuit different from that towhich the receiver is connected.
- -Consult the dealer or an experienced radio/TV technician for help. This equipment complies with FCC radiation exposure limits set forthfor an uncontrolled environment. This equipment should be installed and operated with minimum distance of 20 cm between the radiator and yourbody.

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présentappareilestconforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitationestautoris é aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareildoit accepter tout brouillageradio dectriquesubi, mêmesi le brouillageest susceptible d'encompromettre le fonctionnement.

Radiation Exposure Statement:

This equipment complies with IC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20 cm between the radiator & your body.

D éclaration d'exposition aux radiations:

Cet équipementestconforme aux limites d'exposition aux rayonnements IC établies pour un environnement non contr îl é. Cet équipement doit être install é et utilis é avec un minimum de 20 cm de distance entre la source de rayonnement et votre corps.